

## Fuel Pump Components



- ① Valve plate for exhaust valve
- ② Valve spring for exhaust valve
- ③ Spring seat for exhaust valve
- ④ Gasket for valve retainer plate
- ⑤ Pump Cover
- **6** Valve retainer plate
- ⑦ Valve spring for intake valve
- ® Valve plate for intake valve



- ① Housing cover top
- ② Filter

 $\frac{1}{C}$ 

- 3 Housing cover
- ④ Diaphragm
- ⑤ Diaphragm spring
- 6 Pump housing