Summary of Tolerances and Wear Limits

Front Axle and Steering

***************************************			· · · · · · · · · · · · · · · · · · ·	
Measuring point		Tolerance (new) mm	Wear limits mm	
1. Suspension arm	twist	max. 0,2	_	
	전 : 1 전 : 1 E :	2		
Suspension arm / plastic bushing (try to reach max. limit, bushing tending to swell)	Radial play	0,15 – 0,22	0,30	
3. Suspension arm link pin / bushing	Play	0,042 – 0,087	0,20	
4. Suspension arm link pin	dia.	17,940 – 17,913	17,800	