

Fig. 160

	Va	lve Dimen	sions		
		10 mm (.3 Exhaust		94 in.) dia. Stem Intake	
А	37.9 to 3 1.492 to 1		30.9 to 3° 1.217 to 1.		
В	119.4 to 1 4.70 to 4		130.5 to 13 5.13 to 5.		
·C	9.98 to 9 .3929 to		9.96 to 9. .3921 to		
, b	1.7 to 2 .067 to		2.0 to 2.3		





Fig. 161

28 EN



Observe the following points when seating valves:

- 1. Use a fine grained grinding paste to avoid seat roughness.
- 2. Seat valves using suction cup P 9.
- 3. Thoroughly clean grinding paste from cylinder head.

Note

Grinding paste is water soluble and should not be mixed with oil. Wash cylinder head and valves with water after seating; gdry and oil parts before installing.