- 5. Install the rubber gasket on the new glass and install the glass so that the shaded portion is at the top of the frame.
- 6. Position the rubber gasket so that it will furnish a waterproof seal.
- 7. Install spring clips, carefully spacing them around the circumference of the frame.
- 8. Install and aim the headlight (28 LI).

When installing headlight lenses it is important that the glass makes a waterproof seal with the rim and that the retaining clips are uniformly spaced around the rim as in Fig. 57.

#### Aiming Headlights

## 28 LI

## Note

The adjustment is best performed with an optical headlight aiming device following the instructions furnished by the manufacturer.

In the event that such a device is not available; the lights may be aimed using a test screen.

# lights may be aimed using a test screen.

#### Adjus!ment

- Align the car perpendicular to the test screen or testing device.
- 2. The tire pressure must be correct and the car must be normally loaded. The normal load is considered to be equivalent to either a full fuel tank and no passenger or an empty tank and the driver. The loaded car must be rolled back and forth so that the rear suspension can adjust itself.
- 3. The aiming can now be carried out in accordance with the local regulations.