

Fig. 144



- 11. Oil push rods until oil runs out of bottoms and insert into push rod tubes. (1600 Engines steel push rods, 1600 S Engines light alloy push rods.)
- 13. Install long rocker arm (1600 Engines).





Fig. 145

12. Install rocker arm bracket and tighten to 5 mkg (36 ft. lb.) torque.