Removing Hardtop to Install Soft Top

The installation of the soft top is similar to the operation involved in installing the hardtop with the addition of the following points:

- body. When the top is fully connected to the windshield and body, it must be properly tensioned and without folds.
- The convertible top has two connections where an additional bow is mounted to the body. These must be adjusted after installation for proper length before tightening the clamps.
- 2. The cloth top does not require the cord in the weather strip since it has a different seal with the

In the event that no convertible top was previously installed, the holes for the side panels must be made as in step "11" previous page, with the exception that the hole must be located "a" $4.5 \, \text{cm}$ and "b" $4.5 \, \text{cm}$ ($13/4 \, \text{in.}$).

Note

For new convertible tops it is advisable to install the roof in the raised position and tighten the bolts after the roof has been loosely fitted.