## Removing and Installing Master Cylinder

## 1 Ti

## Removal

- 1. Jack up car.
- 2. Open front hood, take out spare wheel an tools.
- Fold rubber mat (except in Roadster) sideways and unscrew cover to steering gear.
- pedal side.

  7. Pull protective cap from master cylinder. (see fig. 6)

6. Take rubber mat out of car remove floor board at

8. Undo retaining screws of master cylinder and remove master cylinder.




Fig. 5

## Installation

The master cylinder is installed in reverse order, observing the following points:

- When placing the master cylinder into position, the brake push rod must be inserted correctly right from the beginning. Moreover, the master cylinder flange should be sealed with sealing compound, in order to avoid water entering the car inside.
- 2. Adjust clearance between brake push rod and piston in master cylinder, after loosening the locknut on the brake push rod. Clearance approx. .04" (1 mm).
- 4. Disconnect cable on stop light switch.
- 5. Unscrew brake lines from master cylinder and plug openings (with bleeder dust caps).




Fig. 6




Fig. 7

3. Adjust and bleed brakes (13 Ti). Do not forget bleeder dust caps.