
HEATING AGGREGATE, MODEL BN4

The Eberspächer BN 4 Heater will be installed either in the 6 or the 12 volt execution, according to the car's electrical system. Please pay the necessary attention when ordering spare parts.

See Supplements to Catalogue of Spare Parts 356 B, Group 7/13 aA and 7/13 A.



- 1. Cover plate
- 2. Fresh air fan
- 3. Pressure governor
- 4. Fuel line connection
- 5. Magnetic valve
- 6. Injector
- 7. Ignition coil
- 8. Cable connector

- 10. Overheat safety switch
- 11. Thermo switch
- 12. Relay
- 13. Governor switch
- 14. Electric motor
- 15. Air intake
- 16. Fan for burner
- 18. Combustion chamber
- 19. Exhaust pipe
- 20. Outer housing
- 21. Fuel filter
- 22. Heat exchanger
- 23. Fuel pump
- 24. Hot air discharge

- F = fresh air
- W = hot air
- V = combustion air
- A = exhausts




Fig. 2




Fig. 3