
DESCRIPTION of the LOUDSPEAKER INSTALLATION in VEHICLES TYPE 356A and 356B

Coupé Chassis - No. 117 601 From " 155 601 Cabrio 201 601 Hardtop 89 601 Roadster

a modified loudspeaker system will be installed. Figures 1 and 2 show the difference in the exterior appearance of the systems. The tone of the new loudspeaker has been improved.






Fig. 1

The following parts are required for installation:

644.645.504.00

New loudspeaker system

2 Loudspeakers

2	Retaining rings	644.645.515.00
2	Decorative frames	644.645.513.01
2	Grilles	644.645.511.01
8	Fixing angles	644.645.517.00
8	Cheese head tapping	
	screws	B 3,5x22 DIN 7971

Old loudspeaker system

Loudspeakers	644.645.501.00
Grilles	644.645.511.00
Decorative frames	644.645.513.00
Cheese head screws	M 4x10 DIN 84
Washers	4,3 DIN 125
Spring washers	A 4 DIN 137
	Grilles Decorative frames Cheese head screws Washers

INSTALLATION

1. Solder the cables supplied to the two loudspeakers. The cable ends must not touch the loudspeaker case. With "Becker" radio models the cables have to be extended. Cable diameter 0.75 mm².

Pay attention not to damage the membrane.

- 2. Cut out the lining covering the loudspeaker cups on the right and left sidewall. Determine their position by going over the lining with the hand.
- 3. Find the holes for the fixing screws of the loudspeaker in the same way. Cut out the lining covering the holes.

Fig. 2