## Ventilation lever position 2

The ventilation flaps convey the .air entering when vehicle is in motion to the windshield defroster slots.





Fig. 16

Fig. 17

## Ventilation lever position 3

The ventilation flaps in the fresh air ducts convey the air entering when vehicle is in motion to the floor level.



SB 10