## TYPE 741 TRANSMISSION

## Commencing with transmission Serial No. 50 001

Shown below for comparison with the previous version are modifications incorporated into transmissions beginning with serial No. 50 001. Service operations outlined in the 356 B Service Manual and supplements are not affected by these changes.

Up to Transmission No. 49 500

Beginning with Transmission No. 50 001

| Nomenclature, Part Number, and Interchangeability   | Characteristic | Nomenclature, Part Number, and Interchangeability | Characteristic |
|---|----------------|---|----------------|
| Brake band segment 716.302.316.02 interchangeable with 741.302.316.00, but only in conjunction with stop 741.302.317.00   |                | Brake band segment<br>741.302.316.00              |                |
| Stop 716.302.317.02 inter - changeable with 741.302.317.00 but only in conjunction with brake band segment 741.302.316.00 |                | Stop 741.302.317.00                               |                |
| Locking ring 716.302.321.01   | 0              | Locking ring 741.302.311.00 reinforced            | 0              |