Supplements for Group R: Rear Axle and Transmission

1	ı	
Operations, Descriptions	Page	Remarks
Transmission Housing:		
Change in Transmission Front Suspension	SR 1	Transmission Type 741
		beginning with trans, No. 35 001
	;	
Transmission 741, Section View	SR 3	
Transmission 741, Section View		
starting with Trans. No. 50 001	SR 17	
Gear Box:	٠	
	÷	
Special Gear Combinations:		
Converting the Pinion Shaft	SR 5	
Converting the Main Shaft	SR 6	
Transmission Diagram, Special Gear Ratio for Hill		
Climbs	SR 7	·
Transmission Diagram, Special Gear Ratio for the		
Nürburgring	SR 9	·
Transmission Dřagrams	SR 19	
Changes in Transmission Type 741, beginning with		
Trans. No. 50 001	SR 11	
Changes in Transmission Type 741, beginning with		
Trans. No. 51 017	SR 12	
Servo-Thrust Synchronization, beginning with		
Gearbox No. 50 001	SR 13	
Interchangeability of Input Shafts	SR 16	
•••••		·
Rear Axle Drive:		
ZF (Axle Self Servo) Limited Slip Standard	SR 27	
***************************************		and the second s

Operations, Descriptions	Page
Gear Shift Shaft:	ļ
Removing and Installing Gear Shift Shaft	SR 2
Shift Linkage Connector	SR 2
Rear Wheel Suspension:	
Rear Wheel Suspension 356 C	SR 31
Adjusting Rear Wheel Suspension	SR 33
Rear Axle Pivot Stop 356 C	SR 35
	مِ ا
	1

	1

Remarks

Transmission Type 741 beginning with trans. No. 35 001