


19. Install pistons and cylinders using cylinder base 24. Oil and install push rods. gasket (32 to 35 EN).




20. Fasten cylinders to crankcase using spacers P 18.



- 21. Install deflector plates and retaining springs (23 EN).
- 22. Install push rod tubes with oil seals.
- 23. Remove spacers P 18 and install cylinder heads (23 EN) noting correct position of deflector plates.





25. Install rocker arm assemblies (19 or 21 EN).




Fig. 58

26. Adjust valve clearance and install rocker box covers.