3. Safety switch

The safety switch comes into action when, for instance, the heater should fail to ignite or warm up, in which instance the safety switch shuts off the flow of current to the fuel solenoid and, thus, interrupts the flow of fuel to the combustion chamber.