### **User Manual - COBALTO**

### **Equipment**

- WiFi
- Air conditioning
- Heating
- Electrical panel
- Coffee machine
- Induction hob
- Dishwasher
- Safe

#### WiFi

Network name: PortapalacePassword: portapalaceamarena


# **Air Conditioning**

- Location: Bedroom
- Turn on using the ON/OFF button.
- Adjust temperature with the +/- buttons on the remote control.
- Adjust fan speed with the FAN button.
- For heating, select the "sun" symbol using the "Mode" button.



# Heating

- Type: Independent with thermostat.
- Location: Wall to the left of the entrance.
- To turn on the thermostat, press the sun button in the top right corner and adjust with the left arrows. The mode must always be set to the sun. To turn off, press the OFF button at the bottom right.



## **Electrical Panel**

• Location: Wall to the left of the entrance.



## **Coffee Machine**

- Nespresso: Turn on the coffee machine by pressing the cup button near the water tank.
- Once the blinking stops, the machine is ready to dispense coffee.
- Place the cup under the spout and press the cup button to dispense coffee.
- It stops automatically.



# **Induction Hob**

• Select the desired temperature using the two knobs at the bottom of the hob (right for the lower plate, left for the upper plate).



### Dishwasher

- Location: Lower level of the kitchen.
- The switch is behind the microwave.



#### Safe

- Location: Bottom left of the wardrobe in front of the bed.
- With the door open, press the RESET button inside the door, near the battery compartment. The safe will emit two beeps.
- Choose a new numeric code (3 to 8 digits), enter it on the keypad, and press # to confirm.
- If the padlock icon lights up, the code has been successfully set.
- If the exclamation mark icon flashes, the code was not set successfully. Repeat the steps until the code is correctly set.
- WARNING: Test the new code with the door open before closing it.
- At checkout, leave the door open.

