

Document Title	Specification of Log and Trace		
Document Owner	AUTOSAR		
Document Responsibility	AUTOSAR		
Document Identification No	853		

Document Status	published
Part of AUTOSAR Standard	Adaptive Platform
Part of Standard Release	R21-11

Document Change History					
Date	Release	Changed by	Description		
2021-11-25	R21-11	AUTOSAR Release Management	 Removed useless exceptionalsafety elements Provided a logmode to logchannel mapping configuration possibility Header files, c++ syntax errors clean-up Validation sets, typos and up-traces updates 		
2020-11-30	R20-11	AUTOSAR Release Management	 Introduced Non-modeled messages and Modeled messages to Chapter 7.3 Log Messages Introduced Logger::WithLevel() API, to log messages and pass the LogLevel as an API parameter Refactoring and editorial changes 		



2019-11-28	R19-11	AUTOSAR Release Management	 Removed Class LogManager. Moved remoteClientState() to Chapter 8.2 Function definitions (logging.h) Added Functional Cluster shutdown behavior. Added Funtional Cluster initialization via ara::core::Initialize() Removed TSYNC related spec items from Chapter 7.4 Refactoring and editorial changes Changed Document Status from Final to published
2019-03-29	19-03	AUTOSAR Release Management	 Changed APIs (Logstream, Logmanager, Logging) Refactoring and editorial changes
2018-10-31	18-10	AUTOSAR Release Management	Changed initialization APIsImproved referencesLog file definition
2018-03-29	18-03	AUTOSAR Release Management	Refactoring and editorial changesLog and Trace extensions added
2017-10-27	17-10	AUTOSAR Release Management	No content changes
2017-03-31	17-03	AUTOSAR Release Management	Initial release



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Table of Contents

1	Introduction and functional overview	7
2	Acronyms and Abbreviations	8
3	Input documents & related standards and norms	9
	3.1 Input documents	9
4	Constraints and assumptions	10
	4.1 Known limitations	10 10
5	Dependencies to other Functional Clusters	11
	5.1 Platform dependencies	11
6	Requirements Tracing	12
7	Functional specification	15
	7.1 Functional Cluster Lifecyle	15 15 15
	7.2 Necessary Parameters and Initialization	16 16
	7.2.1.1 Application Description	17
	7.2.2 Default Log Level	17
	7.2.3 Log Mode	18 19
	7.2.3.1 Log File Path	19
	7.2.5 Context Description	19
	7.2.6 Initialization of the Logging framework	19
		22
		22
		23
	the state of the s	23
		24 25
	7.4 Conversion Functions	28
	7.5 Log and Trace Timestamp	29
	7.6 Log and Trace data loss prevention	30
8	-	31
	8.1 API Common Data Types	31
		31
		31
	8.1.3 Format specifier	32

Specification of Log and Trace AUTOSAR AP R21-11



	8.1.4	LogHex8	38
	8.1.5	LogHex16	38
	8.1.6	LogHex32	39
	8.1.7		39
	8.1.8		39
	8.1.9		40
	8.1.10		40
	8.1.11		40
	8.1.12		41
8.2	Function	definitions	42
	8.2.1		42
	8.2.2		42
	8.2.3		43
	8.2.4		43
	8.2.5		43
	8.2.6		44
	8.2.7		44
	8.2.8		45
	8.2.9		45
	8.2.10		46
	8.2.11		46
	8.2.12		47
	8.2.13		47
	8.2.14		47
	8.2.15		48
	8.2.16		 48
	8.2.17		.0 49
	8.2.18		49
	8.2.19	-9	50
	8.2.20		50 50
	8.2.21		51
8.3	Class det		5. 52
0.0	8.3.1		52
	8.3.1.		
	8.3.1		54
	8.3.1		54
	8.3.1		58
	8.3.1		61
	8.3.2	71	65
	8.3.2		65
	8.3.2		65
	8.3.2		66
	8.3.2		66
	8.3.2		67
	8.3.2		67
	8.3.2		67
	U.U.L		

Specification of Log and Trace AUTOSAR AP R21-11



	8.3.2.8	Logger::WithLevel	 					68
Α	Mentioned Manifest E	lements						69



1 Introduction and functional overview

This specification specifies the functionality of the AUTOSAR Adaptive Platform Log and Trace.

The Log and Trace provides interfaces for Adaptive Applications to forward logging information onto the communication bus, the console, or to the file system. Each of the provided logging information has its own severity level. For each severity level, a separate method is provided to be used by applications or Adaptive Platform Services, e.g. ara::com. In addition, utility methods are provided to convert decimal values into the hexadecimal numeral system, or into the binary numeral system.

To pack the provided logging information into a standardized delivery and presentation format, a protocol is needed. For this purpose, the LT protocol can be used, which is standardized within the AUTOSAR consortium.

The LT protocol can add additional information to the provided logging information. This information can be used by a Logging client to relate, sort or filter the received logging frames.

Detailed information regarding the use cases and the LT protocol itself are provided by the PRS Log and Trace protocol specification. For more information regarding the LT protocol refer to [1].




Figure 1.1: Architecture overview

Furthermore, this document introduces additional specification extensions for the AUTOSAR Adaptive Platform Log and Trace.



2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the Log and Trace module that are not included in the [2, AUTOSAR glossary].

Abbreviation / Acronym:	Description:
Log and Trace	The official Functional Cluster name that manages the logging
L&T	Acronym for Log and Trace
LT protocol	Original name of the protocol itself (Log and Trace), specified in the
	PRS document [1]
Logging API	The main logging interface towards user applications as a library
Logging back-end	Implementation of the LT protocol, e.g. DLT
Logging Client	An external tool which can remotely interact with the Logging frame-
	work
Logging framework	Implementation of the software solution used for logging purposes
Logging instance	The class that enables the logging functionality and handles a single
	logging context
Log message	Log message, including message header(s)
Log severity level	Meta information about the severity of a passed logging information
DLT	Diagnostics Log and Trace - a GENIVI Log and Trace daemon imple-
	mentation of the LT protocol
Application process	An executable instance (process) that is running on a Machine

The following technical terms used throughout this document are defined in the official [2] AUTOSAR Glossary or [3] TPS Manifest Specification – they are repeated here for tracing purposes.

Term	Description
Adaptive Application	see [2] AUTOSAR Glossary
Application	see [2] AUTOSAR Glossary
AUTOSAR Adaptive Platform	see [2] AUTOSAR Glossary
Adaptive Platform Foundation	see [2] AUTOSAR Glossary
Manifest	see [2] AUTOSAR Glossary
Executable	see [2] AUTOSAR Glossary
Functional Cluster	see [2] AUTOSAR Glossary
Adaptive Platform Service	see [2] AUTOSAR Glossary
Machine	see [2] AUTOSAR Glossary
Service	see [2] AUTOSAR Glossary
Service Interface	see [2] AUTOSAR Glossary
Service Discovery	see [2] AUTOSAR Glossary

Table 2.1: Glossary-defined Technical Terms



3 Input documents & related standards and norms

3.1 Input documents

- [1] Log and Trace Protocol Specification AUTOSAR PRS LogAndTraceProtocol
- [2] Glossary AUTOSAR_TR_Glossary
- [3] Specification of Manifest
 AUTOSAR TPS ManifestSpecification
- [4] General Requirements specific to Adaptive Platform AUTOSAR RS General
- [5] Specification of Adaptive Platform Core AUTOSAR SWS AdaptivePlatformCore
- [6] Log and Trace Protocol Specification with protocol version "2" AUTOSAR PRS LogAndTraceProtocol from Release R21-11
- [7] Log and Trace Protocol Specification with protocol version "1" AUTOSAR_PRS_LogAndTraceProtocol from Release R20-11
- [8] Requirements on Log and Trace AUTOSAR_RS_LogAndTrace
- [9] Specification of Time Synchronization AUTOSAR_SWS_TimeSynchronization

NOTE: [4, RS-RSGeneral] is listed here as an input document because it applies to SWS LogAndTrace as well as to all SWS documents of the Adaptive Platform. Since it includes only non-functional requirements the tracing is not necessary.

3.2 Further applicable specification

AUTOSAR provides a core specification [5, SWS AdaptivePlatformCore] which is also applicable for Log and Trace. The chapter "General requirements for all Functional Clusters" of this specification shall be considered as an additional and required specification for implementation of Log and Trace.

AUTOSAR provides a core specification [5] which is also applicable for Log and Trace. The chapter "General requirements for all Functional Clusters" of this specification shall be considered as an additional and required specification for implementation of Log and Trace.



4 Constraints and assumptions

4.1 Known limitations

The provided Logging framework API is designed to be independent from the underlying Logging back-end implementation and as such doesn't impose limitations.

Although Log and Trace Protocol version "2" (compare [6]) is already available, Log and Trace currently only supports version "1" of the Log and Trace Protocol [7].

4.2 Applicability to car domains

No restrictions to applicability.



5 Dependencies to other Functional Clusters

There are no dependencies to other Functional Clusters.

5.1 Platform dependencies

This specification is part of the AUTOSAR ${\tt AUTOSAR}$ ${\tt Adaptive}$ ${\tt Platform}$ and therefore depends on it.



6 Requirements Tracing

The following table references the requirements specified in RS Log And Trace [8] and links to the fulfillment of these. Please note that if column "Satisfied by" is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[RS_AP_00155]	Avoidance of	[SWS_LOG_00122] [SWS_LOG_00123]
	cluster-specific	
	initialization functions.	
[RS_LT_00003]	Applications shall	[SWS_LOG_00001] [SWS_LOG_00002]
	have the possibility to	[SWS_LOG_00004] [SWS_LOG_00005]
	send log or trace	[SWS_LOG_00006] [SWS_LOG_00007]
	messages to the LT	[SWS_LOG_00008] [SWS_LOG_00009]
	module.	[SWS_LOG_00010] [SWS_LOG_00011]
		[SWS_LOG_00012] [SWS_LOG_00013]
		[SWS_LOG_00015] [SWS_LOG_00016]
		[SWS_LOG_00017] [SWS_LOG_00018]
		[SWS_LOG_00019] [SWS_LOG_00021]
		[SWS_LOG_00022] [SWS_LOG_00023]
		[SWS_LOG_00024] [SWS_LOG_00025]
		[SWS_LOG_00026] [SWS_LOG_00027]
		[SWS_LOG_00028] [SWS_LOG_00029]
		[SWS_LOG_00030] [SWS_LOG_00031]
		[SWS_LOG_00032] [SWS_LOG_00033]
		[SWS_LOG_00034] [SWS_LOG_00035]
		[SWS_LOG_00036] [SWS_LOG_00037] [SWS_LOG_00039] [SWS_LOG_00040]
		[SWS_LOG_00041] [SWS_LOG_00042]
		[SWS_LOG_00043] [SWS_LOG_00044]
		[SWS LOG 00045] [SWS LOG 00046]
		[SWS_LOG_00047] [SWS_LOG_00048]
		[SWS LOG 00049] [SWS LOG 00050]
		[SWS_LOG_00051] [SWS_LOG_00053]
		[SWS_LOG_00054] [SWS_LOG_00055]
		[SWS_LOG_00056] [SWS_LOG_00057]
		[SWS_LOG_00058] [SWS_LOG_00059]
		[SWS_LOG_00060] [SWS_LOG_00062]
		[SWS_LOG_00063] [SWS_LOG_00064]
		[SWS_LOG_00065] [SWS_LOG_00066]
		[SWS_LOG_00067] [SWS_LOG_00068]
		[SWS_LOG_00069] [SWS_LOG_00070]
		[SWS_LOG_00082] [SWS_LOG_00083]
		[SWS_LOG_00091] [SWS_LOG_00095]
		[SWS_LOG_00098] [SWS_LOG_00108]
		[SWS_LOG_00109] [SWS_LOG_00110]



Requirement	Description	Satisfied by
•		[SWS_LOG_00111] [SWS_LOG_00112]
		[SWS_LOG_00113] [SWS_LOG_00114]
		[SWS_LOG_00115] [SWS_LOG_00120]
		[SWS_LOG_00122] [SWS_LOG_00123]
		[SWS_LOG_00124] [SWS_LOG_00128]
		[SWS_LOG_00129] [SWS_LOG_00130]
		[SWS_LOG_00131] [SWS_LOG_00173]
		[SWS_LOG_00201] [SWS_LOG_00203]
		[SWS_LOG_00204] [SWS_LOG_00205]
[RS_LT_00017]	Each log and trace	[SWS_LOG_00083]
	message shall contain	
	a timestamp, which	
	will be added to the	
	message during	
	reception of the	
	message in the LT	
	module.	
[RS_LT_00030]	Logging shall be able	[SWS_LOG_00095]
	to monitor and shape	
	the amount of LT log	
	and trace events.	
[RS_LT_00045]	Logging shall enable	[SWS_LOG_00007]
	applications to check	
	the current severity	
	level.	
[RS_LT_00046]	Logging shall provide	[SWS_LOG_00015] [SWS_LOG_00016]
	conversion functions	[SWS_LOG_00017] [SWS_LOG_00120]
	for hexadecimal and	[SWS_LOG_00206] [SWS_LOG_00207]
	binary values.	[SWS_LOG_00208] [SWS_LOG_00209]
		[SWS_LOG_00210] [SWS_LOG_00211]
		[SWS_LOG_00212] [SWS_LOG_00213]
		[SWS_LOG_00214] [SWS_LOG_00215]
		[SWS_LOG_00216] [SWS_LOG_00217]
		[SWS_LOG_00218] [SWS_LOG_00219]
		[SWS_LOG_00220] [SWS_LOG_00221]
		[SWS_LOG_00222] [SWS_LOG_00223]
		[SWS_LOG_00224] [SWS_LOG_00225]
IDC 17 000471	Logging shall sures and	[SWS_LOG_00226]
[RS_LT_00047]	Logging shall support	[SWS_LOG_00004]
	initialization and	
[DC LT 00040]	registration.	[EWIS OC 00004]
[RS_LT_00048]	Logging shall enable	[SWS_LOG_00004]
	applications to provide	
IDC IT 000401	meta information.	[00000 00.1 9W9] [00000 00.1 9W9]
[RS_LT_00049]	Logging shall enable	[SWS_LOG_00008] [SWS_LOG_00009]
	applications to provide	[SWS_LOG_00010] [SWS_LOG_00011]
	Logging Information.	[SWS_LOG_00012] [SWS_LOG_00013]
		[SWS_LOG_00125] [SWS_LOG_00126]
IDC IT 000501	Logging shall support	[SWS_LOG_00127] [SWS_LOG_00130]
[RS_LT_00050]	Logging shall support	[SWS_LOG_00005] [SWS_LOG_00006]
	grouping of Logging	
	Information.	



Requirement	Description	Satisfied by
[RS_LT_00052]	Logging shall provide early logging capabilities.	[SWS_LOG_00001]



7 Functional specification

This specification defines the usage of the defined C++ Logging API for the Log and Trace. Adaptive Applications can use these functions to forward Log messages to various sinks, for example the network, a serial bus, the console or the file system.

The following functionalities are provided:

- 1) Methods for initializing the Logging framework (see 7.3)
- 2) Utility methods to convert decimal values into hexadecimal or binary values (see 7.4)
- 3) Automatic timestamping of Log messages (see 7.5)
- 4) Log and trace network bandwith limitation (see chapter 7.6)

Adaptive Applications and Functional Clusters can startup (see 7.1.1) and shutdown (see 7.1.2) all Functional Clusters with direct ARA interfaces (e.g. the Logging framework), by calling ara::core::Initialize() or ara::core::Deinitialize().

7.1 Functional Cluster Lifecyle

7.1.1 Startup

In order to initialize the Logging framework, mandatory information needs to be provided to the Logging framework. These information are extracted from the application execution manifest and the AUTOSAR Meta-Model. The execution manifest parameter <code>Executable.loggingBehavior</code> defines if the logging functionality should be initialized. Initialization of the Logging framework (via <code>ara::core::Initialize</code>) is mandatory before usage of any <code>ara::log</code> API. Failure to do so will result in undefined behavior.

[SWS_LOG_00001] [Log message logged before the Logging framework is able to process them (e.g. daemon communication is not established) shall be queued. The queue size is defined by LogAndTraceInstantiation.queueSize. If this size is exceeded the oldest entries shall be discarded. | (RS LT 00003, RS LT 00052)

7.1.2 Shutdown

[SWS_LOG_00122]{DRAFT} [When ara::core::Deinitialize() is called, the Logging framework shall make sure, that no new client connections can be established.] (RS_-LT_00003, RS_AP_00155)



[SWS_LOG_00123]{DRAFT} [When ara::core::Deinitialize() is called, the Logging framework shall take care that all remaining messages in the buffer can be collected, if a client is connected. | (RS_LT_00003, RS_AP_00155)

7.2 Necessary Parameters and Initialization

The concept of identifying the user application:

To be able to distinguish the logs of different application instances within a system (e.g. an ECU or even the whole vehicle), every Application process, in that system, has to get a particular ID and a description.

The concept of log contexts:

In order to be able to distinguish the logs from different logical groups within an Application process, for every context within an Application process a particular ID and a description has to be assigned. Every Application process can have an arbitrary amount of contexts, but at least one — the default context.

Machine-specific configuration settings for the Log and Trace functional cluster are collected in LogAndTraceInstantiation. The Application processes using the Logging framework need to supply the following configuration through the application execution manifest:

- Application ID
- Application description
- The default log level, if not set through the manifest a default predefined value is set
- The log mode
- The log file path, in case of a specific log mode that indicates logging to a file

The Application process using the Logging framework creates a Logging instance per context. The context is defined at creation of the Logging instance and the following information should be provided:

- Context ID
- Context description
- The default log level, if not set through the manifest a default predefined value is set

7.2.1 Application ID

The Application ID is an identifier that allows to associate generated logging information with its user application. The Application ID is passed as a string value. Depending on the Logging framework actual implementation, i.e. Logging back-end,



the length of the Application ID might be limited. To be able to unambiguously associate the received logging information to the origin, it is recommended to assign unique Application IDs within one ECU. There is no need for uniqueness of Application IDs across ECUs as the ECU ID will be the differentiator. The system integrator has the overall responsibility to ensure that each Application process instance has a unique Application ID. By having this value defined in the manifest the integrator is able to perform consistency checks. The applicationId in the DltApplication identifies the application instance and is put as ApplicationId into the log and trace message.

Note:

The Application IDs are unique IDs per Application process, meaning if the same Application process is started multiple times it shall have an own ID per instance.

The length limits of the Application ID apply only to version-1 of the PRS LogAndTraceProtocol.

7.2.1.1 Application Description

Since the length of the Application ID can be quite short, an additional descriptive text can be provided. This description is passed as a string and the maximum length is implementation dependent. The applicationDescription in the DltApplication is an optional setting that allows to describe the applicationId as descriptive text.

7.2.2 Default Log Level

The Log severity level represents the severity of the log messages. Severity levels are defined in chapter 7.3. defaultLogThreshold in the DltLogSink defines the initial log reporting level for the application instance.

Each initiated log message is qualified with such a severity level. The default Log severity level is set through the application configuration per Application process. The Log severity level acts as a reporting filter. Only log messages having a higher or the same severity will be processed by the Logging framework, while the others are ignored.

The default Log severity level is the initially configured log reporting level for a certain Application process, though it can be overriden per context.

The Application process wide log reporting level shall be adjustable during runtime. The realization is an implementation detail of the underlying back-end. E.g. remotely via a Logging client for example DLT Viewer. The same applies for the context reporting level.

The design rationale for providing an initial default Log severity level application wide against having per context default Log severity levels is the following:



- It simplifies the API usage. Otherwise the user will have to define a context default Log severity level for each group before using the API.
- The context separation of Log messages is possible during runtime.

7.2.3 Log Mode

Depending on the Logging framework implementation, the passed logging information can be processed in different ways. The destination (the Log message sink) can be the console output, a file on the file system or the communication bus. The system integrator is responsible to populate this information in the machine manifest. A direct API for dynamically changing this value for development purposes is provided. In the AUTOSAR Meta-Model the category of DltLogSink is equivalent to the log mode described here, for more information see [3]. The category of DltLogSink defines the destination to which the log messages will be forwarded.




Figure 7.1: Log mode

As shown in the diagram, once the log mode is set to use the Logging back-end the configuration is of that back-end is centralized in the Machine manifest configuration. For example, the Logging back-end can be configured to store the logging information locally and that configuration would be kept in the Machine-specific manifest. Furthermore, the output channel on Ethernet for Log messages is configured with the PlatformModuleEthernetEndpointConfiguration that is referenced by DltLogSink in the role endpointConfiguration.



7.2.3.1 Log File Path

In case the log mode is set to log to a file, a destination directory path needs to be provided. path in the DltLogSink defines the destination file to which the logging information is passed. This option is provided for development, integration and prototyping purposes and is not suitable for production.

7.2.4 Context ID

The Context ID is an identifier that is used to logically group logging information within the scope of an Application process. The Context ID is passed as a string value. Depending on the actual implementation of the Logging back-end, the length of the Context ID might be limited. Context ID is unique in the scope of an Application process and as such the developer is responsible for assigning it and this information is not modeled in the manifest. There is no need for uniqueness of Context IDs across multiple different Application processes as the Application ID will be the differentiator.

Note:

Special attention should be paid to library components. The libraries are meant to be used by Application processes and therefore are running within the Application process' scope. Logging executed from those libraries will end up inside the scope of the parent Application process. In order to distinguish the internal library logs from the Application process logs or from other library logs within same process, each library might need to reserve its own Context IDs system wide – at least when it shall be used by more than one Application process.

The length limits of the Cotext ID apply only to version-1 of the PRS LogAndTraceProtocol.

7.2.5 Context Description

Since the length of the Context ID can be quite short, an additional descriptive text must be provided. This Context description is passed as a string. The maximum length of the Context description is implementation dependent.

7.2.6 Initialization of the Logging framework

The Application ID and description are used to identify and to associate the provided logging information with the exact process. The log mode and sink information defines where the logging information is routed. Possible destinations are the console, the file system or the communication bus.



From the Application process' perspective, the Logging framework is intialized and a logger instance is created when an Application process decides to register a logging context. These contexts are used to logically cluster logging information.

[SWS_LOG_00002]{DRAFT} In case of any errors occurring inside the Logging framework or underlying system, it is intended to not bother the Application process and silently discard the function calls. For this purpose, the relevant interfaces neither specify return values nor throw exceptions. | (RS LT 00003)

[SWS_LOG_00004]{DRAFT} [Logging framework shall be initialized if the execution manifest provides the following information for the Logging framework:

- An application ID (Mandatory; if missing, a *Violation* shall be issued)
- An application description (if missing, it can be filled with string with no characters or default values)
- The default Log severity level (default value: kWarn)
- The log mode (default value: kConsole)
- The directory path (only necessary if LogMode::kFile is given as log mode)

(RS LT 00003, RS LT 00047, RS LT 00048)

[SWS_LOG_00005] [The function ara::log::CreateLogger shall create a logger context instance internally inside the Logging framework and return it as reference to the using application. Before a Log message can be processed, at least one logger context shall be available. | (RS LT 00003, RS LT 00050)

Note:

This strong ownership relationship of contexts to the Logging framework ensure correct housekeeping of the involved resources. The design rationale is, once a context is registered against the Logging back-end, its lifetime must be ensured until the end of the Application process.

[SWS_LOG_00006] [By calling CreateLogger(), the following parameters need to be provided:

- The context ID
- The context description
- The Log severity level (as an optional parameter, defaults to LogLevel::kWarn)

|(RS_LT_00003, RS_LT_00050)

[SWS_LOG_00007] [Application processes should be able to check if a desired Log severity level is configured through the function ara::log::Logger::-IsEnabled. This mechanism conserves CPU and memory resources that are used



during preparation of logging information, as this logging information is filtered by the Logging framework later on. $\[(RS_LT_00003, RS_LT_00045) \]$



7.3 Log Messages

Log messages can generally be output to different targets. The Log and Trace Functional Cluster supports these logging targets:

- the console
- a file on a local file system
- a network

Most of the discussion in this section assumes that messages are being output to a network, as this use case requires the additional consideration of minimizing network load.

The Log And Trace Functional Cluster offers two principal "classes" of log messages: *Modeled* and *Non-Modeled* messages. Both these support adding one or more "arguments" to a log message. A log message without any arguments serves no purpose and is discarded.

Non-Modeled messages are the traditional way of composing log messages: All arguments of the message are added to an internal message buffer and then eventually serialized for output, either to a console/file, or via network. All parts of the messages will be sent via network. In the DLT protocol, these messages are called "verbose" messages.

Modeled messages are designed to reduce traffic on the network, by omitting certain static (i.e. unchanging) parts of a message from the network. As the name suggests, these parts are instead added to the application ARXML model. In the DLT protocol, these messages are called "non-verbose" messages. A log message viewer application is able to display the full message by combining the static parts from the model with the dynamic parts from the received message.

Non-modeled messages are mainly used during development, as the information required for the modeled messages may not be available at that time. However, non-modeled messages can impose a high load on the network, making modeled messages usually the preferred choice in production systems.

The ara::log Functional Cluster supports defining and using both modeled and non-modeled messages in a single application at the same time.

7.3.1 Non-modeled messages

The ara::log Functional Cluster defines a "Builder"-pattern inspired set of APIs for constructing non-modeled messages. The ara::log::Logger::WithLevel member function is used for creating a ara::log::LogStream object which is then subsequently filled with message content (i.e. message arguments). Alternatively to ara::log::Logger::WithLevel, there are also separate member functions for creating a ara::log::LogStream object, one per supported log level.



Arguments are added to a verbose message by calling an appropriate operator<< overload for the desired argument:

```
logger.WithLevel(LogLevel::kInfo) << "text" << 4.2;</pre>
```

The ara::log Functional Cluster defines such operator<< overloads for all C++ arithmetic types, for bool, for string types, and for a number of ara::core types. Application-defined data types can be logged as well, by providing suitable operator<< overloads for them.

As the application model allows "annotating" arguments with attributes, the ara::log API for non-modeled messages also supports this. Arguments of certain types can be annotated with a "name" and possibly also a "unit" attribute. For instance:

```
1 logger.WithLevel(LogLevel::kInfo)
2 << Arg("text", "identifier")
3 << Arg(4.2, "velocity", "m/s");</pre>
```

The string argument "text" is annotated with a "name" attribute called "identifier". The double argument 4.2 is annotated with a "name" attribute "velocity" and a "unit" of "m/s". These attributes can only be set for some of the built-in types that the ara::log API supports, i.e. all arithmetic types, bool, strings, and raw data blobs.

Non-modeled messages can also contain information about the location of the log message call in source code. For this purpose, the member function <code>ara::log::-LogStream::WithLocation</code> is called with the filename and line number of the call site. These should usually come from the compiler-defined <code>__FILE__</code> and <code>__LINE__</code> symbols:

```
1 logger
2 .WithLevel(LogLevel::kInfo)
3 .WithLocation(__FILE__, __LINE__) << ...;</pre>
```

These are easiest set via a macro-based frontend for ara::log, but no such macro has yet been defined in the Adaptive Platform.

7.3.2 Modeled messages

7.3.2.1 API principles

The ara::log Functional Cluster defines a single member function ara::log::-Logger::Log for sending modeled messages. Unlike the non-modeled message APIs, it represents a single-call interface, i.e. a single function call passes all arguments to the Logger instance and performs all necessary actions to generate and send the message.

This has the advantage that the runtime cost for a modeled message that is eventually not being output (because the message's log level does not reach the configured log level threshold) can be made very small: after parameter passing and function call, a single if clause checks the log level threshold and immediately returns if the threshold



is not reached. This contrasts with the non-modeled message APIs, where multiple function calls are performed for constructing a message object, even if that is then eventually discarded.

7.3.2.2 Log message model

All modeled messages are defined as DltMessages, which are aggregated by a LogAndTraceMessageCollectionSet. Each DltMessage contains a messageId, which needs to be unique within an ECU, and the messageTypeInfo denoting the log level, and optionally the messageSourceFile and messageLineNumber. The DltMessage aggregates an ordered list of DltArguments, which in turn aggregate SwDataDefProps in the role networkRepresentation. The name of a log message argument is taken from the shortName of the DltArgument, while the type and unit are taken from the SwDataDefProps.

At design time it is possible to define an Executable with a SwComponentPrototype that has a PortPrototype typed by an LogAndTraceInterface. Such a PortPrototype is used to describe that the SwComponentPrototype is able to forward logging information onto the external Dlt Log Viewer. The DltMessages that are used by the SwComponentPrototype are collected in the LogAndTraceMessageCollectionSet that is referenced from the PortPrototype.

At deployment time a mapping of the PortPrototype typed by a LogAndTraceInterface to a DltLogSink is described with the DltLogSinkToPortPrototypeMapping that takes a Process of the Executable as context into account.

The DltLogSink is referenced by the LogAndTraceInstantiation that in turn is associated with the DltEcu that carries the ecuId. The LogAndTraceInstantiation itself defines with sessionIdSupport whether session IDs are used or not. The DltLogSinkToPortPrototypeMapping defines the dltSessionId and contains a reference to DltContext that defines the contextId and the corresponding contextDescription. The Process in which the Executable is executed is assigned with the DltApplication that defines the applicationId and the corresponding applicationDescription.

The DltLogSink defines with the category the type of the output sink: Dlt-LogSinkRemote, DltLogSinkDlt, DltLogSinkFile, DltLogSinkConsole.

In case the <code>DltLogSink</code> has the category <code>DltLogSinkRemote</code> to provide means to forward logging information to a <code>Dlt log channel the logChannelId</code> is defined. In case the <code>DltLogSink</code> has the category <code>DltLogSinkDlt</code> to provide means to forward logging information onto on a specific <code>VLAN</code> the <code>endpointConfiguration</code> is defined in addition to <code>logChannelId</code>. The <code>nonVerboseMode</code> describes whether the modeled messages will be sent as verbose messages as if they were non-modeled messages. In case the <code>DltLogSink</code> has the category <code>DltLogSinkFile</code> to provide means to forward logging information to a file in path of a file system a <code>path</code> is defined. In case the <code>DltLogSink</code> has the category <code>DltLogSinkConsole</code> to provide means to forward



logging information the console the bufferOutput attribute defines whether a buffer is used or not.

7.3.2.3 Usage

The C++ API assumes the existence of a tool that scans source code for modeled log message call sites and generates the expected symbols with unique IDs on-demand.

The framework is required to scan all source code for invocations of the ara::log::Logger::Log member function, and generate a symbol that matches the first argument of that member function call.

For instance, if the ARXML representation of the manifest contains the following:

and the source code contains this code sequence:

```
1 Logger& logger = ...
2 logger.Log(SpeedMsg, 4.2);
```

then the framework will define a global constexpr variable called <code>SpeedMsg</code> of an implementation-defined type. This variable contains knowledge about the message's modeled aspects, such as parameter types and log level, allowing the <code>ara::log implementation</code> to verify that the number of types of parameters given to <code>ara::log::-Logger::Log</code> matches the model of the particular message.

The message variable definitions will be made available via ara/log/logger.h.

Store LogStream objects in a variable:

It is also possible to use the Logging API in an alternative way by storing a ara::-log::LogStream object locally in some named variable. The difference to the temporary object is that it won't go out of scope already at the end of the statement, but stays valid and re-usable as long as the variable exists. Hence, it can be fed with data distributed over multiple lines of code. To get the message buffer processed by the Logging framework, the ara::log::LogStream::Flush method needs to be called, otherwise the buffer will be processed when the object dies, i.e. when the variable goes out of scope, at the end of the function block.

Performance remark:

Due to the fact that a ara::log::LogStream is no longer created per message but rather could be re-used for multiple messages, the costs for this object creation is paid only once — per log level. How much this really influences the actual performance



depends on the Logging framework implementation. However the main goal of this alternative usage of the Logging API is to get the multi-line builder functionality.

Note:

It is highly advised NOT to hold global ara::log::LogStream objects in multithreaded Applications, because then concurrent access protection will no longer be covered by the Logging API.

Usage examples:

```
Logger& ctx0 = CreateLogger("CTX0", "Context Description CTX0");
ctx0.LogInfo() << "Some log information" << 123;

// Locally stored LogStream object will process the arguments
// until either Flush() is called or it goes out of scope from
// the block is was created
Logger& ctx1 = CreateLogger("CTX1", "Context Description CTX1");
LogStream localLogInfo = ctx1.LogInfo();
localLogInfo << "Some log information" << 123;
localLogInfo << "Some other information";
localLogInfo.Flush();
localLogInfo << "a new message..." << 456;</pre>
```

Exception safety: All Log* () interfaces are designed to guarantee no-throw behavior. This applies for the whole Logging API.

New line: Because of convenience purposes the Logging framework automatically appends a newline to the Log message.

Multiple payload arguments: When one message consists of more than one payload argument, payload arguments are separated by single whitespaces for console output.

[SWS_LOG_00008]{DRAFT} [To initiate a Log message with the Log level Fatal, the API ara::log::Logger::LogFatal shall be called. This API returns a ara:-:log::LogStream object that has to be used by passing arguments via the insert stream operator<<.|(RS_LT_00003, RS_LT_00049)

[SWS_LOG_00009]{DRAFT} [To initiate a Log message with the Log level Error, the API ara::log::Logger::LogError shall be called. This API returns a ara:-:log::LogStream object that has to be used by passing arguments via the insert stream operator<<.](RS_LT_00003, RS_LT_00049)

[SWS_LOG_00010]{DRAFT} [To initiate a Log message with the Log level Warning, the API ara::log::Logger::LogWarn shall be called. This API returns a ara::log::LogStream object that has to be used by passing arguments via the insert stream operator<<.] (RS_LT_00003, RS_LT_00049)

[SWS_LOG_00011]{DRAFT} [To initiate a Log message with the Log level Info, the API ara::log::Logger::LogInfo shall be called. This API returns a ara:-:log::LogStream object that has to be used by passing arguments via the insert stream operator<<.|(RS_LT_00003, RS_LT_00049)



[SWS_LOG_00012]{DRAFT} [To initiate a Log message with the Log level Debug, the API ara::log::Logger::LogDebug shall be called. This API returns a ara:-:log::LogStream object that has to be used by passing arguments via the insert stream operator<<.|(RS_LT_00003, RS_LT_00049)

[SWS_LOG_00013]{DRAFT} [To initiate a Log message with the Log level Verbose, the API ara::log::Logger::LogVerbose shall be called. This API returns a ara::log::LogStream object that has to be used by passing arguments via the insert stream operator<<.|(RS LT 00003, RS LT 00049)

[SWS_LOG_00130]{DRAFT} [To write a Log message with a programmatically determined log level, the API ara::log::Logger::WithLevel shall be called.](RS_-LT 00003, RS LT 00049)



7.4 Conversion Functions

Sometimes it makes sense to represent integer numbers in hexadecimal or binary format instead of decimal format.

For this purpose, the following functions are defined to convert provided decimal numbers into the hexadecimal or binary system.

[SWS_LOG_00120]{DRAFT} | Dedicated conversion functions are provided for conversion of positive decimal numbers into a string with hexadecimal or binary representation.|(RS_LT_00003, RS_LT_00046)

[SWS_LOG_00015] {DRAFT} [Dedicated conversion functions are provided for conversion of decimal numbers into a string with hexadecimal or binary representation, where the most significant bit shall be set to '1' for negative numbers.] $(RS_LT_00003, RS_LT_00046)$

[SWS_LOG_00016]{DRAFT} [Function ara::log::HexFormat shall provide functionality to convert an integer decimal number into a string with hexadecimal representation.|(RS LT 00003, RS LT 00046)

[SWS_LOG_00017]{DRAFT} [Function ara::log::BinFormat shall provide functionality to convert an integer decimal number into a string with binary representation.] (RS LT 00003, RS LT 00046)



7.5 Log and Trace Timestamp

The Log and Trace information is transmitted by means of the LT protocol which is bus agnostic.

This protocol offers the possibility to include a timestamp in each sent message, as long as such messages are sent with an extended header (refer to [8] for more information).

The synchronized time base is supplied by the Time Synchronization Functional Cluster. The now() method is used by the Adaptive Applications in order to retrieve the current time from the TS (refer to [9] for more information).

According to the requirement [TPS_MANI_03162], the reference time base is derived from the machine manifest timeBaseResource.

[SWS_LOG_00082] [Log and Trace should have accesss to a synchronized time base. The attribute timeBaseResource in LogAndTraceInstantiation shall be used to identify the time base.] ($RS\ LT\ 000003$)

[SWS_LOG_00083] [If the time base resource is referenced by the Log and Trace module in the manifest configuration LogAndTraceInstantiation.timeBaseResource, the current timestamp information shall be included in each DLT message, otherwise not In case there is no time base resource referenced by the Log and Trace module in the manifest configuration, no timestamp information shall be transmitted.] (RS_LT_00003, RS_LT_00017)

[SWS_LOG_00091]{DRAFT} [When the CreateLogger() function is called, Log and Trace shall send a message, "local time base used" in case the used time base is a local time base or "global time base used" in case the used time base is a globally synchronized time base.

](RS_LT_00003)



7.6 Log and Trace data loss prevention

[SWS_LOG_00095]{DRAFT} [When Log and Trace receives simultaneously a high load of trace information generated by multiple Adaptive Applications, it shall buffer this data internally to prevent the data loss during its continuous transmission.] $(RS_LT_00003, RS_LT_00030)$



8 API specification

8.1 API Common Data Types

8.1.1 LogLevel

[SWS_LOG_00018]{DRAFT}

Kind:	enumeration	
Symbol:	LogLevel	
Scope:	namespace ara::log	
Underlying type:	std::uint8_t	
Syntax:	enum class LogLevel : std::uint8_t {};	
Values:	kOff= 0x00 No logging.	
	kFatal= 0x01	Fatal error, not recoverable.
	kError= 0x02	Error with impact to correct functionality.
	kWarn= 0x03 Warning if correct behavior cannot be ensured.	
	kInfo= 0x04 Informational, providing high level understanding.	
	kDebug= 0x05 Detailed information for programmers.	
	kVerbose= 0x06	Extra-verbose debug messages (highest grade of information)
Header file:	#include "ara/log/common.h"	
Description:	List of possible severity levels .	

|(RS_LT_00003)

8.1.2 LogMode

[SWS_LOG_00019]{DRAFT}

Kind:	enumeration		
Symbol:	LogMode		
Scope:	namespace ara::log		
Underlying type:	std::uint8_t		
Syntax:	enum class LogMode : std::uint8_t {};		
Values:	kRemote= 0x01 Send remotely.		
	kFile= 0x02	kFile= 0x02 Save to file.	
	kConsole= 0x04 Forward to console.		
Header file:	#include "ara/log/common.h"		
Description:	Log mode. Flags, used to configure the sink for log messages.		
Notes:	In order to combine flags, at least the OF	R and AND operators needs to be provided for this type.	

](RS_LT_00003)



8.1.3 Format specifier

$\textbf{[SWS_LOG_00206]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	enumeration	
Symbol:	Fmt	
Scope:	namespace ara::log	
Underlying type:	std::uint16_t	
Syntax:	enum class Fmt : std::uint16_	t {};
Values:	kDefault= 0	implementation-defined formatting
	kDec= 1	decimal (signed/unsigned)
	kOct= 2	octal
	kHex= 3	hexadecimal
	kBin= 4	binary
	kDecFloat= 5 decimal float (like printf "%f")	
	kEngFloat= 6 engineering float (like printf "%e")	
	kHexFloat= 7	hex float (like printf "%a")
	kAutoFloat= 8	automatic "shortest" float (like printf "%g")
Header file:	#include "ara/log/logger.h"	
Description:	Format specifiers for log message arguments .	

](RS_LT_00046)

$\textbf{[SWS_LOG_00207]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	struct	
Symbol:	Format	
Scope:	namespace ara::log	
Syntax:	struct Format final {};	
Header file:	#include "ara/log/logger.h"	
Description:	A type holding a formatting hint.	
	The interpretation of precision depends on fmt: For integral types (i.e. Fmt::kDec, Fmt::kOct, Fmt::kHex, Fmt::kBin), precision is interpreted as the minimum number of digits to output, similar to e.g. std::printf("%.7d"). For the floating-point specifiers Fmt::kDecFloat, Fmt::kEng Float and Fmt::kHexFloat, precision denotes the exact number of digits to be shown after the decimal point; for Fmt::kAutoFloat, precision denotes the number of significant digits to be shown according to the rules of the std::printf "%g" specifier. If fmt is Fmt::kDefault, the precision field is ignored, and an implementation-defined formatting is applied. For integral types, if @precision is 0, it is interpreted the same as if it was 1.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00225]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	variable
Symbol:	fmt
Scope:	struct ara::log::Format
Туре:	Fmt





 \triangle

Syntax:	Fmt fmt;
Header file:	#include "ara/log/logger.h"
Description:	the format specifier

](RS_LT_00046)

[SWS_LOG_00226]{DRAFT} [

Kind:	variable
Symbol:	precision
Scope:	struct ara::log::Format
Туре:	std::uint16_t
Syntax:	std::uint16_t precision;
Header file:	#include "ara/log/logger.h"
Description:	the precision to use

|(RS_LT_00046)

For convenience, there are helper functions to create specific instances of struct Format; these should generally be used instead of creating Format instances manually.

[SWS_LOG_00208]{DRAFT}

Kind:	function	
Symbol:	Dflt()	
Scope:	namespace ara::log	
Syntax:	constexpr Format Dflt () noexcept;	
Return value:	Format a Format instance	
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kDefa	ault formatting hint.

](RS_LT_00046)

[SWS_LOG_00211]{DRAFT}

Kind:	function	function	
Symbol:	Dec()		
Scope:	namespace ara::log	namespace ara::log	
Syntax:	constexpr Format Dec () noexce	constexpr Format Dec () noexcept;	
Return value:	Format	Format a Format instance	
Exception Safety:	noexcept	noexcept	
Header file:	#include "ara/log/logger.h"		
Description:	Create a Format instance with Fmt::kDe	Create a Format instance with Fmt::kDec formatting hint and default precision.	



](RS_LT_00046)

[SWS_LOG_00212]{DRAFT}

Kind:	function		
Symbol:	Dec(std::uint16_t precision)		
Scope:	namespace ara::log	namespace ara::log	
Syntax:	constexpr Format Dec (std::uint16_t precision) noexcept;		
Parameters (in):	precision	precision the precision to use	
Return value:	Format	Format a Format instance	
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Create a Format instance with Fmt::kDec formatting hint and given precision.		

](RS_LT_00046)

[SWS_LOG_00213]{DRAFT}

Kind:	function		
Symbol:	Oct()		
Scope:	namespace ara::log		
Syntax:	constexpr Format Oct () noexcept;		
Return value:	Format	Format a Format instance	
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Create a Format instance with Fmt::kOct	formatting hint and default precision.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00214]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	Oct(std::uint16_t precision)		
Scope:	namespace ara::log	namespace ara::log	
Syntax:	constexpr Format Oct (std::uin	constexpr Format Oct (std::uint16_t precision) noexcept;	
Parameters (in):	precision	precision the precision to use	
Return value:	Format	Format a Format instance	
Exception Safety:	noexcept	noexcept	
Header file:	#include "ara/log/logger.h"		
Description:	Create a Format instance with Fmt::kOct	Create a Format instance with Fmt::kOct formatting hint and given precision.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00209]} \{ \texttt{DRAFT} \} \; \lceil \;$



Kind:	function	
Symbol:	Hex()	
Scope:	namespace ara::log	
Syntax:	constexpr Format Hex () noexcept;	
Return value:	Format a Format instance	
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kHex formatting hint and default precision.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00210]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	Hex(std::uint16_t precision)	
Scope:	namespace ara::log	
Syntax:	constexpr Format Hex (std::uint16_t precision) noexcept;	
Parameters (in):	precision the precision to use	
Return value:	Format a Format instance	
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kHex formatting hint and given precision.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00215]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	Bin()	
Scope:	namespace ara::log	
Syntax:	constexpr Format Bin () noexcept;	
Return value:	Format a Format instance	
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kBin formatting hint and default precision.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00216]} \{ \texttt{DRAFT} \} \; \lceil \;$

Symbol: Bin(std::uint16_t precision) Scope: namespace ara::log Syntax: constexpr Format Bin (std::uint16_t precision) noexcept; Parameters (in): precision the precision to use	Kind:	function	
Syntax: constexpr Format Bin (std::uint16_t precision) noexcept;	Symbol:	Bin(std::uint16_t precision)	
	Scope:	namespace ara::log	
Parameters (in): precision the precision to use	Syntax:	constexpr Format Bin (std::uin	t16_t precision) noexcept;
	Parameters (in):	precision	the precision to use





\triangle

Return value:	Format	a Format instance
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kBin formatting hint and given precision.	

∫(RS_LT_00046)

[SWS_LOG_00217]{DRAFT}

Kind:	function	
Symbol:	DecFloat(std::uint16_t precision=6)	
Scope:	namespace ara::log	
Syntax:	constexpr Format DecFloat (std::uint16_t precision=6) noexcept;	
Parameters (in):	precision the precision to use	
Return value:	Format a Format instance	
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kDecFloat formatting hint and given precision.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00218]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	DecFloatMax()	
Scope:	namespace ara::log	
Syntax:	constexpr Format DecFloatMax () noexcept;	
Return value:	Format	a Format instance
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kDecFloat formatting hint and a precision that is sufficient for full round-trip safety.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00219]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	EngFloat(std::uint16_t precision=6)	
Scope:	namespace ara::log	
Syntax:	constexpr Format EngFloat (std::uint16_t precision=6) noexcept;	
Parameters (in):	precision	the precision to use
Return value:	Format a Format instance	
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	





Description:	Create a Format instance with Fmt::kEngFloat formatting hint and given precision.
--------------	---

](RS_LT_00046)

[SWS_LOG_00220]{DRAFT} [

Kind:	function	
Symbol:	EngFloatMax()	
Scope:	namespace ara::log	
Syntax:	constexpr Format EngFloatMax () noexcept;
Return value:	Format	a Format instance
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kEngFloat formatting hint and a precision that is sufficient for full round-trip safety.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00221]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	HexFloat(std::uint16_t precision)	
Scope:	namespace ara::log	
Syntax:	constexpr Format HexFloat (std::uint16_t precision) noexcept;	
Parameters (in):	precision	the precision to use
Return value:	Format	a Format instance
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kHexFloat formatting hint and given precision.	

](RS_LT_00046)

[SWS_LOG_00222]{DRAFT} [

Kind:	function	
Symbol:	HexFloatMax()	
Scope:	namespace ara::log	
Syntax:	constexpr Format HexFloatMax () noexcept;
Return value:	Format	a Format instance
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kHexFloat formatting hint and a precision that is sufficient for full round-trip safety.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00223]} \{ \texttt{DRAFT} \} \; \lceil \;$



Kind:	function	
Symbol:	AutoFloat(std::uint16_t precision=6)	
Scope:	namespace ara::log	
Syntax:	constexpr Format AutoFloat (std::uint16_t precision=6) noexcept;	
Parameters (in):	precision	the precision to use
Return value:	Format	a Format instance
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kAutoFloat formatting hint and given precision.	

](RS_LT_00046)

$\textbf{[SWS_LOG_00224]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	AutoFloatMax()	
Scope:	namespace ara::log	
Syntax:	constexpr Format AutoFloatMax	() noexcept;
Return value:	Format	a Format instance
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a Format instance with Fmt::kAuto for full round-trip safety.	oFloat formatting hint and a precision that is sufficient

](RS_LT_00046)

8.1.4 LogHex8

$\textbf{[SWS_LOG_00108]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	struct	
Symbol:	LogHex8	
Scope:	namespace ara::log	
Syntax:	struct LogHex8 {};	
Header file:	#include "ara/log/log_stream.h"	
Description:	Represents a 8 bit hexadecimal value data type .	
	Helper struct that is utilized as custom type. Holds an integer value that will be logged with a special format.	

](RS_LT_00003)

8.1.5 LogHex16

[SWS_LOG_00109]{DRAFT} [



Kind:	struct
Symbol:	LogHex16
Scope:	namespace ara::log
Syntax:	struct LogHex16 {};
Header file:	#include "ara/log/log_stream.h"
Description:	Represents a 16 bit hexadecimal value data type .

8.1.6 LogHex32

[SWS_LOG_00110]{DRAFT}

Kind:	struct
Symbol:	LogHex32
Scope:	namespace ara::log
Syntax:	struct LogHex32 {};
Header file:	#include "ara/log/log_stream.h"
Description:	Represents a 32 bit hexadecimal value data type .

](RS_LT_00003)

8.1.7 LogHex64

$\textbf{[SWS_LOG_00111]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	struct
Symbol:	LogHex64
Scope:	namespace ara::log
Syntax:	struct LogHex64 {};
Header file:	#include "ara/log/log_stream.h"
Description:	Represents a 64 bit hexadecimal value data type .

](RS_LT_00003)

8.1.8 **LogBin8**

[SWS_LOG_00112]{DRAFT}



Kind:	struct
Symbol:	LogBin8
Scope:	namespace ara::log
Syntax:	struct LogBin8 {};
Header file:	#include "ara/log/log_stream.h"
Description:	Represents a 8 bit binary data type .

8.1.9 LogBin16

[SWS_LOG_00113]{DRAFT}

Kind:	struct
Symbol:	LogBin16
Scope:	namespace ara::log
Syntax:	struct LogBin16 {};
Header file:	#include "ara/log/log_stream.h"
Description:	Represents a 16 bit binary data type .

](RS_LT_00003)

8.1.10 LogBin32

[SWS_LOG_00114]{DRAFT}

Kind:	struct
Symbol:	LogBin32
Scope:	namespace ara::log
Syntax:	struct LogBin32 {};
Header file:	#include "ara/log/log_stream.h"
Description:	Represents a 32 bit binary data type .

](RS_LT_00003)

8.1.11 LogBin64

 $\textbf{[SWS_LOG_00115]} \{ \texttt{DRAFT} \} \; \lceil \;$



Kind:	struct
Symbol:	LogBin64
Scope:	namespace ara::log
Syntax:	struct LogBin64 {};
Header file:	#include "ara/log/log_stream.h"
Description:	Represents a 64 bit binary data type .

8.1.12 ClientState

$\textbf{[SWS_LOG_00098]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	enumeration		
Symbol:	ClientState		
Scope:	namespace ara::log		
Underlying type:	std::int8_t	std::int8_t	
Syntax:	enum class ClientState : std::int8_t {};		
Values:	kUnknown= -1 –		
	kNotConnected –		
	kConnected –		
Header file:	#include "ara/log/common.h"		
Description:	Client state representing the connection state of an external client		

](RS_LT_00003)



8.2 Function definitions

8.2.1 CreateLogger

[SWS_LOG_00021]{DRAFT}

Kind:	function	function	
Symbol:	CreateLogger(ara::core::StringView ctxld, ara::core::StringView ctxDescription, LogLevel ctxDef LogLevel::kWarn)		
Scope:	namespace ara::log		
Syntax:		Logger& CreateLogger (ara::core::StringView ctxId, ara::core::String View ctxDescription, LogLevel ctxDefLogLevel=LogLevel::kWarn) noexcept;	
Parameters (in):	ctxld	The context ID.	
	ctxDescription	The description of the provided context ID.	
	ctxDefLogLevel	The default log level, set to Warning severity if not explicitly specified.	
Return value:	Logger &	Reference to the internal managed instance of a Logger object. Ownership stays within the Logging framework	
Exception Safety:	noexcept	noexcept	
Thread Safety:	reentrant		
Header file:	#include "ara/log/logger.h"		
Description:	Creates a Logger object, holding the context which is registered in the Logging framework.		

|(RS_LT_00003)

8.2.2 HexFormat (uint8)

$\textbf{[SWS_LOG_00022]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	HexFormat(std::uint8_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogHex8 HexFormat (s	td::uint8_t value) noexcept;
Parameters (in):	value Decimal number to be converted into hexadecimal number system.	
Return value:	LogHex8 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a uint8 into a hexadecimal value.	
	Negatives are represented in 2's complement. The number of represented digits depends on the overloaded parameter type length.	
Notes:	Logs decimal numbers in hexadecimal format.	

](RS_LT_00003)



8.2.3 HexFormat (int8)

[SWS_LOG_00023]{DRAFT}

Kind:	function	
Symbol:	HexFormat(std::int8_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogHex8 HexFormat (s	td::int8_t value) noexcept;
Parameters (in):	value Decimal number to be converted into hexadecimal number system.	
Return value:	LogHex8 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a int8 into a hexadecimal value.	
Notes:	Logs decimal numbers in hexadecimal fo	rmat. Negatives are represented in 2's complement.

|(RS_LT_00003)

8.2.4 HexFormat (uint16)

[SWS_LOG_00024]{DRAFT} [

Kind:	function	
Symbol:	HexFormat(std::uint16_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogHex16 HexFormat (std::uint16_t value) noexcept;
Parameters (in):	value Decimal number to be converted into hexadecimal number system.	
Return value:	LogHex16 LogHex16 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a uint16 into a hexadecimal value.	
Notes:	Logs decimal numbers in hexadecimal fo	rmat.

(RS_LT_00003)

8.2.5 HexFormat (int16)

[SWS_LOG_00025]{DRAFT}



Kind:	function		
Symbol:	HexFormat(std::int16_t value)		
Scope:	namespace ara::log		
Syntax:	constexpr LogHex16 HexFormat (std::int16_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into hexadecimal number system.		
Return value:	LogHex16	LogHex16 LogHex16 type that has a built-in stream handler.	
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/logger.h"		
Description:	Conversion of a int16 into a hexadecimal value.		
Notes:	Logs decimal numbers in hexadecimal fo	rmat. Negatives are represented in 2's complement.	

8.2.6 HexFormat (uint32)

[SWS_LOG_00026]{DRAFT}

Kind:	function	
Symbol:	HexFormat(std::uint32_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogHex32 HexFormat (std::uint32_t value) noexcept;
Parameters (in):	value Decimal number to be converted into hexadecimal number system.	
Return value:	LogHex32 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a uint32 into a hexadecimal value.	
Notes:	Logs decimal numbers in hexadecimal fo	rmat.

](RS_LT_00003)

8.2.7 HexFormat (int32)

[SWS_LOG_00027]{DRAFT}

Kind:	function	
Symbol:	HexFormat(std::int32_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogHex32 HexFormat (std::int32_t value) noexcept;	





Parameters (in):	value	Decimal number to be converted into hexadecimal number system.
Return value:	LogHex32	LogHex32 type that has a built-in stream handler.
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a int32 into a hexadecimal value.	
Notes:	Logs decimal numbers in hexadecimal format. Negatives are represented in 2's complement.	

](RS_LT_00003)

8.2.8 HexFormat (uint64)

$\textbf{[SWS_LOG_00028]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	HexFormat(std::uint64_t value)		
Scope:	namespace ara::log		
Syntax:	constexpr LogHex64 HexFormat (std::uint64_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into hexadecimal number system.		
Return value:	LogHex64	LogHex64 LogHex64 type that has a built-in stream handler.	
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/logger.h"		
Description:	Conversion of a uint64 into a hexadecimal value.		
Notes:	Logs decimal numbers in hexadecimal for	ormat.	

](RS_LT_00003)

8.2.9 HexFormat (int64)

[SWS_LOG_00029]{DRAFT} [

Kind:	function	
Symbol:	HexFormat(std::int64_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogHex64 HexFormat (std::int64_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into hexadecimal number system.	
Return value:	LogHex64	LogHex64 type that has a built-in stream handler.
Exception Safety:	noexcept	





Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a int64 into a hexadecimal value.	
Notes:	Logs decimal numbers in hexadecimal format. Negatives are represented in 2's complement.	

](RS_LT_00003)

8.2.10 BinFormat (uint8)

$\textbf{[SWS_LOG_00030]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	function	
Symbol:	BinFormat(std::uint8_t value)	BinFormat(std::uint8_t value)	
Scope:	namespace ara::log		
Syntax:	constexpr LogBin8 BinFormat (s	constexpr LogBin8 BinFormat (std::uint8_t value) noexcept;	
Parameters (in):	value	value Decimal number to be converted into a binary value.	
Return value:	LogBin8	LogBin8 LogBin8 type that has a built-in stream handler.	
Exception Safety:	noexcept	noexcept	
Thread Safety:	reentrant	reentrant	
Header file:	#include "ara/log/logger.h"	#include "ara/log/logger.h"	
Description:	Conversion of a uint8 into a binary value	Conversion of a uint8 into a binary value.	
Notes:	Logs decimal numbers in binary format.	Logs decimal numbers in binary format.	

](RS_LT_00003)

8.2.11 BinFormat (int8)

[SWS_LOG_00031]{DRAFT}

Kind:	function		
Symbol:	BinFormat(std::int8_t value)		
Scope:	namespace ara::log		
Syntax:	constexpr LogBin8 BinFormat (s	constexpr LogBin8 BinFormat (std::int8_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into a binary value.		
Return value:	LogBin8 LogBin8 type that has a built-in stream handler.		
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/logger.h"		
Description:	Conversion of a int8 into a binary value.		
Notes:	Logs decimal numbers in binary format. I	Negatives are represented in 2's complement.	

](RS_LT_00003)



8.2.12 BinFormat (uint16)

[SWS_LOG_00032]{DRAFT} [

Kind:	function	
Symbol:	BinFormat(std::uint16_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogBin16 BinFormat (std::uint16_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into a binary value.	
Return value:	LogBin16 LogBin8 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a uint16 into a binary value.	
Notes:	Logs decimal numbers in binary format.	

(RS_LT_00003)

8.2.13 **BinFormat (int16)**

[SWS_LOG_00033]{DRAFT}

Kind:	function	
Symbol:	BinFormat(std::int16_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogBin16 BinFormat (std::int16_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into a binary value.	
Return value:	LogBin16 LogBin8 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a int16 into a binary value.	
Notes:	Logs decimal numbers in binary format. I	Negatives are represented in 2's complement.

](RS_LT_00003)

8.2.14 BinFormat (uint32)

[SWS_LOG_00034]{DRAFT}

Kind:	function
Symbol:	BinFormat(std::uint32_t value)



Scope:	namespace ara::log	
Syntax:	constexpr LogBin32 BinFormat (std::uint32_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into a binary value.	
Return value:	LogBin32 LogBin8 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a uint32 into a binary value.	
Notes:	Logs decimal numbers in binary format.	

](RS_LT_00003)

8.2.15 BinFormat (int32)

[SWS_LOG_00035]{DRAFT}

Kind:	function	
Symbol:	BinFormat(std::int32_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogBin32 BinFormat (std::int32_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into a binary value.	
Return value:	LogBin32 LogBin8 type that has a built-in stream handler.	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/logger.h"	
Description:	Conversion of a int32 into a binary value.	
Notes:	Logs decimal numbers in binary format. I	Negatives are represented in 2's complement.

](RS_LT_00003)

8.2.16 BinFormat (uint64)

$\textbf{[SWS_LOG_00036]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	BinFormat(std::uint64_t value)	
Scope:	namespace ara::log	
Syntax:	constexpr LogBin64 BinFormat (std::uint64_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into a binary value.	
Return value:	LogBin64 LogBin8 type that has a built-in stream handler.	
Exception Safety:	noexcept	





Thread Safety:	reentrant
Header file:	#include "ara/log/logger.h"
Description:	Conversion of a uint64 into a binary value.
Notes:	Logs decimal numbers in binary format.

|(RS_LT_00003)

8.2.17 BinFormat (int64)

$\textbf{[SWS_LOG_00037]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	BinFormat(std::int64_t value)		
Scope:	namespace ara::log		
Syntax:	constexpr LogBin64 BinFormat (constexpr LogBin64 BinFormat (std::int64_t value) noexcept;	
Parameters (in):	value Decimal number to be converted into a binary value.		
Return value:	LogBin64 LogBin8 type that has a built-in stream handler.		
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/logger.h"		
Description:	Conversion of a int64 into a binary value.		
Notes:	Logs decimal numbers in binary format. I	Negatives are represented in 2's complement.	

](RS_LT_00003)

8.2.18 RegisterConnectionStateHandler

[SWS_LOG_00205]{DRAFT}

Kind:	function	function	
Symbol:	RegisterConnectionStateHandler(st	RegisterConnectionStateHandler(std::function< void(ClientState)> callback)	
Scope:	namespace ara::log	namespace ara::log	
Syntax:	void RegisterConnectionStat	<pre>void RegisterConnectionStateHandler (std::function< void(ClientState)> callback) noexcept;</pre>	
Parameters (in):	callback	callback a callback that is invoked whenever the connection state has changed	
Return value:	None	None	
Exception Safety:	noexcept	noexcept	
Header file:	#include "ara/log/logger.h"	#include "ara/log/logger.h"	
Description:	Register a callback to be invoked wh	Register a callback to be invoked whenever the connection state changes.	
		Only a single function can be installed this way; if a callback was already registered before, only the newly registered one is used henceforth.	



8.2.19 Wrapper object creator

[SWS_LOG_00201]{DRAFT}

Kind:	function	
Symbol:	Arg(T &&arg, const char *name=nullptr, const char *unit=nullptr, Format format=Dflt())	
Scope:	namespace ara::log	
Syntax:	<pre>template <typename t=""> Argument<t> Arg (T &&arg, const char *name=nullptr, const char *unit=nullptr, Format format=Dflt()) noexcept;</t></typename></pre>	
Parameters (in):	arg an argument payload object	
	name	an optional "name" attribute for arg
	unit an optional "unit" attribute for arg	
	format	an optional formatting hint for integral or floating-point arguments; the default is to use the implementation's standard formatting
Return value:	Argument< T >	a wrapper object holding the supplied arguments
Exception Safety:	noexcept	
Header file:	#include "ara/log/logger.h"	
Description:	Create a wrapper object for the given arguments.	
	Calling this function shall be ill-formed if any of these conditions are met: T is not an arithmetic type and not "bool" and not convertible to "ara::core::StringView" and not convertible to "ara::core::Span <const ara::core::byte="">" T is convertible to "ara::core::StringView" or convertible to "ara::core::Span<const ara::core::byte="">" or "bool", and "unit" is not "nullptr"</const></const>	

](RS_LT_00003)

8.2.20 Logger of an argument with attributes

[SWS_LOG_00203]{DRAFT}

Kind:	function	
Symbol:	operator<<(const Argument< T > &arg)	
Scope:	class ara::log::LogStream	
Syntax:	<pre>template <typename t=""> LogStream& operator<< (const Argument< T > &arg) noexcept;</typename></pre>	
Template param:	T the argument payload type	
Parameters (in):	arg	the argument wrapper object
Return value:	LogStream &	*this
Exception Safety:	noexcept	
Header file:	#include "ara/log/log_stream.h"	
Description:	Log an argument with attributes.	
	When output to the console, the value and	d all its attributes shall be shown as a single argument.

](RS_LT_00003)



8.2.21 Logger of modeled message

$\textbf{[SWS_LOG_00204]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	Log(const Msgld &id, const Params & args)		
Scope:	class ara::log::Logger	class ara::log::Logger	
Syntax:	template <typename msgid,="" params="" typename=""> void Log (const MsgId &id, const Params & args) noexcept;</typename>		
Template param:	Msgld	the type of the id parameter	
	Args the types of the args parameters		
Parameters (in):	id	an implementation-defined type identifying the message object	
	args	the arguments to add to the message	
Return value:	None		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Log a modeled message.		
	If this function is called with an argument list that does not match the modeled message, the program is ill-formed.		

](RS_LT_00003)



8.3 Class definitions

8.3.1 Class LogStream

The class ara::log::LogStream represents a Log message, allowing stream operators to be used for appending data.

[SWS_LOG_00173]{DRAFT}

Kind:	class
Symbol:	LogStream
Scope:	namespace ara::log
Syntax:	class LogStream final {};
Header file:	#include "ara/log/log_stream.h"
Description:	Class LogStream Initiates it with the given log level directly on the back-end

|(RS_LT_00003)

Note:

Normally Application processes would not use this class directly. Instead one of the log methods provided in the main Logging API shall be used. Those methods automatically setup a temporary object of this class with the given log severity level. The only reason to use this class directly is, if the user wants to hold a ara::log:-:LogStream object longer than the default one-statement scope. This is useful in order to create log messages that are distributed over multiple code lines. See the ara::log::LogStream::Flush method for further information. Once this temporary object gets out of scope, its destructor takes care that the message buffer is ready to be processed by the Logging framework.

8.3.1.1 Extending the Logging API to understand custom types

The ara::log::LogStream class supports natively the formats stated in chapter 8.2, it can be easily extended for other derived types by providing a stream operator that makes use of already supported types.

Example:

```
1 struct MyCustomType {
2    int8_t foo;
3    ara::core::String bar;
4 };
5
6 LogStream& operator<<(LogStream& out, const MyCustomType& value) {
7    return (out << value.foo << value.bar);
8 }
9
10 // Producing the output "42 the answer is."
11 Logger& ctx0 = CreateLogger("CTX0", "Context Description CTX0");</pre>
```



12 ctx0.LogDebug () << MyCustomType{42, " the answer is."};</pre>



8.3.1.2 LogStream::Flush

[SWS_LOG_00039]{DRAFT}

Kind:	function
Symbol:	Flush()
Scope:	class ara::log::LogStream
Syntax:	void Flush () noexcept;
Return value:	None
Exception Safety:	noexcept
Thread Safety:	reentrant
Header file:	#include "ara/log/log_stream.h"
Description:	Sends out the current log buffer and initiates a new message stream.

(RS_LT_00003)

Note:

Calling ara::log::LogStream::Flush is only necessary if the ara::log::-LogStream object is going to be re-used within the same scope. Otherwise, if the object goes out of scope (e.g. end of function block) then the flushing operation will be done internally by the destructor. It is important to note that the ara::log::-LogStream::Flush command does not empty the buffer, but it forwards the buffer's current contents to the Logging framework.

8.3.1.3 Built-in operators for natively supported types

[SWS_LOG_00040]{DRAFT}

Kind:	function	
Symbol:	operator<<(bool value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (bool value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Appends given value to the internal mess	sage buffer.

|(RS_LT_00003)

[SWS_LOG_00041]{DRAFT}



Kind:	function	
Symbol:	operator<<(std::uint8_t value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::uint8_t value) noexcept;	
Parameters (in):	Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int 8 bit parameter into n	nessage.

$\textbf{[SWS_LOG_00042]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(std::uint16_t value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::uint16_t value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int 16 bit parameter into	message.

](RS_LT_00003)

$\textbf{[SWS_LOG_00043]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(std::uint32_t value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::uint32_t value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int 32 bit parameter into	message.

](RS_LT_00003)

$\textbf{[SWS_LOG_00044]} \{ \texttt{DRAFT} \} \; \lceil \;$



Kind:	function	
Symbol:	operator<<(std::uint64_t value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::uint64_t value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int 64 bit parameter into	message.

$\textbf{[SWS_LOG_00045]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(std::int8_t value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::int8_t value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes signed int 8 bit parameter into me	ssage.

](RS_LT_00003)

$\textbf{[SWS_LOG_00046]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	function	
Symbol:	operator<<(std::int16_t value)	operator<<(std::int16_t value)	
Scope:	class ara::log::LogStream	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::in	LogStream& operator<< (std::int16_t value) noexcept;	
Parameters (in):	value	value Value to be appended to the internal message buffer.	
Return value:	LogStream &	LogStream & *this	
Exception Safety:	noexcept	noexcept	
Thread Safety:	reentrant		
Header file:	#include "ara/log/log_stream.h"		
Description:	Writes signed int 16 bit parameter into m	essage.	

](RS_LT_00003)

$\textbf{[SWS_LOG_00047]} \{ \texttt{DRAFT} \} \; \lceil \;$



Kind:	function	
Symbol:	operator<<(std::int32_t value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::int32_t value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes signed int 32 bit parameter into me	essage.

$\textbf{[SWS_LOG_00048]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(std::int64_t value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (std::int64_t value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes signed int 64 bit parameter into m	essage.

](RS_LT_00003)

$\textbf{[SWS_LOG_00049]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	operator<<(float value)		
Scope:	class ara::log::LogStream		
Syntax:	LogStream& operator<< (float value) noexcept;		
Parameters (in):	value Value to be appended to the internal message buffer.		
Return value:	LogStream &	*this	
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/log_stream.h"		
Description:	Writes float 32 bit parameter into messag	Writes float 32 bit parameter into message.	

](RS_LT_00003)

 $\textbf{[SWS_LOG_00050]} \{ \texttt{DRAFT} \} \; \lceil \;$



Kind:	function	
Symbol:	operator<<(double value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (double value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes float 64 bit parameter into messag	ge.

8.3.1.4 Built-in operators for conversion types

$\textbf{[SWS_LOG_00053]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	operator<<(const LogHex8 &value)		
Scope:	class ara::log::LogStream		
Syntax:	LogStream& operator<< (const LogHex8 &value) noexcept;		
Parameters (in):	value Value to be appended to the internal message buffer.		
Return value:	LogStream & *this		
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/log_stream.h"		
Description:	Writes unsigned int parameter into messa	Writes unsigned int parameter into message, formatted as hexadecimal 8 digits.	

](RS_LT_00003)

$\textbf{[SWS_LOG_00054]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(const LogHex16 &value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const LogHex16 &value) noexcept;	
Parameters (in):	value	Value to be appended to the internal message buffer.
Return value:	LogStream &	*this
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	





Description:	Writes unsigned int parameter into message, formatted as hexadecimal 16 digits.
--------------	---

](RS_LT_00003)

[SWS_LOG_00055]{DRAFT}

Kind:	function	
Symbol:	operator<<(const LogHex32 &value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const LogHex32 &value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int parameter into messa	age, formatted as hexadecimal 32 digits.

](RS_LT_00003)

[SWS_LOG_00056]{DRAFT}

Kind:	function	
Symbol:	operator<<(const LogHex64 &value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const LogHex64 &value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int parameter into message, formatted as hexadecimal 64 digits.	

](RS_LT_00003)

$\textbf{[SWS_LOG_00057]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	function	
Symbol:	operator<<(const LogBin8 &value)	operator<<(const LogBin8 &value)	
Scope:	class ara::log::LogStream	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const L	LogStream& operator<< (const LogBin8 &value) noexcept;	
Parameters (in):	value	value Value to be appended to the internal message buffer.	
Return value:	LogStream &	*this	
Exception Safety:	noexcept		





Thread Safety:	reentrant
Header file:	#include "ara/log/log_stream.h"
Description:	Writes unsigned int parameter into message, formatted as binary 8 digits.

](RS_LT_00003)

$\textbf{[SWS_LOG_00058]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	operator<<(const LogBin16 &value)		
Scope:	class ara::log::LogStream	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const LogBin16 &value) noexcept;		
Parameters (in):	value Value to be appended to the internal message buffer.		
Return value:	LogStream &	LogStream & *this	
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/log_stream.h"		
Description:	Writes unsigned int parameter into messa	age, formatted as binary 16 digits.	

](RS_LT_00003)

$\textbf{[SWS_LOG_00059]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(const LogBin32 &value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const LogBin32 &value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.	
Return value:	LogStream & *this	
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int parameter into messa	age, formatted as binary 32 digits.

](RS_LT_00003)

$\textbf{[SWS_LOG_00060]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(const LogBin64 &value)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const LogBin64 &value) noexcept;	
Parameters (in):	value	Value to be appended to the internal message buffer.





Return value:	LogStream &	*this
Exception Safety:	noexcept	
Thread Safety:	reentrant	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes unsigned int parameter into message, formatted as binary 64 digits.	

](RS_LT_00003)

8.3.1.5 Built-in operators for extra types

[SWS_LOG_00062]{DRAFT}

Kind:	function	function	
Symbol:	operator<<(const ara::core::StringView v	operator<<(const ara::core::StringView value)	
Scope:	class ara::log::LogStream	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const a	LogStream& operator<< (const ara::core::StringView value) noexcept;	
Parameters (in):	value	Value to be appended to the internal message buffer.	
Return value:	LogStream &	LogStream & *this	
Exception Safety:	noexcept	noexcept	
Thread Safety:	reentrant		
Header file:	#include "ara/log/log_stream.h"	#include "ara/log/log_stream.h"	
Description:	Writes ara::core::StringView into message	ge.	

](RS_LT_00003)

[SWS_LOG_00051]{DRAFT}

Kind:	function		
Symbol:	operator<<(const char *const value)		
Scope:	class ara::log::LogStream	class ara::log::LogStream	
Syntax:	LogStream& operator<< (const c	har *const value) noexcept;	
Parameters (in):	value Value to be appended to the internal message buffer.		
Return value:	LogStream &	LogStream & *this	
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/log_stream.h"		
Description:	Writes null terminated UTF8 string into m FUTURE!)	Writes null terminated UTF8 string into message. (NOT sPECIFIED. WILL BE REMOVED IN	

](RS_LT_00003)

 $\textbf{[SWS_LOG_00063]} \{ \texttt{DRAFT} \} \; \lceil \;$



Kind:	function		
Symbol:	operator<<(LogStream &out, LogLevel value)		
Scope:	namespace ara::log		
Syntax:	LogStream& operator<< (LogStre	LogStream& operator<< (LogStream &out, LogLevel value) noexcept;	
Parameters (in):	out	LogStream Object which is used to append the logged LogLevel (value) to	
	value	LogLevel enum parameter as text to be appended to the internal message buffer.	
Return value:	LogStream &	*this	
Exception Safety:	noexcept		
Thread Safety:	reentrant		
Header file:	#include "ara/log/log_stream.h"		
Description:	Appends LogLevel enum parameter as te	ext into message.	

$\textbf{[SWS_LOG_00124]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	function	
Symbol:	operator<<(LogStream &out, const core::ErrorCode &ec)		
Scope:	namespace ara::log		
Syntax:	LogStream& operator<< (LogStream &out, const core::ErrorCode &ec) noexcept;		
Parameters (in):	out the LogStream object into which to add the value		
	ec	the ErrorCode instance to log	
Return value:	LogStream &	LogStream & out	
Exception Safety:	noexcept		
Header file:	#include "ara/log/log_stream.h"		
Description:	Write a core::ErrorCode instance into the message.		
	When output to the console, the ErrorCode shall be shown in an implementation-defined way as a String holding the result of ErrorCode:Domain().Name() (i.e. the ErrorDomain's Shortname), and the integral error code number.		

](RS_LT_00003)

$\textbf{[SWS_LOG_00125]} \{ \mathsf{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(LogStream &out, const std::chrono::duration< Rep, Period > &value)	
Scope:	namespace ara::log	
Syntax:	<pre>template <typename period="" rep,="" typename=""> LogStream& operator<< (LogStream &out, const std::chrono::duration</typename></pre> Rep, Period > &value) noexcept;	
Template param:	Rep arithmetic type representing the number of ticks in this duration	
	Period	a std::ratio type representing the tick period of the clock, in seconds
Parameters (in):	out	the LogStream object into which to add the value





	value	the duration instance to log
Return value:	LogStream &	out
Exception Safety:	noexcept	
Header file:	#include "ara/log/log_stream.h"	
Description:	Write a std::chrono::duration instance into the message.	
	When output to the console, the duration shall be shown as a decimal integer value, together with the duration's unit in SI notation, for at least all units in [std::nano, std::micro, std::milli, std::centi, std::deci, std::ratio<1>].	

](RS_LT_00049)

$\textbf{[SWS_LOG_00126]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(LogStream &out, const ara::core::InstanceSpecifier &value)	
Scope:	namespace ara::log	
Syntax:	LogStream& operator<< (LogStream &out, const ara::core::Instance Specifier &value) noexcept;	
Parameters (in):	out the LogStream object into which to add the value	
	value	the InstanceSpecifier to log
Return value:	LogStream &	out
Exception Safety:	noexcept	
Header file:	#include "ara/log/log_stream.h"	
Description:	Write a core::InstanceSpecifier into the message.	
	The InstanceSpecifier shall be shown as	the result of calling InstanceSpecifier::ToString.

](RS_LT_00049)

$\textbf{[SWS_LOG_00127]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function	
Symbol:	operator<<(LogStream &out, const void *const value)	
Scope:	namespace ara::log	
Syntax:	LogStream & operator<< (LogStream &out, const void *const value) noexcept;	
Parameters (in):	out	the LogStream object into which to add the value
	value	to log
Return value:	LogStream & out	
Exception Safety:	noexcept	
Header file:	#include "ara/log/log_stream.h"	
Description:	Writes pointer address into message, formatted as hexadecimal.	

](RS_LT_00049)

[SWS_LOG_00128]{DRAFT} [



Kind:	function	
Symbol:	operator<<(core::Span< const core::Byte > data)	
Scope:	class ara::log::LogStream	
Syntax:	LogStream& operator<< (core::Span< const core::Byte > data) noexcept;	
Parameters (in):	data a Span <const byte=""> covering the range to be logged</const>	
Return value:	LogStream &	*this
Exception Safety:	noexcept	
Header file:	#include "ara/log/log_stream.h"	
Description:	Write a byte sequence into message.	
	This call shall copy the sequence of core::Byte objects as-is into the message.	
	When output to the console, this byte sec apostrophe-separated list of hexadecima	quence shall be shown as a sequence of I octet-pairs, for instance: "48'65'6c'6c'6f"

$\textbf{[SWS_LOG_00129]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function			
Symbol:	WithLocation(core::StringView file, int lir	WithLocation(core::StringView file, int line)		
Scope:	class ara::log::LogStream			
Syntax:	LogStream& WithLocation (core	LogStream& WithLocation (core::StringView file, int line) noexcept;		
Parameters (in):	file	file the source file identifier		
	line	line the source file line number		
Return value:	LogStream &	LogStream & *this		
Exception Safety:	noexcept	noexcept		
Header file:	#include "ara/log/log_stream.h"	#include "ara/log/log_stream.h"		
Description:	Add source file location into the message.			
	This function has no effect if another me message has already been called.	This function has no effect if another member function that adds content to the current message has already been called.		

](RS_LT_00003)



8.3.2 Class Logger

The class Logger represents a logger context. The Logging framework defines contexts which can be seen as logger instances within one Application process or process scope.

The contexts have the following properties:

- 1) Context ID
- 2) Description of the Context ID
- 3) Default log level

A context will be automatically registered against the Logging back-end during creation phase, as well as automatically deregistered during process shutdown phase. So the end user does not care for the objects life time. To ensure such housekeeping functionality, a strong ownership of the logger instances needs to be ensured towards the Logging framework. This means that the Application process are not supposed to call the Logger constructor themselves.

The user is not allowed to create a Logger object by himself. Logger context needs to be created by the provided API call CreateLogger().

8.3.2.1 Logger::LogFatal

[SWS_LOG_00064]{DRAFT}

Kind:	function		
Symbol:	LogFatal()		
Scope:	class ara::log::Logger		
Syntax:	LogStream LogFatal () const noexcept;		
Return value:	LogStream object of Fatal severity.		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Creates a LogStream object.		
	Returned object will accept arguments via the insert stream operator "@c <<".		
Notes:	In the normal usage scenario, the object's life time of the created LogStream is scoped within one statement (ends with ; after last passed argument). If one wants to extend the LogStream object's life time, the object might be assigned to a named variable.		

(RS_LT_00003)

8.3.2.2 Logger::LogError

[SWS_LOG_00065]{DRAFT}



Kind:	function		
Symbol:	LogError()		
Scope:	class ara::log::Logger		
Syntax:	LogStream LogError () const noexcept;		
Return value:	LogStream object of Error severity.		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Same as Logger::LogFatal().		

8.3.2.3 Logger::LogWarn

$\textbf{[SWS_LOG_00066]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	LogWarn()		
Scope:	class ara::log::Logger		
Syntax:	LogStream LogWarn () const noexcept;		
Return value:	LogStream object of Warn severity.		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Same as Logger::LogFatal().		

](RS_LT_00003)

8.3.2.4 Logger::LogInfo

$\textbf{[SWS_LOG_00067]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	LogInfo()		
Scope:	class ara::log::Logger		
Syntax:	LogStream LogInfo () const noexcept;		
Return value:	LogStream object of Info severity.		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Same as Logger::LogFatal().		

](RS_LT_00003)



8.3.2.5 Logger::LogDebug

$\textbf{[SWS_LOG_00068]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function			
Symbol:	LogDebug()	LogDebug()		
Scope:	class ara::log::Logger			
Syntax:	LogStream LogDebug () const noexcept;			
Return value:	LogStream	LogStream		
Exception Safety:	noexcept			
Header file:	#include "ara/log/logger.h"			
Description:	Same as Logger::LogFatal().			

](RS_LT_00003)

8.3.2.6 Logger::LogVerbose

[SWS_LOG_00069]{DRAFT}

Kind:	function		
Symbol:	LogVerbose()	LogVerbose()	
Scope:	class ara::log::Logger		
Syntax:	LogStream LogVerbose () const noexcept;		
Return value:	LogStream object of Verbose severity.		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Same as Logger::LogFatal().		

](RS_LT_00003)

8.3.2.7 Logger::IsEnabled

$\textbf{[SWS_LOG_00070]} \{ \texttt{DRAFT} \} \; \lceil \;$

Kind:	function		
Symbol:	IsEnabled(LogLevel logLevel)		
Scope:	class ara::log::Logger		
Syntax:	bool IsEnabled (LogLevel logLevel) const noexcept;		
Parameters (in):	logLevel The to be checked log level.		
Return value:	bool True if desired log level satisfies the configured reporting level.		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		





Description:	Check current configured log reporting level.
	Applications may want to check the actual configured reporting log level of certain loggers before doing log data preparation that is runtime intensive.

](RS_LT_00003)

8.3.2.8 Logger::WithLevel

[SWS_LOG_00131]{DRAFT}

Kind:	function		
Symbol:	WithLevel(LogLevel logLevel)		
Scope:	class ara::log::Logger		
Syntax:	LogStream WithLevel (LogLevel logLevel) const noexcept;		
Parameters (in):	logLevel the log level to use for this LogStream instance		
Return value:	LogStream a new LogStream instance with the given log level		
Exception Safety:	noexcept		
Header file:	#include "ara/log/logger.h"		
Description:	Log message with a programmatically determined log level can be written.		

|(RS_LT_00003)



A Mentioned Manifest Elements

For the sake of completeness, this chapter contains a set of class tables representing meta-classes mentioned in the context of this document.

Class	DltApplication				
Package	M2::AUTOSARTemplates:	M2::AUTOSARTemplates::LogAndTraceExtract			
Note	This meta-class represent	s the app	lication fro	om which the log and trace message originates.	
Base	ARObject, Identifiable, Mi	ultilanguag	geReferra	ble, Referrable	
Attribute	Туре	Type Mult. Kind Note			
application Description	String	01	attr	This attribute can be used to describe the applicationId that is used in the log and trace message in more detail.	
applicationId	String	01	attr	This attribute identifies the SW-C/BSW module in the log and trace message.	
context	DitContext	*	ref	Definition of ContextIds for the Application. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=context.dltContext, context.variation Point.shortLabel vh.latestBindingTime=systemDesignTime	

Table A.1: DltApplication

Class	DitArgument					
Package	M2::AUTOSARTemplates	::LogAndT	raceExtra	ct		
Note	This element defines an A	Argument i	in a DltMe	essage.		
Base	ARObject, Identifiable, M	lultilangua	geReferra	ble, Referrable		
Attribute	Туре	Mult.	Kind	Note		
dltArgument Entry	DltArgument	*	aggr	This aggregation is used to describe subElements of a Dlt Argument that defines a Structure.		
length	PositiveInteger	01	attr	Describes the DltArgument length in case of Arrays and Strings in number of BaseTypes.		
network Representation	SwDataDefProps	01	aggr	Definition of the networkRepresentation of the Dlt Argument.		
optional	Boolean	01	attr	This attribute defines whether the argument is optional or not. If set to True, the argument can be omitted from the payload of a DLT message.		
predefinedText	Boolean	01	attr	This attribute defines whether the DltArgument is a predefinedText (Static Data).		
variableLength	Boolean	01	attr	This attribute defines whether the length of the Dlt Argument is variable (determined at runtime) or not.		

Table A.2: DltArgument

Class	DitContext
Package	M2::AUTOSARTemplates::LogAndTraceExtract
Note	This meta-class represents the Context that groups Log and Trace Messages that are generated by an application.
	Tags:atp.recommendedPackage=DltContexts





Class	DItContext	DltContext					
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable						
Attribute	Туре	Mult.	Kind	Note			
context Description	String	01	attr	This attribute can be used to describe the contextld that is used in the log and trace message in more detail.			
contextId	String	01	attr	This attribute is used to group log and trace messages produced by an application to distinguish functionality.			
dltMessage	DltMessage	*	ref	Group of Log and Trace Messages assigned to the Dlt Context			
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=dltMessage.dltMessage, dlt Message.variationPoint.shortLabel vh.latestBindingTime=systemDesignTime			

Table A.3: DItContext

Class	DitEcu	DitEcu					
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::LogAndTraceExtract					
Note	This element represents a	This element represents an Ecu or Machine that produces logging and tracing information.					
	Tags:atp.recommendedP	Tags:atp.recommendedPackage=DltEcus					
Base	ARElement, ARObject, C Element, Referrable	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable					
Attribute	Туре	Mult.	Kind	Note			
application	DltApplication	*	aggr	Application on DItEcu that provides log or trace data.			
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=application.shortName, application.variation Point.shortLabel vh.latestBindingTime=systemDesignTime			
eculd	String	01	attr	This attribute defines the name of the ECU for use within the Dlt protocol.			

Table A.4: DItEcu

Class	DltLogSink					
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::LogAndTrace					
Note	The meta-class defines th	The meta-class defines the output sink for DltLogMessages				
	Tags: atp.Status=draft atp.recommendedPackage=DltLogSinks					
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable, UploadablePackageElement					
Attribute	Туре	Type Mult. Kind Note				
bufferOutput	Boolean	01	attr	This attribute defines whether a buffer is used in case that the output sink is the console.		
				Tags:atp.Status=draft		
defaultLog Threshold	LogTraceDefaultLog LevelEnum	01	attr	This attribute allows to set a log level Threshold for Log Level filtering.		
				Tags:atp.Status=draft		





Class	DltLogSink			
defaultTrace	Boolean	01	attr	This attributes defines the default trace status.
State				Tags:atp.Status=draft
endpoint Configuration	PlatformModule EthernetEndpoint	01	ref	Network configuration (Protocol, Port, IP Address) for transmission of dlt messages on a specific VLAN.
	Configuration			Tags:atp.Status=draft
logChannelld	String	01	attr	This attribute identifies the LogChannel for usage within the Log And Trace protocol.
				Tags:atp.Status=draft
nonVerbose Mode	Boolean	01	attr	This attribute defines whether this DltLogSink supports non-Verbose Dlt messages. If disabled only verbose mode messages shall be used.
				Tags:atp.Status=draft
path	UriString	01	attr	This attribute defines the path to the file that is used as output sink.
				Tags:atp.Status=draft
queueSize	PositiveInteger	01	attr	Length of the queue (in which messages can be stored before processing) in the unit "Log message".
				Tags:atp.Status=draft

Table A.5: DltLogSink

Class	DltLogSinkToPortProto	typeMapp	ing			
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::LogAndTrace					
Note	This meta-class maps a PortPrototype to an output sink of a log and trace message.					
	Tags: atp.Status=draft atp.recommendedPackage=DltLogSinkToPortPrototypeMappings					
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable, UploadablePackageElement					
Attribute	Туре	Mult.	Kind	Note		
dltContext	DltContext	01	ref	Assignement of the DltContext that groups log and trace messages that will be transmitted to the DltLogSink.		
				Tags:atp.Status=draft		
dltLogSink	DltLogSink	*	ref	Reference to the output sink to which the log or trace message will be transmitted,		
				Tags:atp.Status=draft		
dltSessionId	PositiveInteger	01	attr	This attribute allows distinguishing log/trace messages from different instances of the same SW-C.		
				Tags:atp.Status=draft		
pPortPrototype	PPortPrototype	01	iref	Reference to PPortPrototype that is mapped to the DltLog Sink.		
				Tags:atp.Status=draft InstanceRef implemented by:PPortPrototypeIn ExecutableInstanceRef		
process	Process	01	ref	This reference represents the process required as context for the mapping.		
				Tags:atp.Status=draft		





Class	DltLogSinkToPortPrototypeMapping			
rPortPrototype	RPortPrototype	01	iref	Reference to RPortPrototype that is mapped to a DltLog Sink
				Tags:atp.Status=draft InstanceRef implemented by:RPortPrototypeIn ExecutableInstanceRef

Table A.6: DltLogSinkToPortPrototypeMapping

Class	DltMessage						
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::LogAndTraceExtract					
Note	This element defines a DI	tMessage.					
Base	ARObject, Identifiable, M.	ultilanguag	geReferra	ble, Referrable			
Attribute	Туре	Mult. Kind Note					
dltArgument (ordered)	DltArgument	*	aggr	Ordered collection of DltArguments in the DltMessage.			
messageld	PositiveInteger	01	attr	This attribute defines the unique Id for the DltMessage.			
messageLine Number	PositiveInteger	01	attr	This attribute describes the position in the source file in which this log message was called.			
messageSource File	String	01	attr	This attribute describes the source file in which this log message was called.			
messageType Info	String	01	attr	This attribute describes the message Type			

Table A.7: DltMessage

Class	Executable					
Package	M2::AUTOSARTemplates::AdaptivePlatform::ApplicationDesign::ApplicationStructure					
Note	This meta-class represents an executable program.					
	Tags: atp.Status=draft atp.recommendedPackage=Executables					
Base	ARElement, ARObject, AtpClassifier, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable					
Attribute	Туре	Mult.	Kind	Note		
buildType	BuildTypeEnum	01	attr	This attribute describes the buildType of a module and/or platform implementation.		
				Tags:atp.Status=draft		
loggingBehavior	LoggingBehaviorEnum	01	attr	This attribute indicates the intended logging behavior of the enclosing Executable.		
				Tags:atp.Status=draft		
minimumTimer Granularity	TimeValue	01	attr	This attribute describes the minimum timer resolution (TimeValue of one tick) that is required by the Executable.		
				Tags:atp.Status=draft		
reporting Behavior	ExecutionState ReportingBehavior	01	attr	this attribute controls the execution state reporting behavior of the enclosing Executable.		
	Enum			Tags:atp.Status=draft		



Class	Executable			
rootSw Component Prototype	RootSwComponent Prototype	01	aggr	This represents the root SwCompositionPrototype of the Executable. This aggregation is required (in contrast to a direct reference of a SwComponentType) in order to support the definition of instanceRefs in Executable context.
				Tags:atp.Status=draft
version	outsigned and the second secon	01	attr	Version of the executable.
	String			Tags:atp.Status=draft

Table A.8: Executable

Class	Identifiable (abstract)
Package	M2::AUTOSARTemplates::GenericStructure::GeneralTemplateClasses::Identifiable
Note	Instances of this class can be referred to by their identifier (within the namespace borders). In addition to this, Identifiables are objects which contribute significantly to the overall structure of an AUTOSAR description. In particular, Identifiables might contain Identifiables.
Base	ARObject, MultilanguageReferrable, Referrable





Class	Identifiable (abstract)					
Subclasses	ARPackage, AbstractDolpLogicAddressProps, AbstractEvent, AbstractIsericantionDataTypeEleme AbstractSecurityEventFilter, AbstractSecurityIdsmInstanceFilter, AbstractServiceInstance, Abstract SignalBasedTolSignalTriggeringMapping, AdaptiveModuleInstantiation, AdaptiveSwcInternalBehavior, ApApplicationEndpoint, ApplicationEndpoint, ApplicationError, ArtifactChecksum, AtpBlueprint, Atp Blueprintable, AtpClassifier, AlpFeature, AutosarOperationArgumentInstance, AutosarVariableInstance BuildActionEntity, BuildActionEnvironment, Chapter, CheckpointTransition, ClassContentConditional, ClientIdDefinition, ClientServerOperation, Code, CollectableElement, ComManagementMapping, Com ConnectorPort, CommunicationConnector, CommunicationController, Compiler, ConsistencyNeeds, ConsumedEventGroup, CouplingPort, CouplingPortStructuralElement, CryptoCertificate, CryptoKeySic CryptoProvider, CryptoServiceMapping, DataPrototypeGroup, DataTransformation, DdsDomainRange DependencyOnArtifact, DeterministicClientResourceNeeds, DiagEventDebounceAlgorithm, Diagnostic ConnectedIndicator, DiagnosticDataElement, DiagnosticDebounceAlgorithmProps, DiagnosticFunction InhibitSource, DiagnosticRoutineSubfunction, DitApplication, DitArgument, DitMessage, DolpInterface, DolpLogicAddress, DolpRoutingActivation, E2EProfileConfiguration, End2EndEventProtectionProps, End2EndMethodProtectionProps, EndToEndProtection, EthernetWakeupSleepOnDatalineConfig, Even Handler, EventMapping, ExclusiveArea, ExecutableEntity, ExecutionTime, FMAttributeDef, FMFeature Restriction, FMFeatureSelection, FieldMapping, FireAndForgetMapping, FlexrayArTpNode, FlexrayTp PduPool, FrameTriggering, GeneralParameter, GlobalSupervision, GlobalTimeGateway, GlobalTime Master, GlobalTimeSlave, HealthChannel, HeapUsage, HwAttributeDef, HwAttributeDef, HwPin, HwPinGroup, IPSecRule, IPv6ExtHeaderFilterList, ISignalTolPduMapping, ISignalTriggering, Ident Caption, InternalTriggeringPoint, Keyword, LifeCycleState, Linker, MacMulticastGroup, McDataInstance MemorySection, MethodMapping, Mode					
	SecureCommunication/ FreshnessProps, Secur ServiceInterfaceElemer TranslationEventProps, EventGroup, SomeipPro StaticSocketConnection Condition, SwGenericA SystemMemoryUsage, TimingExtensionResour JobMapping, Topic1, Tp TransformationTechnology	Authenticatic ityEventCon itSecureCor SignalServi ovidedEvent , Structured , Structured TimeBaseR ce, TimingN Address, Triggr,	onProps, SontextProps mConfig, aceTranslat Group, Sonte Begource, SwSentes Modelnstat aceable Taturn Description	dgClass, SecOcJobMapping, SecOcJobRequirement, SecureCommunicationDeployment, SecureCommunication is, ServiceEventDeployment, ServiceFieldDeployment, ServiceMethodDeployment, ServiceNeeds, SignalService tionProps, SocketAddress, SoftwarePackageStep, Someip omeipTpChannel, SpecElementReference, StackUsage, ervisionCheckpoint, SupervisionMode, SupervisionMode rviceArg, SwcServiceDependency, SystemMapping, TimingCondition, TimingConstraint, TimingDescription, nce, TIsCryptoCipherSuiteProps, TIs able, TraceableText, TracedFailure, TransformationProps, cription, UcmStep, VariableAccess, VariationPointProxy,		
Attribute	SecureCommunication/ FreshnessProps, Secur ServiceInterfaceElemer TranslationEventProps, EventGroup, SomeipPro StaticSocketConnection Condition, SwGenericA SystemMemoryUsage, TimingExtensionResoul JobMapping, Topic1, Tp	Authenticatic ityEventCon itSecureCor SignalServi ovidedEvent , Structured , Structured TimeBaseR ce, TimingN Address, Triggr,	onProps, SontextProps mConfig, aceTranslat Group, Sonte Begource, SwSentes Modelnstat aceable Taturn Description	dgClass, SecOcJobMapping, SecOcJobRequirement, SecureCommunicationDeployment, SecureCommunication is, ServiceEventDeployment, ServiceFieldDeployment, ServiceMethodDeployment, ServiceNeeds, SignalService tionProps, SocketAddress, SoftwarePackageStep, Someip omeipTpChannel, SpecElementReference, StackUsage, ervisionCheckpoint, SupervisionMode, SupervisionMode rviceArg, SwcServiceDependency, SystemMapping, TimingCondition, TimingConstraint, TimingDescription, nce, TIsCryptoCipherSuiteProps, TIs able, TraceableText, TracedFailure, TransformationProps, cription, UcmStep, VariableAccess, VariationPointProxy,		
Attribute adminData	SecureCommunication/ FreshnessProps, Secur ServiceInterfaceElemer TranslationEventProps, EventGroup, SomeipPro StaticSocketConnection Condition, SwGenericA SystemMemoryUsage, TimingExtensionResour JobMapping, Topic1, Tp TransformationTechnolov	Authenticatic ityEventCor ityEventCor SignalServi ovidedEvent , Structurec kisParamTy TimeBaseR rce, TimingN Address, Tr gy, Trigger, wMap, Vlan	onProps, SontextProps mConfig, aceTranslati Group, SontextProps iBreq, Suppoe, SwSentes desource, ModeInstati aceableTati Uconfig, W	dgClass, SecOcJobMapping, SecOcJobRequirement, SecureCommunicationDeployment, SecureCommunication s, ServiceEventDeployment, ServiceFieldDeployment, ServiceMethodDeployment, ServiceNeeds, SignalService tionProps, SocketAddress, SoftwarePackageStep, Someip omeipTpChannel, SpecElementReference, StackUsage, ervisionCheckpoint, SupervisionMode, SupervisionMode rviceArg, SwcServiceDependency, SystemMapping, TimingCondition, TimingConstraint, TimingDescription, nce, TlsCryptoCipherSuite, TlsCryptoCipherSuiteProps, Tls able, TraceableText, TracedFailure, TransformationProps, cription, UcmStep, VariableAccess, VariationPointProxy, laitPoint		
	SecureCommunication/ FreshnessProps, Secur ServiceInterfaceElemer TranslationEventProps, EventGroup, SomeipPro StaticSocketConnection Condition, SwGenericA SystemMemoryUsage, TimingExtensionResout JobMapping, Topic1, Tp TransformationTechnolovehicleRolloutStep, Vienderson	Authenticatic tityEventCor tityEventCor SignalServi byidedEvent , Structured xisParamTyp TimeBaseR TimegN Address, Tr gy, Trigger, wMap, Vlan Mult.	onProps, SontextProps mConfig, GeeTransla Group, SontextProps place (Group, SontextProps) place (Group, SontextProps) place (Group, SontextProps) place (Group, SontextProps) place (Group) place (Gro	dgClass, SecOcJobMapping, SecOcJobRequirement, SecureCommunicationDeployment, SecureCommunication is, ServiceEventDeployment, ServiceFieldDeployment, ServiceMethodDeployment, ServiceNeeds, SignalService tionProps, SocketAddress, SoftwarePackageStep, Someip omeipTpChannel, SpecElementReference, StackUsage, ervisionCheckpoint, SupervisionMode, SupervisionMode rviceArg, SwcServiceDependency, SystemMapping, TimingCondition, TimingConstraint, TimingDescription, nce, TlsCryptoCipherSuite, TlsCryptoCipherSuiteProps, Tlsable, TraceableText, TracedFailure, TransformationProps, cription, UcmStep, VariableAccess, VariationPointProxy, laitPoint Note This represents the administrative data for the identifiable		
	SecureCommunication/ FreshnessProps, Secur ServiceInterfaceElemer TranslationEventProps, EventGroup, SomeipPro StaticSocketConnection Condition, SwGenericA SystemMemoryUsage, TimingExtensionResout JobMapping, Topic1, Tp TransformationTechnolovehicleRolloutStep, Vienderson	Authenticatic tityEventCor tityEventCor SignalServi byidedEvent , Structured xisParamTyp TimeBaseR TimegN Address, Tr gy, Trigger, wMap, Vlan Mult.	onProps, SontextProps mConfig, GeeTransla Group, SontextProps place (Group, SontextProps) place (Group, SontextProps) place (Group, SontextProps) place (Group, SontextProps) place (Group) place (Gro	dgClass, SecOcJobMapping, SecOcJobRequirement, SecureCommunicationDeployment, SecureCommunication is, ServiceEventDeployment, ServiceFieldDeployment, ServiceMethodDeployment, ServiceNeeds, SignalService tionProps, SocketAddress, SoftwarePackageStep, Someip omeipTpChannel, SpecElementReference, StackUsage, ervisionCheckpoint, SupervisionMode, SupervisionMode rviceArg, SwcServiceDependency, SystemMapping, TimingCondition, TimingConstraint, TimingDescription, nce, TlsCryptoCipherSuite, TlsCryptoCipherSuiteProps, Tlsable, TraceableText, TracedFailure, TransformationProps, cription, UcmStep, VariableAccess, VariationPointProxy, aitPoint Note This represents the administrative data for the identifiable object. Stereotypes: atpSplitable Tags: atp.Splitkey=adminData		
adminData	SecureCommunication/ FreshnessProps, Secur ServiceInterfaceElemer TranslationEventProps, EventGroup, SomeipPro StaticSocketConnection Condition, SwGenericA SystemMemoryUsage, TimingExtensionResoul JobMapping, Topic1, Tp TransformationTechnolo VehicleRolloutStep, Vie Type AdminData	Authenticatic ityEventCor ityEventCor ityEventCor ityEventCor ityEventCor ityPirent it	onProps, SontextProps mConfig, GeeTransla Group, SontextProps ideroup, SontextProps identification id	dgClass, SecOcJobMapping, SecOcJobRequirement, SecureCommunicationDeployment, SecureCommunication s, ServiceEventDeployment, ServiceFieldDeployment, ServiceMethodDeployment, ServiceNeeds, SignalService tionProps, SocketAddress, SoftwarePackageStep, Someip omeipTpChannel, SpecElementReference, StackUsage, ervisionCheckpoint, SupervisionMode, SupervisionMode rviceArg, SwcServiceDependency, SystemMapping, TimingCondition, TimingConstraint, TimingDescription, nce, TlsCryptoCipherSuite, TlsCryptoCipherSuiteProps, Tlsable, TraceableText, TracedFailure, TransformationProps, cription, UcmStep, VariableAccess, VariationPointProxy, laitPoint Note This represents the administrative data for the identifiable object. Stereotypes: atpSplitable Tags: atp.Splitkey=adminData xml.sequenceOffset=-40 Possibility to provide additional notes while defining a model element (e.g. the ECU Configuration Parameter Values). These are not intended as documentation but		
adminData	SecureCommunication/ FreshnessProps, Secur ServiceInterfaceElemer TranslationEventProps, EventGroup, SomeipPro StaticSocketConnection Condition, SwGenericA SystemMemoryUsage, TimingExtensionResoul JobMapping, Topic1, Tp TransformationTechnolo VehicleRolloutStep, Vie Type AdminData	Authenticatic ityEventCor ityEventCor ityEventCor ityEventCor ityEventCor ityPirent it	onProps, SontextProps mConfig, GeeTransla Group, SontextProps ideroup, SontextProps identification id	dgClass, SecOcJobMapping, SecOcJobRequirement, SecureCommunicationDeployment, SecureCommunication s, ServiceEventDeployment, ServiceFieldDeployment, ServiceMethodDeployment, ServiceNeeds, SignalService tionProps, SocketAddress, SoftwarePackageStep, Someip omeipTpChannel, SpecElementReference, StackUsage, tervisionCheckpoint, SupervisionMode, SupervisionMode rviceArg, SwcServiceDependency, SystemMapping, TimingCondition, TimingConstraint, TimingDescription, nce, TlsCryptoCipherSuite, TlsCryptoCipherSuiteProps, Tlsable, TraceableText, TracedFailure, TransformationProps, cription, UcmStep, VariableAccess, VariationPointProxy, laitPoint Note		

 ∇



Class	Identifiable (abstract)			
desc	MultiLanguageOverview Paragraph	01	aggr	This represents a general but brief (one paragraph) description what the object in question is about. It is only one paragraph! Desc is intended to be collected into overview tables. This property helps a human reader to identify the object in question.
				More elaborate documentation, (in particular how the object is built or used) should go to "introduction".
				Tags:xml.sequenceOffset=-60
introduction	DocumentationBlock	01	aggr	This represents more information about how the object in question is built or is used. Therefore it is a DocumentationBlock.
				Tags:xml.sequenceOffset=-30
uuid	String	01	attr	The purpose of this attribute is to provide a globally unique identifier for an instance of a meta-class. The values of this attribute should be globally unique strings prefixed by the type of identifier. For example, to include DCE UUID as defined by The Open Group, the UUID would be preceded by "DCE:". The values of this attribut may be used to support merging of different AUTOSAR models. The form of the UUID (Universally Unique Identifier) is taken from a standard defined by the Open Group (was Open Software Foundation). This standard i widely used, including by Microsoft for COM (GUIDs) and by many companies for DCE, which is based on CORBA The method for generating these 128-bit IDs is published in the standard and the effectiveness and uniqueness of the IDs is not in practice disputed. If the id namespace is omitted, DCE is assumed. An example is "DCE:2fac1234-31f8-11b4-a222-08002b34c003". The uuid attribute has no semantic meaning for an AUTOSAR model and there is no requirement for AUTOSAR tools to manage the timestamp.
				Tags:xml.attribute=true

Table A.9: Identifiable

Class	LogAndTraceInstantiation						
Package	M2::AUTOSARTempla	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::LogAndTrace					
Note	This meta-class define	This meta-class defines the attributes for the Log&Trace configuration on a specific machine.					
	Tags:atp.Status=draft						
Base	1 1 1	ARObject, AdaptiveModuleInstantiation, Identifiable, MultilanguageReferrable, NonOsModule Instantiation, Referrable					
Attribute	Туре	Mult.	Kind	Note			
dltEcu	DItEcu	01	ref	Reference to the Ecu representation in the Log And Trace Extract.			
				Tags:atp.Status=draft			
logSink	DltLogSink	*	ref	Reference to output sinks for log or trace messages that are produced on the Machine.			
				Tags:atp.Status=draft			
sessionId Support	Boolean	01	attr	This attribute defines whether the sessionId is used or not.			
				Tags:atp.Status=draft			





Class	LogAndTraceInstantiation					
timeBase Resource	TimeBaseResource	01	ref	This reference is used to describe to which time base the Log and Trace module has access. From the Time Base Resource the Log and Trace module gets the needed information to generate the time stamp. Tags:atp.Status=draft		

Table A.10: LogAndTraceInstantiation

Class	LogAndTraceInterface	LogAndTraceInterface					
Package	M2::AUTOSARTemplates:	:Adaptive	Platform::	ApplicationDesign::PortInterface			
Note	Tags: atp.Status=draft						
Base		ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, PortInterface, Referrable					
Attribute	Туре	Type Mult. Kind Note					
_	_	-	-	-			

Table A.11: LogAndTraceInterface

Class	LogAndTraceMessageCollectionSet					
Package	M2::AUTOSARTemplates:	:LogAndT	raceExtra	ct		
Note	Collection of DltMessages	;				
	Tags:atp.recommendedPa	ackage=Lo	ogAndTra	ceMessageCollectionSets		
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable					
Attribute	Туре	Mult.	Kind	Note		
dltMessage	DitMessage	*	aggr	Collection of DltMessages in the DltMessageCollection Set.		
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=dltMessage.shortName, dlt Message.variationPoint.shortLabel vh.latestBindingTime=systemDesignTime		

Table A.12: LogAndTraceMessageCollectionSet

Class	Machine					
Package	M2::AUTOSARTemplates::AdaptivePlatform::MachineManifest					
Note	Machine that represents an Adaptive Autosar Software Stack.					
	Tags: atp.Status=draft atp.recommendedPackage=Machines					
Base	ARElement, ARObject, AtpClassifier, AtpFeature, AtpStructureElement, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable					
Attribute	Type Mult. Kind Note					





Class	Machine			
default Application Timeout	EnterExitTimeout	01	aggr	This aggration defines a default timeout in the context of a given Machine with respect to the launching and termination of applications.
				Tags:atp.Status=draft
environment Variable	TagWithOptionalValue	*	aggr	This aggregation represents the collection of environment variables that shall be added to the environment defined on the level of the enclosing Machine.
				Stereotypes: atpSplitable Tags: atp.Splitkey=environmentVariable, environment Variable.variationPoint.shortLabel atp.Status=draft
machineDesign	MachineDesign	1	ref	Reference to the MachineDesign this Machine is implementing.
				Tags:atp.Status=draft
module Instantiation	AdaptiveModule Instantiation	*	aggr	Configuration of Adaptive Autosar module instances that are running on the machine.
				Stereotypes: atpSplitable Tags: atp.Splitkey=moduleInstantiation.shortName atp.Status=draft
processor	Processor	1*	aggr	This represents the collection of processors owned by the enclosing machine.
				Tags:atp.Status=draft
secure Communication	SecureCommunication Deployment	*	aggr	Deployment of secure communication protocol configuration settings to crypto module entities.
Deployment				Stereotypes: atpSplitable Tags: atp.Splitkey=secureCommunicationDeployment.short Name atp.Status=draft
trustedPlatform Executable	TrustedPlatform ExecutableLaunch	1	attr	This attribute controls the behavior of how authentication affects the ability to launch for each Executable.
LaunchBehavior	BehaviorEnum			Tags:atp.Status=draft

Table A.13: Machine

Class	PlatformModuleEthernetEndpointConfiguration					
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::AdaptiveModule Implementation					
Note	This meta-class defines the attributes for the configuration of a port, protocol type and IP address of the communication on a VLAN.					
	Tags: atp.Status=draft atp.recommendedPackage=PlatformModuleEndpointConfigurations					
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, PlatformModuleEndpointConfiguration, Referrable					
Attribute	Туре	Mult.	Kind	Note		
communication Connector	EthernetCommunication Connector	01	ref	Reference to the CommunicationConnector (VLAN) for which the network configuration is defined.		
				Tags:atp.Status=draft		





Class	PlatformModuleEthernetEndpointConfiguration				
ipv4MulticastIp Address	lp4AddressString	01	attr	Multicast IPv4 Address to which the message will be transmitted.	
				Tags:atp.Status=draft	
ipv6MulticastIp Address	lp6AddressString	01	attr	Multicast IPv6 Address to which the message will be transmitted.	
				Tags:atp.Status=draft	
tcpPort	ApApplicationEndpoint	01	ref	This reference allows to configure a tcp port number.	
				Tags:atp.Status=draft	
udpPort	ApApplicationEndpoint	01	ref	This reference allows to configure a udp port number.	
				Tags:atp.Status=draft	

Table A.14: PlatformModuleEthernetEndpointConfiguration

Class	PortPrototype (abstract)							
Package	M2::AUTOSARTemplates::SWComponentTemplate::Components							
Note	Base class for the ports of an AUTOSAR software component.							
	The aggregation of PortPrototypes is subject to variability with the purpose to support the conditional existence of ports.							
Base	ARObject, AtpBlueprintal	ole, AtpFe	ature, Atp	Prototype, Identifiable, MultilanguageReferrable, Referrable				
Subclasses	AbstractProvidedPortProt	totype, Ab	stractReq	uiredPortPrototype				
Attribute	Туре	Mult.	Kind	Note				
clientServer Annotation	ClientServerAnnotation	*	aggr	Annotation of this PortPrototype with respect to client/ server communication.				
delegatedPort Annotation	DelegatedPort Annotation	01	aggr	Annotations on this delegated port.				
ioHwAbstraction Server Annotation	IoHwAbstractionServer Annotation	*	aggr	Annotations on this IO Hardware Abstraction port.				
logAndTrace Message	LogAndTraceMessage CollectionSet	01	ref	Reference to a collection of Log or Trace messages that will be used by the application.				
CollectionSet				Tags:atp.Status=draft				
modePort Annotation	ModePortAnnotation	*	aggr	Annotations on this mode port.				
nvDataPort Annotation	NvDataPortAnnotation	*	aggr	Annotations on this non voilatile data port.				
parameterPort Annotation	ParameterPort Annotation	*	aggr	Annotations on this parameter port.				
portPrototype Props	PortPrototypeProps	01	aggr	This attribute allows for the definition of further qualification of the semantics of a PortPrototype.				
				Tags:atp.Status=draft				
senderReceiver Annotation	SenderReceiver Annotation	*	aggr	Collection of annotations of this ports sender/receiver communication.				
triggerPort Annotation	TriggerPortAnnotation	*	aggr	Annotations on this trigger port.				

Table A.15: PortPrototype



Class	Process							
Package	M2::AUTOSARTemplates::AdaptivePlatform::ExecutionManifest							
Note	This meta-class provides information required to execute the referenced executable.							
	Tags: atp.Status=draft atp.recommendedPackage=Processes							
Base	ARElement, ARObject, AbstractExecutionContext, AtpClassifier, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable, UploadablePackageElement							
Attribute	Туре	Mult.	Kind	Note				
design	ProcessDesign	01	ref	This reference represents the identification of the design-time representation for the Process that owns the reference.				
				Tags:atp.Status=draft				
deterministic Client	DeterministicClient	01	ref	This reference adds further execution characteristics for deterministic clients.				
				Tags:atp.Status=draft				
executable	Executable	01	ref	Reference to executable that is executed in the process.				
				Stereotypes: atpUriDef Tags:atp.Status=draft				
functionCluster Affiliation	String	01	attr	This attribute specifies which functional cluster the process is affiliated with.				
				Tags:atp.Status=draft				
numberOf RestartAttempts	PositiveInteger	01	attr	This attribute defines how often a process shall be restarted if the start fails.				
				numberOfRestartAttempts = "0" OR Attribute not existing, start once				
				numberOfRestartAttempts = "1", start a second time				
				Tags:atp.Status=draft				
preMapping	Boolean	01	attr	This attribute describes whether the executable is preloaded into the memory.				
				Tags:atp.Status=draft				
processState	ModeDeclarationGroup	01	aggr	Set of Process States that are defined for the process.				
Machine	Prototype			Tags:atp.Status=draft				
securityEvent	SecurityEventDefinition	*	ref	The reference identifies the collection of SecurityEvents that can be reported by the enclosing SoftwareCluster.				
				Stereotypes: atpSplitable; atpUriDef Tags: atp.Splitkey=securityEvent atp.Status=draft				
stateDependent	StateDependentStartup	*	aggr	Applicable startup configurations.				
StartupConfig	Config			Tags:atp.Status=draft				

Table A.16: Process

Class	Referrable (abstract)
Package	M2::AUTOSARTemplates::GenericStructure::GeneralTemplateClasses::Identifiable
Note	Instances of this class can be referred to by their identifier (while adhering to namespace borders).
Base	ARObject





Class	Referrable (abstract)				
Subclasses	AtpDefinition, BswDistinguishedPartition, BswModuleCallPoint, BswModuleClientServerEntry, Bsw VariableAccess, CouplingPortTrafficClassAssignment, CppImplementationDataTypeContextTarget, DiagnosticEnvModeElement, EthernetPriorityRegeneration, ExclusiveAreaNestingOrder, HwDescription Entity, ImplementationProps, ModeTransition, MultilanguageReferrable, NmNetworkHandle, Pnc MappingIdent, SingleLanguageReferrable, SoConlPduIdentifier, SocketConnectionBundle, Someip RequiredEventGroup, TimeSyncServerConfiguration, TpConnectionIdent				
Attribute	Type Mult. Kind Note				
shortName	Identifier	1	attr	This specifies an identifying shortName for the object. It needs to be unique within its context and is intended for humans but even more for technical reference.	
				Stereotypes: atpldentityContributor Tags: xml.enforceMinMultiplicity=true xml.sequenceOffset=-100	
shortName Fragment	ShortNameFragment	*	aggr	This specifies how the Referrable.shortName is composed of several shortNameFragments.	
				Tags:xml.sequenceOffset=-90	

Table A.17: Referrable

Class	SwComponentPrototyp	SwComponentPrototype				
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::SWComponentTemplate::Composition				
Note	Role of a software compo	Role of a software component within a composition.				
Base	ARObject, AtpFeature, A	ARObject, AtpFeature, AtpPrototype, Identifiable, MultilanguageReferrable, Referrable				
Attribute	Туре	Type Mult. Kind Note				
type	SwComponentType	SwComponentType 01 tref Type of the instance.				
				Stereotypes: isOfType		

Table A.18: SwComponentPrototype

Class	< <atpvariation>> SwDataDefProps</atpvariation>
Package	M2::MSR::DataDictionary::DataDefProperties





Class	< <atpvariation>> SwData</atpvariation>	DefProps	;						
Note		attern of i	nheritanc	nt for data objects under various aspects. One could e by aggregation". The properties can be applied to all ps is aggregated.					
	Note that not all of the attributes or associated elements are useful all of the time. Hence, the process definition (e.g. expressed with an OCL or a Document Control Instance MSR-DCI) has the task of implementing limitations.								
	SwDataDefProps covers various aspects:								
	 Structure of the data element for calibration use cases: is it a single value, a curve, or a map, but also the recordLayouts which specify how such elements are mapped/converted to the Data Types in the programming language (or in AUTOSAR). This is mainly expressed by properties like swRecordLayout and swCalprmAxisSet 								
	 Implementation aspects, mainly expressed by swImplPolicy, swVariableAccessImplPolicy, sw AddrMethod, swPointerTagetProps, baseType, implementationDataType and additionalNative TypeQualifier 								
	 Access policy for 	the MCD	system, n	nainly expressed by swCalibrationAccess					
	 Semantics of the invalidValue 	data elem	ent, main	ly expressed by compuMethod and/or unit, dataConstr,					
	Code generation	policy pro	vided by s	swRecordLayout					
	Tags:vh.latestBindingTime	e=codeGe	enerationT	Time					
Base	ARObject								
Attribute	Туре	Mult.	Kind	Note					
additionalNative TypeQualifier	NativeDeclarationString	01	attr	This attribute is used to declare native qualifiers of the programming language which can neither be deduced from the baseType (e.g. because the data object describes a pointer) nor from other more abstract attributes. Examples are qualifiers like "volatile", "strict" or "enum" of the C-language. All such declarations have to be put into one string.					
				Tags:xml.sequenceOffset=235					
annotation	Annotation	*	aggr	This aggregation allows to add annotations (yellow pads) related to the current data object.					
				Tags: xml.roleElement=true xml.roleWrapperElement=true xml.sequenceOffset=20 xml.typeElement=false xml.typeWrapperElement=false					
baseType	SwBaseType	01	ref	Base type associated with the containing data object.					
				Tags:xml.sequenceOffset=50					
compuMethod	CompuMethod	01	ref	Computation method associated with the semantics of this data object.					
				Tags:xml.sequenceOffset=180					
dataConstr	DataConstr	01	ref	Data constraint for this data object.					
				Tags:xml.sequenceOffset=190					
displayFormat	DisplayFormatString	01	attr	This property describes how a number is to be rendered e.g. in documents or in a measurement and calibration system.					
				Tags:xml.sequenceOffset=210					
display	DisplayPresentation Enum	01	attr	This attribute controls the presentation of the related data for measurement and calibration tools.					





Class	< <atpvariation>> SwData</atpvariation>	DefProps	3	
implementation DataType	AbstractImplementation DataType	01	ref	This association denotes the ImplementationDataType of a data declaration via its aggregated SwDataDefProps. It is used whenever a data declaration is not directly referring to a base type. Especially
				 redefinition of an ImplementationDataType via a "typedef" to another ImplementationDatatype
				 the target type of a pointer (see SwPointerTarget Props), if it does not refer to a base type directly
				 the data type of an array or record element within an ImplementationDataType, if it does not refer to a base type directly
				 the data type of an SwServiceArg, if it does not refer to a base type directly
				Tags:xml.sequenceOffset=215
invalidValue	ValueSpecification	01	aggr	Optional value to express invalidity of the actual data element.
				Tags:xml.sequenceOffset=255
stepSize	Float	01	attr	This attribute can be used to define a value which is added to or subtracted from the value of a DataPrototype when using up/down keys while calibrating.
swAddrMethod	SwAddrMethod	01	ref	Addressing method related to this data object. Via an association to the same SwAddrMethod it can be specified that several DataPrototypes shall be located in the same memory without already specifying the memory section itself.
				Tags:xml.sequenceOffset=30
swAlignment	AlignmentType	01	attr	The attribute describes the intended typical alignment of the DataPrototype. If the attribute is not defined the alignment is determined by the swBaseType size and the memoryAllocationKeywordPolicy of the referenced Sw AddrMethod.
				Tags:xml.sequenceOffset=33
swBit Representation	SwBitRepresentation	01	aggr	Description of the binary representation in case of a bit variable.
				Tags:xml.sequenceOffset=60
swCalibration Access	SwCalibrationAccess Enum	01	attr	Specifies the read or write access by MCD tools for this data object.
				Tags:xml.sequenceOffset=70
swCalprmAxis Set	SwCalprmAxisSet	01	aggr	This specifies the properties of the axes in case of a curve or map etc. This is mainly applicable to calibration parameters.
				Tags:xml.sequenceOffset=90
swComparison	SwVariableRefProxy	*	aggr	Variables used for comparison in an MCD process.
Variable				Tags: xml.sequenceOffset=170 xml.typeElement=false
swData Dependency	SwDataDependency	01	aggr	Describes how the value of the data object has to be calculated from the value of another data object (by the MCD system).
				Tags:xml.sequenceOffset=200





Class	< <atpvariation>> SwData</atpvariation>	aDefProps	3	
swHostVariable	SwVariableRefProxy	01	aggr	Contains a reference to a variable which serves as a host-variable for a bit variable. Only applicable to bit objects.
				Tags: xml.sequenceOffset=220 xml.typeElement=false
swImplPolicy	SwImplPolicyEnum	01	attr	Implementation policy for this data object.
				Tags:xml.sequenceOffset=230
swIntended Resolution	Numerical	01	attr	The purpose of this element is to describe the requested quantization of data objects early on in the design process.
				The resolution ultimately occurs via the conversion formula present (compuMethod), which specifies the transition from the physical world to the standardized world (and vice-versa) (here, "the slope per bit" is present implicitly in the conversion formula).
				In the case of a development phase without a fixed conversion formula, a pre-specification can occur through swIntendedResolution.
				The resolution is specified in the physical domain according to the property "unit".
				Tags:xml.sequenceOffset=240
swInterpolation Method	Identifier	01	attr	This is a keyword identifying the mathematical method to be applied for interpolation. The keyword needs to be related to the interpolation routine which needs to be invoked.
				Tags:xml.sequenceOffset=250
swlsVirtual	Boolean	01	attr	This element distinguishes virtual objects. Virtual objects do not appear in the memory, their derivation is much more dependent on other objects and hence they shall have a swDataDependency.
				Tags:xml.sequenceOffset=260
swPointerTarget Props	SwPointerTargetProps	01	aggr	Specifies that the containing data object is a pointer to another data object.
				Tags:xml.sequenceOffset=280
swRecord	SwRecordLayout	01	ref	Record layout for this data object.
Layout				Tags:xml.sequenceOffset=290
swRefresh Timing	MultidimensionalTime	01	aggr	This element specifies the frequency in which the object involved shall be or is called or calculated. This timing can be collected from the task in which write access processes to the variable run. But this cannot be done by the MCD system.
				So this attribute can be used in an early phase to express the desired refresh timing and later on to specify the real refresh timing.
		<u> </u>		Tags:xml.sequenceOffset=300
swTextProps	SwTextProps	01	aggr	the specific properties if the data object is a text object.
				Tags:xml.sequenceOffset=120
swValueBlock	Numerical	01	attr	This represents the size of a Value Block
Size				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime





Class	< <atpvariation>> SwDat</atpvariation>	aDefProps	•	
swValueBlock SizeMult (ordered)	Numerical	*	attr	This attribute is used to specify the dimensions of a value block (VAL_BLK) for the case that that value block has more than one dimension.
				The dimensions given in this attribute are ordered such that the first entry represents the first dimension, the second entry represents the second dimension, and so on.
				For one-dimensional value blocks the attribute swValue BlockSize shall be used and this attribute shall not exist.
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime
unit	Unit	01	ref	Physical unit associated with the semantics of this data object. This attribute applies if no compuMethod is specified. If both units (this as well as via compuMethod) are specified the units shall be compatible.
				Tags:xml.sequenceOffset=350
valueAxisData Type	ApplicationPrimitive DataType	01	ref	The referenced ApplicationPrimitiveDataType represents the primitive data type of the value axis within a compound primitive (e.g. curve, map). It supersedes CompuMethod, Unit, and BaseType.
				Tags:xml.sequenceOffset=355

Table A.19: SwDataDefProps