

EB tresos® AutoCore Generic 8 Transformers documentation

product release 8.7.5





Elektrobit Automotive GmbH Am Wolfsmantel 46 91058 Erlangen, Germany Phone: +49 9131 7701 0

Fax: +49 9131 7701 6333

Email: info.automotive@elektrobit.com

Technical support

https://www.elektrobit.com/support

Legal disclaimer

Confidential information.

ALL RIGHTS RESERVED. No part of this publication may be copied in any form, by photocopy, microfilm, retrieval system, or by any other means now known or hereafter invented without the prior written permission of Elektrobit Automotive GmbH.

All brand names, trademarks, and registered trademarks are property of their rightful owners and are used only for description.

Copyright 2021, Elektrobit Automotive GmbH.



Table of Contents

1. Overview of EB tresos Autocore Generic o Transformers documentation	. ,
2. Supported features	. 8
2.1. Overview	. 8
2.2. Product details	8
2.3. Feature details	8
2.3.1. Supported ComXf features	. 8
2.3.2. Supported SomelpXf features	. 9
3. ACG8 Transformers release notes	10
3.1. Overview	10
3.2. Scope of the release	10
3.2.1. Configuration tool	10
3.2.2. AUTOSAR modules	10
3.2.3. EB (Elektrobit) modules	10
3.2.4. MCAL modules and EB tresos AutoCore OS	11
3.3. Module release notes	11
3.3.1. ComXf module release notes	11
3.3.1.1. Change log	11
3.3.1.2. New features	16
3.3.1.3. EB-specific enhancements	17
3.3.1.4. Deviations	18
3.3.1.5. Limitations	23
3.3.1.6. Open-source software	26
3.3.2. SomelpXf module release notes	27
3.3.2.1. Change log	27
3.3.2.2. New features	34
3.3.2.3. EB-specific enhancements	34
3.3.2.4. Deviations	35
3.3.2.5. Limitations	39
3.3.2.6. Open-source software	42
3.3.3. Xfrm module release notes	42
3.3.3.1. Change log	42
3.3.3.2. New features	47
3.3.3.3. EB-specific enhancements	47
3.3.3.4. Deviations	47
3.3.3.5. Limitations	47
3.3.3.6. Open-source software	47
4. ACG8 Transformers user's guide	48
4.1. Overview	48
4.2. Background information	48



4.2.1. Functional overview	48
4.2.2. Data transformation use cases	51
4.2.3. AUTOSAR modules for data transformation	52
4.3. Using data transformation support	53
4.3.1. Adding data transformation to the system description	53
4.3.2. Configuring data transformation modules using EB tresos Studio	54
4.4. ComXf module user's guide	55
4.4.1. Overview	55
4.4.2. Background information	56
4.4.3. Configuring ComXf	56
4.4.4. ComXf integration notes	57
4.5. SomelpXf module user's guide	57
4.5.1. Overview	57
4.5.2. Background information	58
4.5.3. Configuring SomelpXf	58
4.5.4. SomeIpXf integration notes	59
5. ACG8 Transformers module references	60
5.1. Overview	60
5.1.1. Notation in EB module references	60
5.1.1.1. Default value of configuration parameters	60
5.1.1.2. Range information of configuration parameters	60
5.2. ComXf	
5.2.1. Configuration parameters	61
5.2.1.1. CommonPublishedInformation	61
5.2.1.2. PublishedInformation	64
5.2.1.3. XfrmGeneral	65
5.2.1.4. XfrmImplementationMapping	66
5.2.1.5. XfrmVariableDataPrototypeInstanceRef	68
5.2.1.6. XfrmDemEventParameterRefs	
5.2.1.7. XfrmSignal	69
5.2.1.8. XfrmSignalChoice	69
5.2.1.9. XfrmlSignalGroupRefChoice	70
5.2.1.10. XfrmlSignalRefChoice	70
5.2.2. Application programming interface (API)	
5.2.2.1. Type definitions	
5.2.2.1.1. ComXf_ConfigType	
5.2.2.2. Macro constants	
5.2.2.2.1. COMXF E INIT FAILED	
5.2.2.2. COMXF_E_PARAM	
5.2.2.3. COMXF_E_PARAM_POINTER	
5.2.2.2.4. COMXF_E_UNINIT	
5.2.2.2.5. COMXF_INSTANCE_ID	
	· · -



5.2.2.2.6. COMXF_SID_DEINIT	72
5.2.2.7. COMXF_SID_GETVERSIONINFO	72
5.2.2.2.8. COMXF_SID_INIT	72
5.2.2.2.9. COMXF_SID_SR_INV_TRANSFORMER	72
5.2.2.2.10. COMXF_SID_SR_TRANSFORMER	72
5.2.2.3. Functions	73
5.2.2.3.1. ComXf_DeInit	73
5.2.2.3.2. ComXf_GetVersionInfo	73
5.2.2.3.3. ComXf_Init	73
5.2.2.3.4. ComXf_Inv_transformerId	74
5.2.2.3.5. ComXf_transformerId	74
5.2.3. Integration notes	75
5.2.3.1. Exclusive areas	75
5.2.3.2. Production errors	75
5.2.3.3. Memory mapping	75
5.2.3.4. Integration requirements	76
5.2.3.4.1. ComXf.EB.IntReq.RequiresCom01	76
5.2.3.4.2. ComXf.EB.IntReq.InitRoutines	76
5.2.3.4.3. ComXf.EB.IntReq.RequiresE2E01	76
5.2.3.4.4. ComXf.EB.IntReq.EB_INTREQ_Com_0002	77
5.2.3.4.5. ComXf.EB.IntReq.EB_INTREQ_Com_0003	78
5.2.3.4.6. ComXf.EB.IntReq.EB_INTREQ_Com_0005	79
5.3. SomelpXf	80
5.3.1. Configuration parameters	80
5.3.1.1. CommonPublishedInformation	81
5.3.1.2. PublishedInformation	84
5.3.1.3. XfrmGeneral	84
5.3.1.4. XfrmImplementationMapping	85
5.3.1.5. XfrmVariableDataPrototypeInstanceRef	87
5.3.1.6. XfrmDemEventParameterRefs	88
5.3.1.7. XfrmSignal	89
5.3.1.8. XfrmSignalChoice	89
5.3.1.9. XfrmlSignalGroupRefChoice	89
5.3.1.10. XfrmlSignalRefChoice	
5.3.2. Application programming interface (API)	
5.3.2.1. Functions	90
5.3.2.1.1. SomelpXf_CS_transformerId	90
5.3.2.1.2. SomelpXf_Inv_CS_transformerId	91
5.3.2.1.3. SomelpXf_Inv_ET_transformerId	
5.3.2.1.4. SomelpXf_Inv_SR_transformerId	
5.3.2.1.5. SomelpXf_SR_transformerId	
5.3.2.1.6. SomelpXf_TE_transformerId	95



	5.3.3	Integration notes	95
		5.3.3.1. Exclusive areas	95
		5.3.3.2. Production errors	96
		5.3.3.3. Memory mapping	96
		5.3.3.4. Integration requirements	96
6.	Bibliography		97



1. Overview of EB tresos AutoCore Generic 8 Transformers documentation

Welcome to the EB tresos AutoCore Generic 8 Transformers (ACG8 Transformers) product documentation.

This document provides:

- ► <u>Chapter 2, "Supported features"</u>: list of features supported by the ACG8 Transformers
- Chapter 3, "ACG8 Transformers release notes": release notes for the ACG8 Transformers modules
- Chapter 4, "ACG8 Transformers user's guide": containing background information and instructions
- ► <u>Chapter 5, "ACG8 Transformers module references"</u>: information about configuration parameters and the application programming interface



2. Supported features

2.1. Overview

This chapter provides an overview of the products of ACG8 Transformers and the features that are currently supported.

Section 2.2, "Product details" contains an overview of the products of ACG8 Transformers.

Section 2.3.1, "Supported ComXf features" contains an overview of ComXf features.

Section 2.3.2, "Supported SomelpXf features" contains an overview of SomelpXf features.

2.2. Product details

ACG8 Transformers provides AUTOSAR modules for the EB tresos AutoCore Generic (ACG) product line. ACG8 Transformers is based on AUTOSAR 4.2.1, selected features of AUTOSAR 4.2.2, AUTOSAR 4.3.0, and EB-specific enhancements implemented compatible to the AUTOSAR standard.

ACG8 Transformers includes the following basic software modules:

Basic software modules	Module abbreviation
COM Based Transformer	ComXf
SOME/IP Transformer	SomelpXf

2.3. Feature details

This chapter contains an overview of the supported and unsupported features.

2.3.1. Supported ComXf features

ComXf provides the following main features according to the AUTOSAR specification:

▶ Data serialization according to Com configuration: Serialization of complex data elements into a byte stream of variable length according to the configuration of the AUTOSAR Com module which in turn is derived from the AUTOSAR system description.



▶ Data de-serialization according to Com configuration: De-serialization of a byte stream of variable length into complex data element according to the configuration of the AUTOSAR com module which in turn is derived from the AUTOSAR system description.

2.3.2. Supported SomelpXf features

SomeIpXf provides the following main features according to the AUTOSAR specification:

- ▶ Data serialization according to SOME/IP: Serialization of complex data elements and remote client/ server calls and responses into a byte stream of variable length according to the SOME/IP specification. Hereby the serialization of remote client/server calls includes remote client/server calls of fire-and-forget methods (REQUEST_NO_RETURN) which are handled via inter-ECU external trigger event communication according to AUTOSAR 4.2.2 (RFC #67799).
- ▶ Data de-serialization according to SOME/IP: De-serialization of a byte stream of variable length into complex data elements and remote client/server calls and responses according to the SOME/IP specification. Hereby the de-serialization of remote client/server calls includes remote client/server calls of fire-and-forget methods (REQUEST_NO_RETURN) which are handled via inter-ECU external trigger event communication according to AUTOSAR 4.2.2 (RFC #67799).



3. ACG8 Transformers release notes

3.1. Overview

This chapter provides the ACG8 Transformers product specific release notes. General release notes that are applicable to all products are provided in the EB tresos AutoCore Generic documentation. Refer to the general release notes in addition to the product release notes documented here.

3.2. Scope of the release

3.2.1. Configuration tool

Your release of EB tresos AutoCore is compatible with the release of the EB tresos Studio configuration tool:

EB tresos Studio: 27.1.0 b210224-0338

3.2.2. AUTOSAR modules

The following table lists the AUTOSAR modules that are part of this ACG8 Transformers release.

Module name	AUTOSAR version and revision	SWS version and revision	Module version	Supplier
ComXf	4.2.1 []	4.2.1 [0000]	1.0.35	Elektrobit Automo- tive GmbH
SomelpXf	4.2.1 []	4.2.1 [0000]	1.0.44	Elektrobit Automotive GmbH

Table 3.1. Hardware-Independent Modules specified by the AUTOSAR standard

3.2.3. EB (Elektrobit) modules

The following table lists all modules which are part of this release but are not specified by the AUTOSAR standard. These modules include tooling developed by EB or they may hold files shared by all other modules.



Module name	Module version	Supplier
<u>Xfrm</u>	1.0.30	Elektrobit Automotive GmbH

Table 3.2. Modules not specified by the AUTOSAR standard

3.2.4. MCAL modules and EB tresos AutoCore OS

For information about MCAL modules and OS, refer to the respective documentation, which is available as PDF at $TRESOS_BASE/doc/3.0_EB_tresos_AutoCore_OS$ and $TRESOS_BASE/doc/5.0_MCAL_modules^1$. It is also available in the online help in EB tresos Studio. Browse to the folders EB tresos AutoCore OS and MCAL modules.

3.3. Module release notes

3.3.1. ComXf module release notes

AUTOSAR R4.2 Rev 1

AUTOSAR SWS document version: 4.2.1

Module version: 1.0.35.B403451

Supplier: Elektrobit Automotive GmbH

3.3.1.1. Change log

This chapter lists the changes between different versions.

Module version 1.0.35

2021-02-19

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.34

2020-11-06

¹\$TRESOS BASE is the location at which you installed EB tresos Studio.



Internal module improvement. This module version update does not affect module functionality

Module version 1.0.33

2020-06-19

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.32

2020-01-24

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.31

2019-10-11

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.30

2019-07-05

ASCCOMXF-492, ASCE2E-771 Fixed known issue: Invalid safety-related ComXf support for XfrmBuffer-LengthType configured to UINT32 (Note: requires also E2E library update)

Module version 1.0.29

2019-03-22

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.28

2019-02-15

Added 64 bit data types de-/serialization support

Module version 1.0.27

2018-10-26

ASCCOMXF-449 Fixed known issue: Generator aborts with an exception when simple array of primitive data types is configured as ApplicationDataTypes



2018-09-28

ASCCOMXF-442 Fixed known issue: Safety Com transformer calculates wrong buffer size

Module version 1.0.25

2018-07-27

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.24

2018-06-22

Moved safety checker part from module to asc_ComXfCV

Module version 1.0.23

2018-05-25

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.22

2018-03-16

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.21

2018-02-16

Allow partial SenderReceiverToSignalGroupMapping

Module version 1.0.20

2017-12-15

- ASCCOMXF-347 Fixed known issue: Wrong byte size used for packing/unpacking of data elements configured with big-endian byte order
- Implemented support for configurable type of BufferLength
- Added XfrmIsSafetyTransformer configuration parameter



2017-09-22

- Added 64 bit support for safety related de-/serialization of signal groups
- Switch from MISRA-C:2004 to MISRA-C:2012

Module version 1.0.18

2017-08-25

Use ImplementationDataType of (outermost) composition

Module version 1.0.17

2017-06-30

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.16

2017-06-02

Added support for safety related de-/serialization of signal groups

Module version 1.0.15

2017-05-05

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.14

2017-03-31

- Incorporated Bugzilla RfC 69896: Execution of Transformer chain in case of unqueued communication when no data is available
- Incorporated Bugzilla RfC 68623: Insufficient specification of autonomous error response
- Removed and incorporated EB tresos AutoCore Generic 8 Transformer (COM) user's guide into EB tresos AutoCore Generic 8 Transformers documentation

Module version 1.0.13

2017-01-05



Internal module improvement. This module version update does not affect module functionality

Module version 1.0.12

2016-12-02

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.11

2016-11-04

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.10

2016-10-07

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.9

2016-09-09

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.8

2016-07-01

- Added support for memory partitioning of partitioned RTE
- ► ASCCOMXF-115 Fixed known issue: Incorrect mapping from ApplicationRecordElement to ImplementationRecordElement

Module version 1.0.7

2016-05-25

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.6

2016-04-29

Internal module improvement. This module version update does not affect module functionality



2016-04-01

ASCCOMXF-64 Fixed known issue: Unserialized signals when referenced by application data type

Module version 1.0.4

2016-02-05

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.3

2016-01-15

Added support of ApplicationDataTypes

Module version 1.0.2

2015-11-06

- Changed parameter name XfrmTransformationBswModuleEntryRef to XfrmTransformerBswModuleEntryRef (see AUTOSAR RfC #68531)
- Added support for specification of XfrmVariableDataPrototypeInstanceRef (multiple receivers)

Module version 1.0.1

2015-10-09

Implemented robust code generation by reporting a warning and ignoring problematic XfrmImplementationMappings

Module version 1.0.0

2015-06-19

Initial version

3.3.1.2. New features

No new features have been added since the last release.



3.3.1.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

Integration requirement: EB_INTREQ_ComXf_0002

Support for serialization of unaligned / non-consecutively mapped signal groups

Description:

The ACG7 Transformer (COM) supports the serialization of signal groups which do not start or end at byte boundaries. Further, there is no constraint that group signals must be completely or consecutively mapped to the IPdu.

Before serialization the transformer initializes the (Rte) buffer with the latest values of the area of the EB Com module internal I-PDU buffer corresponding to the signal group. That includes unused area bits as well as the values of signals / group signals of other group signals. If the value of a signal / group signal has never been updated the latest value equals the initial value (ComSignalInitValue). Therefore the initial value is also taken for group signals which are not mapped to a Data Element member.

Note: Unaligned signal groups must be considered in the AUTOSAR System / Software Component Description such that the TransformerTechnology of the related COM Based Transformer specifies more bytes for the BufferComputation within the BufferProperties.

Note: There is no check (neither at configuration time, nor at compile time, nor at runtime) if the buffer provided by Rte is big enough to hold the resulting array starting with the byte of the first group signal and ending with the last group signal.

Integration requirement: EB_INTREQ_ComXf_0003

Support for de-serialization of unaligned / non-consecutively mapped signal groups

Description:

The ACG7 Transformer (COM) supports the de-serialization of signal groups which do not start or end at byte boundaries. Further, there is no constraint that group signals must be completely or consecutively mapped to the IPdu.

The AUTOSAR Com module updates the buffer for the transformer with the latest values of the area of the AUTOSAR Com module internal I-PDU buffer corresponding to the signal group. That includes unused area bits as well as the values of signals / group signals of other group signals. The ACG7 Transformer (COM) extracts only the group signals which are mapped to a data element.

Note: Unaligned signal groups must be considered in the AUTOSAR System / Software Component Description such that the TransformerTechnology of the related COM Based Transformer specifies more bytes for the BufferComputation within the BufferProperties.

Integration requirement: EB_INTREQ_ComXf_0004



Support for safety related de-/serialization of signal groups

Description:

If a basic software entry of the ComXf module references a transformer which is part of a transformer chain that includes the E2EXf transformer (safety related), the basic software entry of the ComXf module uses the pack and unpack macros from the E2E library for safety related serialization and de-serialization of the composite data type.

In order to provide safety related serialization and de-serialization the ComXf module does not use the post-build configuration or library APIs of the EB Com module. The system configuration and the pack and unpack macros from the E2E library are used instead. This ensures no information dependencies between the ComXf module and the Com module in case of safety related serialization and de-serialization. However, the configuration of signal groups within the system configuration (for the ComXf module) and the Com module have to be consistent which implies that changes done within the local Com configuration regarding signal groups (i.e. ComBitposition or data types of group signals) needs also be adapted within the system configuration (i.e. ISignalTolPduMapping).

The E2E pack macros including range checks for each group signal during serialization of the corresponding data element member. The range check occur if the value of the data element member cannot be represented by the mapped group signal in relation to the configured bit-length and signal type. In this case the ComXf module returns the error code E2E_RANGECHK_INVALID (0xFFU).

Unused area bits are updated with the value specified in parameter UNUSED-BIT-PATTERN of the system configuration.

3.3.1.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

Module Interlink Types Header File

Description:

The module interlink types header file SchM_ComXfType.h is included instead of the header file SchM_ComXf_Type.h specified by SWS_ComXf_00001.

Rationale:

This allows compatibility to the Rte which generates header file SchM ComXfType.h.

Requirements:

SWS ComXf 00001

Non-reentrant transformer APIs



Description:

In contrast to AUTOSAR which specifies that the generated serializer and de-serializer APIs are reentrant, these APIs are non-reentrant. Additional information on race conditions are stated in Integration requirement EB_INTREQ_Com_0002 of the AUTOSAR Com module.

Extended Production Errors

Description:

Extended production errors are not supported.

Requirements:

ECUC_Xfrm_00016 ECUC_Xfrm_00015 SWS_Xfrm_00070 SWS_Xfrm_00071

Error Handling

Description:

Even though a hard error is returned, the output buffer of the serializer transformer API (SWS_ComXf_-00007) will be changed. This means that the serialized data is written to the output buffer during serialization. If the hard error occurs the buffer where the serialized data is written to, will not be used.

Rationale:

Only one buffer is used for the serialization process which leads to better performance.

Requirements:

SWS_Xfrm_00051

- ► The following Com module deviations also apply for the ComXf module:
- Signal invalidation is not supported (but is supported via RTE) (reference to product description: ASCPD-15)

Description:

Signal invalidation is not supported. However, the EB tresos AutoCore RTE is extended in order to provide the signal invalidation functionality based on the configuration of the Com module.

Requirements:

COM099, COM286, COM680, COM681, COM736, COM683, COM737, COM717, COM718, COM334, COM024, COM203, COM642, COM643, COM288, COM644, COM557, COM645, COM536, COM315_-Conf, COM391_Conf, COM314_Conf COM738, COM682, COM483, COM396, COM005, COM731

Com_SendSignal() does not return COM_SERVICE_NOT_AVAILABLE in case the value of the signal does not fit into the PDU



Description:

The function <code>Com_SendSignal()</code> does not return <code>COM_SERVICE_NOT_AVAILABLE</code> in case the value of the signal does not fit into the PDU, but an error is reported to DET. However, the SWS states: Return value: <code>E_OK</code> - service has been accepted <code>COM_SERVICE_NOT_AVAILABLE</code> - corresponding I-PDU group was stopped (or service failed due to development error). Therefore a <code>COM_SERVICE_NOT_AVAILABLE</code> should be returned.

Requirements:

COM197

Restricted support of small Rx-I-PDUs

Description:

According to the AUTOSAR COM SWS chapter *Signal indication (Unpacking of I-PDUs)* it is specified that it is allowed that smaller than expected Rx-I-PDUs can be received (configured). In such a case partly or not received signals/signal groups shall not be updated and no notification via ComNotification shall take place.

However, the implementation behaves as follows:

- The received data length (PduInfoPtr->SduLength) is copied into the Com-internal I-PDU buffer. If a signal or signal groups are received only partly, these are also updated partly. Signals/signal groups which are not received at all are not updated. If the I-PDU contains a dynamic length signal the API Com_ReceiveDynSignal() does not copy data and 0 is returned in the length parameter. If a dynamic length signal is used within the signal gateway, the length of the corresponding Tx dynamic length signal is also set to 0.
- ComNotification is invoked for all signals or signal groups that belong to this Rx-I-PDU.

Workaround 1:

- For a smaller Rx-I-PDU, for which it is expected that a signal or signal group is only partly updated: Configure an I-PDU callout which updates the partly received signal/signal groups with a proper value (either last received value or initial value).
- Design the applications in a way that they can handle ComNotification of signals which are not or only partly received.

Workaround 2:

- Provide an application for each expected size of the Rx-I-PDU.
- For each expected size of the Rx-I-PDU configure a Rx-I-PDU in the Com module.
- Create a mapping between the additional applications and Rx-I-PDUs.



Configure an Rx-I-PDU callout with the large I-PDU which invocates Com_RxIndication of the respective smaller Rx-I-PDU and returns FALSE in case a shorter I-PDU is received.

Rationale:

In general this limitation allows a more efficient implementation for I-PDUs which are received completely. Workarounds are available if this feature is required.

Requirements:

COM574, COM575

No generation of symbolic name value into Com_Cfg.h

Description:

Several requirements claim that the symbolic names for the Com Handle IDs shall be published via Com_-Cfg.h. However, the symbolic name values are provided in Com_SymbolicNames_PBcfg.h which is also included in Com.h.

Rationale:

- Requirement is a deviation against TPS_ECUC_02108 of Specification of ECU Configuration which says that the symbolic name values shall be generated into the module header file.
- Requirement is a deviation against SWS_BSW_00200 of SWS General Specification of Basic Software Modules AUTOSAR 4.1 Rev 1, which says that symbolic name values shall be imported through the header of the BSW module that provides the value.
- Shall be removed in future AUTOSAR releases, see http://www.autosar.org/bugzilla/show_bug.cgi? id=60888

Requirements:

COM174, COM126, COM163, COM044, COM521

No support of dynamic length signals in signal groups

Description:

Dynamic length signals are only supported as signals. They are not supported in a group signal.

Rationale:

The implementation uses <code>Com_UpdateShadowSignal()</code> and <code>Com_ReceiveShadowSignal()</code> for the access of group signals. Since AUTOSAR does not define an equivalent API for access dynamic group signals, it is not possible to support dynamic length signals for group signals.

Requirements:



COM127

No support of zero size signals / group signals with transfer property PENDING

Description:

In contrast to AUTOSAR which allows zero size signals / group signals for transfer properties TRIGGERED, PENDING, and TRIGGERED_WITHOUT_REPETITION, only transfer property TRIGGERED is supported.

Requirements:

COM762

Overlapping of ComSignals / ComGroupSignals

Description:

In contrast to AUTOSAR which states that ComSignal / ComGroupSignal are not allowed to overlap each other, the COM module allows the configuration of overlapped ComSignals / ComGroupSignals.

Requirements:

COM102

Configurable callback / callout functions are not provided in Com_Cbk.h

Description:

In contrast to AUTOSAR which states that the configurable callback and callout functions shall be provide in the header file Com_Cbk.h, the COM module does not declare these functions. Instead, it simply declares and calls these external function only in an internal Com compilation unit.

Rationale:

These functions are usually generated / implemented by the Rte which also generates adequate function declarations. The linker then is able to resolve the function calls and the adequate function definitions in Rte.

Requirements:

COM731

Violation of VSMD rule Constr_3023

Description:

The attribute apiServicePrefix is mandatory for VSMDs derived from the CDD StMD. The attribute shall not be provided for VSMDs derived from any other StMDs. The rule is based on Constr_3023 from AUTOSAR TPS ECUConfiguration.pdf of 4.2.1 Release.



Effected node:

StMD-Node: /AUTOSAR/EcucDefs/Xfrm

Rationale:

The ComXf module violates the second part of the rule, but correctly, because SWS_ComXf_00025 requires the definition of apiServicePrefix attribute.

Requirements:

SWS_ComXf_00025

Violation of VSMD rule EcucSws_2038_2040_ASR41

Description:

If there is a SYMBOLIC-NAME-REFERENCE which points to another module, the rule EcucSws_2038_-2040_ASR41, which is based on requirements TPS_ECUC_02038 and TPS_ECUC_02040 from AUTOSAR_TPS_ECUConfiguration.pdf of 4.1 Release, always creates a violation.

Effected nodes:

- VSMD-Node: Xfrm/XfrmImplementationMapping/XfrmDemEventParameterRefs/XFRM_− E_MALFORMED_MESSAGE
- VSMD-Node: Xfrm/XfrmImplementationMapping/XfrmOsApplicationRef

Rationale:

Violation occurs due to an invalid behavior within the EB tresos Studio. No useful workaround available. Rule EcucSws_2038_2040_ASR41 shall be ignored.

Requirements:

ECUC_Xfrm_00016

3.3.1.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

Limitation on Implementation Mapping

Description:



The short name of the implementation mapping has to be identical with the short name of the referenced BSW module entry. I.e. the value of parameter XfrmImplementationMapping is the same as the referenced XfrmTransformerBswModuleEntryRef (or XfrmInvTransformerBswModuleEntryRef).

As a consequence, short name of XfrmImplementationMapping has to be equal the function name of the related transformer API.

Rationale:

It eases the implementation of the module.

Limitation on safety related de-/serialization of signal groups regarding configuration aspects

Description:

In order to provide correct safety related serialization and de-serialization the configuration of signal groups within the system configuration (for the ComXf module) and the Com module have to be consistent which implies that changes done within the local Com configuration regarding signal groups (i.e. ComBitposition or data types of group signals) needs also be adapted within the system configuration (i.e. ISignalToIP-duMapping).

Rationale:

For safety related serialization and de-serialization the ComXf module does not use the post-build configuration or library APIs of the EB Com module. The system configuration and the pack and unpack macros from the E2E library are used instead. This ensures no information dependencies between the ComXf module and the Com module in case of safety related serialization and de-serialization.

Limitation on safety related de-/serialization of signal groups regarding range checks

Description:

The E2E pack macro range checks for float and byte array (opaque data type UINT8_N) signal types are not supported.

Range checks for 64 bit signal types are only supported on byte level.

Limitation on safety related de-/serialization of signal groups regarding 64 bit support

Description:

The E2E packing and unpacking macros for 64 bit signal types includes the following limitations:

- group signals shall be byte aligned
- bitlength shall be a multiple of 8
- Limitation on safety related de-/serialization of signal groups regarding development errors

Description:



In case of safety related serialization and de-serialization of signal groups, development errors are not supported. Development error checks are always performed, but development errors will not be reported. In case of an error a transformer and an inverted transformer return E_SER_GENERIC_ERROR. The configuration parameter XfrmDevErrorDetect will be ignored.

Rationale:

Development errors would have to be conform with the highest requested saftey standard.

Limitation on safety related de-/serialization of signal groups regarding unaligned / non-consecutively mapped signal groups

Description:

In case of safety related serialization and de-serialization of unaligned / non-consecutively mapped signal groups, the transformer does not initialize the (Rte) buffer with the latest values of the area of the EB Com module internal I-PDU buffer corresponding to the signal group or the values of signals / group signals of other group signals.

Rationale:

The initialization of the buffer with the latest version needs internal EB Com module information. This shall not apply for safety related de-/serialization of signal groups. The bit areas are handled as unused areas.

Implementation-specific restrictions

Description:

There are some implementation-specific restrictions which are listed for completeness only, as they are most probably irrelevant for the intended use of the module:

- The maximum number of signals allowed is 65534.
- The maximum number of Rx/Tx I-PDUs allowed is 65534.
- ► The maximum number of callouts configured is 65534.
- The sum of the lengths of all byte-arrays which are sent via the Com module must not exceed 65535 bytes.
- The number of signals and signal group members, signal groups, notifications per I-PDU must not exceed 254.
- Limitation on handling user data with more than 64 KiB

Description:

With parameter XfrmBufferLengthType configured to UINT32, the module is basically allowed to handle user data with more than 64 KiB.



Setting the parameter XfrmBufferLengthType to UINT32 is possible even though user data with more than 64 KiB shall not be handled.

Rationale:

The non-safety related serialization/deserialization relies on the COM module. This holds dedicated constraints on the signal length, not allowing user data greater than 64 KiB to be handled.

The safety related serialization/deserialization relies on the EB tresos data base instead of the COM module. This approach, which would allow handling of user data greater than 64 KiB, is no use case in a safety environment.

Restriction on 64 bit signals/group signals

Description:

The following restrictions for signals/group signals with ComSignalType configured to UINT64 apply:

- ► The ComBitPosition is restricted to be byte aligned.
- ► The ComBitSize is restricted to be a multiple of 8 bit.
- The ComfilterAlgorithm is limited to ALWAYS, NEVER, ONE_EVERY_N, MASKED_NEW_DIF-FERS_X and MASKED_NEW_EQUALS_X.
- ► For the ComfilterAlgorithms MASKED_NEW_DIFFERS_X and MASKED_NEW_EQUALS_X, only the bits with respect to the configured ComBitSize are taken into account for the filter evaluation.
- ► The ComfilterAlgorithm for zero size signals / group signals is limited to ALWAYS and NEVER.

The following restrictions for signals/group signals with ComSignalType configured to SINT64 apply:

- ► The ComBitPosition is restricted to be byte aligned.
- ► The ComBitSize is restricted to be 64 bit (zero size signals / group signals are not supported).
- ► The ComfilterAlgorithm is limited to ALWAYS, NEVER, ONE_EVERY_N, MASKED_NEW_DIF-FERS_X and MASKED_NEW_EQUALS_X.

Requirements:

COM675, COM602, COM170_Conf, COM352, COM325, COM764, COM273, COM603, COM302, COM303, COM763, COM222 COM324, COM793

3.3.1.6. Open-source software

ComXf does not use open-source software.



3.3.2. SomelpXf module release notes

AUTOSAR R4.2 Rev 1

AUTOSAR SWS document version: 4.2.1

Module version: 1.0.44.B403451

Supplier: Elektrobit Automotive GmbH

3.3.2.1. Change log

This chapter lists the changes between different versions.

Module version 1.0.44

2021-02-19

Implemented major inspection source code findings

Module version 1.0.43

2020-11-06

- ASCSOMEIPXF-1055 Fixed known issue: Serialization of fixed size arrays with array length fields results in a generic transformer error
- Incorporated RfC 68113: Session ID is always set to 0x00 for S/R communication

Module version 1.0.42

2020-02-21

ASCSOMEIPXF-283 Fixed known issue: Length field values get de-/serialized wrong on big endian platforms

Module version 1.0.41

2020-01-24

ASCXFRM-365 Fixed known issue: Variable Size Arrays are serialized to the wrong array type

Module version 1.0.40

2019-12-06



- Implemented major inspection source code findings
- ASCSOMEIPXF-907 Fixed known issue: Wrong deserialization of extensible structures and arrays

2019-11-08

ASCSOMEIPXF-964 Fixed known issue: External trigger event transformer leads to compile error within safe SomelpXf partition

Module version 1.0.38

2019-10-11

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.37

2019-05-17

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.36

2019-03-22

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.35

2019-02-15

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.34

2018-10-26

Added support for bitfields

Module version 1.0.33

2018-07-27



Improved support for configurable type of BufferLength

Module version 1.0.32

2018-06-22

Moved safety checker part from module to asc_SomelpXfCV

Module version 1.0.31

2018-05-25

- Implemented non-functional code improvements to fix Misra violations
- ASCSOMEIPXF-822 Fixed known issue: Compile error in generated SomeIpXf_Api_gen.h

Module version 1.0.30

2018-03-16

- ASCSOMEIPXF-781 Fixed known issue: Client/server deserializer without arguments silently ignores hard errors
- Improved support for configurable type of BufferLength

Module version 1.0.29

2018-02-16

ASCSOMEIPXF-765 Fixed known issue: Compile error for client/server sending transformer API with autonomous error response

Module version 1.0.28

2018-01-19

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.27

2017-12-15

- Implemented support for configurable type of BufferLength
- Added XfrmIsSafetyTransformer configuration parameter
- Improved support for configurable type of BufferLength



2017-09-22

- Switch from MISRA-C:2004 to MISRA-C:2012
- ▶ Replaced DET handling with defensive programming mechanism returning E SER GENERIC ERROR
- Modified initialization sequence
- Prepared SomelpXf for use in safety releases
- ASCSOMEIPXF-660 Fixed known issue: Missing memory section for array holding the process sequence

Module version 1.0.25

2017-07-28

Implemented usage of ApplicationDataType of (outermost) SwComponentType

Module version 1.0.24

2017-06-30

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.23

2017-06-02

ASCSOMEIPXF-600 Fixed known issue: No error message when length field exceeds buffer length of variable size array

Module version 1.0.22

2017-05-05

- ASCSOMEIPXF-560 Fixed known issue: Compilation error due to multiple definitions of identical configuration array size macros
- Added support for variable size array profile of type fully flexible
- ASCSOMEIPXF-561 Fixed known issue: Wrong ClientID and SessionID in client/server communication on big-endian platforms

Module version 1.0.21

2017-03-31



- Incorporated Bugzilla RfC 66764 in allowing usage of uint64 and sint64 data types.
- Incorporated Bugzilla RfC 68623: Insufficient specification of autonomous error response
- Incorporated Bugzilla RFC 69896: Execution of Transformer chain in case of unqueued communication when no data is available
- Incorporated Bugzilla RfC 72952: Adaptation of ApplicationErrors inconsistent
- Incorporated Bugzilla RfC 76926: Contradiction between SWS SomelpXf 00107 and constr 1108
- Removed and incorporated EB tresos AutoCore Generic 8 Transformer (SOME/IP) user's guide into EB tresos AutoCore Generic 8 Transformers documentation

2017-02-03

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.19

2017-01-05

Enhanced variable size array usage in allowing size indicator value 0

Module version 1.0.18

2016-12-02

Implemented handling of missing data parameters in SOME/IP transformer functions

Module version 1.0.17

2016-11-04

► ASCSOMEIPXF-431 Fixed known issue: Compile error on Big Endian platform for Client/Server communication

Module version 1.0.16

2016-10-07

- Incorporated Bugzilla RfC 71047: Determining the length of the length field for variable size arrays
- Implemented usage of ImplementationDataType of (outermost) SwComponentType



2016-09-09

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.14

2016-08-05

- Added support for memory partitioning of partitioned RTE
- ASCSOMEIPXF-311 Fixed known issue: Compilation error for a structure which holds a multidimensional array

Module version 1.0.13

2016-07-01

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.12

2016-05-25

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.11

2016-04-29

Module version 1.0.10

2016-04-01

Added support of length fields for structures and fix size arrays

Module version 1.0.9

2016-02-05

ASCSOMEIPXF-188 Fixed known issue: Erroneous value returned for client/server communication without arguments



ASCSOMEIPXF-199 Fixed known issue: Wrong interface version 0 provided

Module version 1.0.8

2016-01-15

- ASCSOMEIPXF-177 Fixed known issue: Compilation fails for client/server communication without operation argument
- Added support of ApplicationDataTypes
- Incorporated Bugzilla RfC 68085: Clarification issues regarding the modeling of Variable-Size Array Data Type
- Incorporated Bugzilla RfC 67799: Fire-and-forget methods without parameters

Module version 1.0.7

2015-11-06

- ► Changed parameter name XfrmTransformationBswModuleEntryRef to XfrmTransformerBswModuleEntryRef (see AUTOSAR RfC #68531)
- Added support for specification of XfrmVariableDataPrototypeInstanceRef (multiple receivers)

Module version 1.0.6

2015-10-09

Incorporated Bugzilla RfC 67586: SOME/IP Transformer does not support Message Type Notification

Module version 1.0.5

2015-09-18

- ▶ Incorporated Bugzilla RfC 68519: Rte_Cs_TransactionHandleType may have no members
- Incorporated Bugzilla RfC 68756: Clarification regarding the existence of the SOME/IP returnValue parameter when a server runnable has no application errors
- Implemented robust code generation by reporting a warning and ignoring problematic XfrmImplementationMappings

Module version 1.0.4

2015-06-19

Internal module improvement. This module version update does not affect module functionality



2015-04-24

- Added support of variable size arrays for basic data types
- Incorporated Bugzilla RfC 68035: Input parameters of scalar and enum types shall be passed by value
- Added support of client/server communication

Module version 1.0.2

2015-02-20

Provided missing memory sections to function declarations

Module version 1.0.1

2015-01-07

ASCSOMEIPXF-35 Fixed known issue: Erroneous serialization/deserialization of data elements following an array of structures

Module version 1.0.0

2014-10-02

Initial AUTOSAR 4.2 version

3.3.2.2. New features

Session Handling ID counter is used to set the correct Request ID in the SOME/IP header in case of Sender/Receiver communication where session handling is activated.

Session Handling ID counter is used to set the correct Request ID in the SOME/IP header in case of External Trigger communication where session handling is activated.

3.3.2.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

► This module provides no EB-specific enhancements.



3.3.2.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

Definition of Identifiers

Description:

The complete section 'Definition of Identifiers' and 'Reserved and special identifiers for SOME/IP and SOME/IP-SD is not supported.

Requirements:

 $SWS_SomelpXf_00001\ SWS_SomelpXf_00025\ SWS_SomelpXf_00002\ SWS_SomelpXf_00005\ SWS_SomelpXf_00006\ SWS_SomelpXf_00007\ SWS_SomelpXf_00009\ SWS_SomelpXf_00010\ SWS_SomelpXf_00011\ SWS_SomelpXf_00130\ SWS_SomelpXf_00131\ SWS_SomelpXf_00132\ SWS_SomelpXf_00134$

Strings of fixed length

Description:

The complete section 'Strings (fixed lengths)' is not supported

Requirements:

 $SWS_SomelpXf_00053 \ SWS_SomelpXf_00054 \ SWS_SomelpXf_00055 \ SWS_SomelpXf_00056 \ SWS_SomelpXf_00057 \ SWS_SomelpXf_00058 \ SWS_SomelpXf_00059 \ SWS_SomelpXf_00060 \ SWS_SomelpXf_00017 \ (partly)$

Optional Parameters

Description:

The section 'Optional Parameters' is not supported

Requirements:

SWS_SomelpXf_00076 SWS_SomelpXf_00076_Deser SWS_SomelpXf_00017 (partly)

Strings of dynamic length

Description:

The section 'Strings (dynamic length)' is not supported


Requirements:

SWS_SomelpXf_00076 SWS_SomelpXf_00076_Deser SWS_SomelpXf_00017 (partly)

NolnitVal Bitfields

Description:







Forward and backward compatibility of parameters, arrays and structures is not supported,

except extended structures and arrays of fix size according to Bugzilla RfC 67775.

Requirements:

SWS_SomeIpXf_00016 (partly) SWS_SomeIpXf_00017 (partly) SWS_Xfrm_00048 (partly)

Extended Production Errors

Description:

Extended production errors are not supported.

Requirements:

ECUC_Xfrm_00016 ECUC_Xfrm_00015 SWS_Xfrm_00070 SWS_Xfrm_00071

Error Handling

Description:

Even though a hard error is returned, the output buffer of the serializer transformer APIs (SWS_SomelpXf_-00138, SWS_Xfrm_00036, SWS_Xfrm_00038, SWS_Xfrm_00040) will be changed. This means that the serialized data is written to the output buffer during serialization. If the hard error occurs the buffer where the serialized data is written to, will not be used.

Rationale:

Only one buffer is used for the serialization process which leads to better performance.

Requirements:

SWS_Xfrm_00051

Request ID

Description:

Optional setting of the Request ID as mentioned in SWS_SomelpXf_00106 is not implemented. Instead the behavior described in SWS_SomelpXf_00024 is implemented. The Request ID is constructed of the Client ID and Session ID, which are chosen by the Rte and handed over to the SOME/IP transformer.

Requirements:

SWS_SomeIpXf_00106 (partly)

Application Error with value 0 (E_OK)

Description:



Requirement SWS_SomeIpXf_00115 states on error codes in the range of 0x20 - 0x5e to adapt the value of the application error in adding 0x1F. This holds for application errors in the range of 0x01- 0x3F. The handling of possible error value 0 (E_OK) is not specified by any requirement. The possible error value 0 (E_OK) is handled untouched, i.e. directly written to the return code without adding 0x1F.

Rationale:

Incorporated Bugzilla RfC 76926: Contradiction between SWS_SomelpXf_00107 and constr_1108.

Requirements:

SWS SomelpXf 00107 (partly)

Development Error Tracer is not supported

Description:

- ▶ The Development Error Tracer DET is not supported due to safety aspects.
- The SomelpXf module is maintained in two flavors. One at safety level according to ISO 26262 and another one at QM level. To keep this both close together, any handling by the DET module is removed. Instead it is handled by defensive programming techniques.

Rationale:

The function Det ReportError() is only specified and implemented at QM level, not at any ASIL level.

Requirements:

SWS_SomelpXf_00184, ECUC_Xfrm_00013_Conf

SomelpXf_Init() and SomelpXf_DeInit() do not exist

Description:

The API service SomelpXf_Init() and SomelpXf_DeInit() do not exist as part of the SomelpXf implementation.

Rationale:

The SomelpXf needs no initialization of global data. Even if the necessity of an initialization routine might be the case in future, there would be a specific routine for each partition in order to support multi-core systems.

Requirements:

SWS_SomelpXf_00181, SWS_SomelpXf_00182

Violation of VSMD rule Constr_3023



Description:

The attribute apiServicePrefix is mandatory for VSMDs derived from the CDD StMD. The attribute shall not be provided for VSMDs derived from any other StMDs. The rule is based on Constr_3023 from AUTOSAR_TPS_ECUConfiguration.pdf of 4.2.1 Release.

Effected node:

StMD-Node: /AUTOSAR/EcucDefs/Xfrm

Rationale:

The SomelpXf module violates the second part of the rule, but correctly, because SWS_SomelpXf_00185 requires the definition of apiServicePrefix attribute.

Requirements:

SWS_SomelpXf_00185

Violation of VSMD rule EcucSws_2038_2040_ASR41

Description:

If there is a SYMBOLIC-NAME-REFERENCE which points to another module, the rule EcucSws_2038_-2040_ASR41, which is based on requirements TPS_ECUC_02038 and TPS_ECUC_02040 from AUTOSAR_TPS_ECUConfiguration.pdf of 4.1 Release, always creates a violation.

Effected nodes:

- VSMD-Node: Xfrm/XfrmImplementationMapping/XfrmDemEventParameterRefs/XFRM_-E_MALFORMED_MESSAGE
- VSMD-Node: Xfrm/XfrmImplementationMapping/XfrmOsApplicationRef

Rationale:

Violation occurs due to an invalid behavior within the EB tresos Studio. No useful workaround available. Rule EcucSws_2038_2040_ASR41 shall be ignored.

Requirements:

ECUC_Xfrm_00016

3.3.2.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.



Limitation on Implementation Mapping

Description:

The short name of the implementation mapping has to be identical to the BswModuleEntry. I.e. the value of parameter XfrmImplementationMapping is the same as the referenced XfrmTransformerBswModuleEntryRef (or XfrmInvTransformerBswModuleEntryRef).

As a consequence, either the XfrmTransformerBswModuleEntryRef or the XfrmInvTransformerBswModuleEntryRef might be referenced, not both.

Additionally, the recommended optimization on the transformer chain can not be applied the way specified, since it is not possible to reference the same BswModuleEntry for different ImplementationMappings.

Rationale:

This avoids usage of an X-Path expression to extract data from the tresos DB.

Requirements

SWS_Xfrm_00054, SWS_Xfrm_00101 (Incorporated by Bugzilla RfC 67799), SWS_Xfrm_00055 and SWS_Xfrm_00056

No support of extensible arrays containing structures

Description:

Extensible arrays (which are fix size arrays with length fields, i.e. parameter SOMEIPTransformationISignalProps.sizeOfArrayLengthFields is configured with a value greater than 0) containing structures are not supported. This holds for standard structures as well as extensible structures.

No support of extensible arrays or extensible structures containing variable size arrays

Description:

Extensible arrays (fix size arrays with length fields) containing a variable size array are not supported. This holds for each variable size array profile type.

Extensible structures (structures with length fields) containing a variable size array are not supported. This holds for each variable size array profile type.

Restriction on dimension of extensible arrays

Description:

The number of dimensions for an extensible array (fix size array with length fields) is limited to 5.

Restriction on nested level of extensible structures

Description:



The maximum number of nested extensible structures (structure with length fields) is limited to 5.

No support of standard arrays (fix size arrays without length fields) containing variable size arrays

Description:

Standard arrays (fix size arrays without length fields) containing variable size arrays as elements are not supported. This holds for each variable size array profile type.

Restrictions on variable size arrays

Description:

The payload shall not consist of or contain any extensible array (with length fields) at any nested level.

The payload shall not consist of or contain any extensible structure (with length fields) at any nested level.

The payload of the inner dimension shall not contain a standard array (without length fields).

The payload of the inner dimension shall not contain a variable size array. Nested standard structures (without length fields) are possible when holding only basic data types.

The number of dimensions for an variable size array is limited to 5.

Restrictions on Bitfields

Description:

Only standard structures (without length fields) can hold Bitfields as members.

Bitfields not supported on big endian platforms (CPU_BYTE_ORDER configured with HIGH_BYTE_-FIRST)

Restriction on the maximum depth of nested fixed size arrays of structures (without length fields)

Description:

The maximum number of nested fixed size arrays without length fields of structures without length fields is limited to 10.

No support of different signals using the same data type but different length fields size

Description:

Configurations where different signals serialize/de-serialize the same data type but have configured different values for parameter SizeOfArrayLengthFields are not supported.

Configurations where different signals serialize/de-serialize the same data type but have configured different values for parameter SizeOfStructLengthFields are not supported.



3.3.2.6. Open-source software

SomelpXf does not use open-source software.

3.3.3. Xfrm module release notes

► AUTOSAR R4.0 Rev 3

AUTOSAR SWS document version: 0.0.0

Module version: 1.0.30.B403451

Supplier: Elektrobit Automotive GmbH

3.3.3.1. Change log

This chapter lists the changes between different versions.

Module version 1.0.30

2020-11-06

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.29

2020-06-19

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.28

2020-01-24

ASCXFRM-365 Fixed known issue: Variable Size Arrays are serialized to the wrong array type

Module version 1.0.27

2019-10-11



Internal module improvement. This module version update does not affect module functionality

Module version 1.0.26

2019-03-22

Enhanced support of parameter disableEndToEndCheck to single receivers

Module version 1.0.25

2019-02-15

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.24

2018-10-26

Prevent transformers from generating invalid BSWMD.arxml when configuration of XfrmImplementation-Mapping is empty

Module version 1.0.23

2018-07-27

▶ Align memory mapping with safety options according to AUTOSAR 4.3 MetaModel

Module version 1.0.22

2018-06-22

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.21

2018-05-25

ASCXFRM-309 Fixed known issue: Compile error in generated SomelpXf_Api_gen.h

Module version 1.0.20

2018-03-16



Updated the compatibility check interface

Module version 1.0.19

2017-12-15

- Implemented support for configurable type of BufferLength
- Added XfrmIsSafetyTransformer configuration parameter
- Updated the supported datatypes to AUTOSAR release 4.2.1

Module version 1.0.18

2017-09-22

Add safe transformer condition check

Module version 1.0.17

2017-07-28

Implemented usage of ApplicationDataType of (outermost) SwComponentType

Module version 1.0.16

2017-06-02

Added support for Safe ComXf

Module version 1.0.15

2017-05-05

- Improved gathering of computational methods
- Added support for variable size array profile of type fully flexible

Module version 1.0.14

2017-03-31

- Incorporated Bugzilla RfC 69896: Execution of Transformer chain in case of unqueued communication when no data is available
- Incorporated Bugzilla RfC 68623: Insufficient specification of autonomous error response



Module version 1.0.13

2017-03-03

ASCXFRM-150 Fixed known issue: Compile error occurs when ImplementationDataType of the outermost CompositionSwComponent differs from atomic software component for client/server communication

Module version 1.0.12

2017-02-03

► Enable Xfrm users to gather computational methods from the abstracted data type model by providing a reference to SwDataDefProps

Module version 1.0.11

2017-01-05

Internal module improvement. This module version update does not affect module functionality

Module version 1.0.10

2016-12-02

ASCXFRM-144 Fixed known issue: Compile error occurs when ImplementationDataType of the outermost CompositionSwComponent differs from atomic software component for sender/receiver communication

Module version 1.0.9

2016-11-04

Incorporated Bugzilla RfC 70485: Missing configuration parameter XfrmVersionInfoApi

Module version 1.0.8

2016-10-07

Implemented usage of ImplementationDataType of (outermost) SwComponentType

Module version 1.0.7

2016-09-09



Internal module improvement. This module version update does not affect module functionality

Module version 1.0.6

2016-07-01

ASCXFRM-82 Fixed known issue: Generic SwBaseTypes when referenced by ImplementationDataType lead to incorrect generated configuration items

Module version 1.0.5

2016-05-25

Provided error message for usage of unsupported basic data types

Module version 1.0.4

2016-04-29

Addded support for generic SwBaseType

Module version 1.0.3

2016-04-01

Incorporated Bugzilla RfC 67775: SOME/IP Transformer uses wrong length of length field (extensible fixed size arrays)

Module version 1.0.2

2016-02-05

- Addded support of ApplicationDataType
- Incorporated Bugzilla RfC 68085: Clarification issues regarding the modeling of Variable-Size Array Data Type

Module version 1.0.1

2015-11-06

Changed parameter name XfrmTransformationBswModuleEntryRef to XfrmTransformerBswModuleEntryRef (see AUTOSAR RfC #68531)



Added support for specification of XfrmVariableDataPrototypeInstanceRef (multiple receivers)

Module version 1.0.0

2015-10-09

Initial release of Transformer library

3.3.3.2. New features

No new features have been added since the last release.

3.3.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

► This module provides no EB-specific enhancements.

3.3.3.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

For this module no deviations are known.

3.3.3.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

For this module no limitations are known.

3.3.3.6. Open-source software

Xfrm does not use open-source software.



4. ACG8 Transformers user's guide

4.1. Overview

This user's guide describes the concepts and the configuration of the modules:

- ComIpXf COM Based Transformer
- SomeIpXf SOME/IP Transformer

To understand the basic concepts of the transformer modules, see Section 4.2, "Background information".

To use data transformation in your project, see Section 4.3, "Using data transformation support".

For instructions how to configure the modules, see:

- Section 4.4, "ComXf module user's guide"
- Section 4.5, "SomelpXf module user's guide"

4.2. Background information

This chapter enables you to understand the basic concepts of the AUTOSAR transformer modules. If you are familiar with these concepts already, you may want to skip this chapter and proceed to the instruction chapters.

4.2.1. Functional overview

This section provides a brief overview of the data transformation concept as defined by AUTOSAR. You can find detailed information in the AUTOSAR 4.2 documents.

Data transformation is a new communication paradigm in AUTOSAR 4.2 that provides the following:

- Efficient communication of large data elements of complex types.
- Simplified configuration of additional safety or security mechanisms.

The basic idea is that, in the transmission path, a data element is first converted to a byte array. Then, you can use additional transformer modules to process the byte array to add safety or security functionality. In the



reception path inverse functions are called in reverse order so that first safety checks or security transformations are applied and finally the byte array is transformed back to the data element.

In this context, the first transformer on the transmission path is called a *serializing* transformer, as it *serializes* a data element to a byte array or *de-serializes* the byte array back to a data element. Further transformers just work on the byte array, i.e. have a byte array as input and as output. Here, transformers can be of the following classes:

- A *safety* transformer ensures that the input byte array is not unintentionally modified during transmission. To do this, a CRC value is appended to the original byte array.
- A security transformer ensures that the data is not intentionally modified by authenticating and encrypting the transmitted data. Additionally the data may be encrypted to protect against eavesdropping.
- A *custom* transformer is used for any other functionality.

The data transformation scenario is highly configurable to your needs and allows these options:

Byte-wise data serialization according to the scalable service-oriented middleware over IP (SOME/IP) specification or data serialization according to the Com module configuration.

Byte-wise data serialization according to SOME/IP means that, during data serialization, each single data element of the complex data type is written to a specific byte offset in the serialized data array and thus starts at a byte boundary. This kind of serialization is implemented by the SomeIpXf module. Bit shifting and packing is not required, making this kind of transformation fast. However, this results in more data and might not necessarily be compatible with other ECUs on the network. If the SOME/IP transformer is used, the data transferred can only be received by other ECUs that also use SOME/IP transformation. This is incompatible with older ECUs that use the Com module for data transfer or ECUs that use the ComXf module for data serialization.

Serialization according to the Com module configuration means that the complex data element is packed into the byte array as configured in the Com module, i.e. based on the configured bit offset and length of each signal. The effect is that the serialized data element has the same memory layout as it would have without serialization and if it were then transmitted using the Com module. This results in identical representation of the data on the network. This kind of serialization is implemented by the ComXf module.

Transformer chains and transformer fan-out

If more than one transformer is used, i.e. if additional transformers are attached to the serializing transformer, this is called a *transformer chain*. The output of one transformer is then provided as input to the next transformer.

The first transformer in the chain is a serializing transformer that converts the data element to a byte array. Other transformers work on the serialized data stream and produce a serialized data stream with either changed data, e.g. in the case of a security transformer. Or, with appended data, e.g. in the case of a safety transformer. When you use transformer chains there is room for optimization if data is sent to more than one recipient (fan-out). In this case the Rte ensures that transformer functions are called if necessary.



NOTE

Data transformation chains in the Rte



For more information on data transformation chains in the Rte module, see the EB tresos AutoCore Generic 8 RTE product documentation.

Data serialization together with end-to-end protection by a safety transformer

You can use both serializing transformers (ComXf and SomeIpXf) together with an end-to-end protection transformer (E2EXf). This means that data is first serialized, then the end-to-end checksum is calculated and appended to the serialized data stream. From a software component's point of view there is no difference between sending protected and sending unprotected data. It suffices to model the data exchange accordingly and include the E2EXf module in the transformer chain to have the data end-to-end protected. Thus the software component can be relocated among ECUs without any modifications in the software component's implementation.

Buffer handling

The system description can model the buffer consumption of a transformer as *out-of-place* or *in-place*. Out-of-place means that the input pointer to the transformer points to another memory location than the output pointer and the transformer may safely write to the output pointer without overwriting the input data. This case requires more memory but is required for some types of transformers. The serializing transformer for example is always an out-of-place transformer. In-place buffer handling means that the input and the output pointer of the transformer call point to the same memory location. It depends on the type of transformer if this type of buffer handling is possible. For example for some profiles of end-to-end protection the original data is not changed and just the checksum is appended, so this is possible.



4.2.2. Data transformation use cases




Figure 4.1. Use cases of data transmission

This section explains the use cases and the benefits of data transformation. The following use cases are possible:

► The traditional use case: SWC - Rte - Com

This is the traditional use case of data transmission without any data transformation and is just mentioned for comparison. The Rte updates each signal of the complex data element and then requests transmission as a signal group. Updating each signal involves bit shifting and packing for each member of the data element.

> SWC - Rte - SomeIpXf - Com

In this use case the <code>SomeIpXf</code> serializes a complex data element to a byte array. This byte array is then transmitted via the <code>Com</code> module. This is particularly efficient with respect to execution time for large and complex data elements since the <code>SomeIpXf</code> simply writes each element of the data type to a separate byte and there is no need for bit packing and shifting. Using the <code>Com</code> module in this case has the advantage that other <code>Com</code> features can still be used, e.g. deadline monitoring. There is no additional ROM consumption as would be the case if the <code>LdCom</code> module and the <code>Com</code> module were used in parallel.

> SWC - Rte - SomeIpXf - LdCom

Similarly to above the <code>SomeIpXf</code> serializes the data to a byte array but this is then transmitted via the <code>LdCom</code> module. This reduces execution time and in addition may save ROM if the <code>Com</code> module is not required at all, since the <code>LdCom</code> provides only a minimum functionality compared to the <code>Com</code> module.



SWC - Rte - ComXf - Com

In this use case the <code>ComXf</code> serializes a complex data element to a byte array, which is then transmitted via the <code>Com</code> module. This use case is still more efficient than the transmission of the data element as a signal group via the <code>Com</code> module. However, as the <code>ComXf</code> serializes according to the <code>Com</code> configuration and does similar bit packing and shifting, it has a higher execution time than the <code>SomeIpXf</code>. One important benefit of this use case is that data on the network is identical to the traditional signal-based case and thus ECUs in this use case can be added to existing networks.

SWC - Rte - SomeIpXf/ComXf - E2EXf - Com/LdCom

In this use case a complex data element is first serialized using <code>SomeIpXf</code> or <code>ComXf</code>, then the serialized byte array is end-to-end protected and a sequence counter and checksum are appended to the byte array. The byte array is then transmitted over <code>Com</code> or <code>LdCom</code>. Besides the advantages mentioned above, this use case also has an important benefit regarding the configuration. The system description already models the data serialization and the end-to-end protection and thus no additional configuration effort is required to have end-to-end protected communication. No changes in the SWC implementation are required when they are relocated among ECUs.

4.2.3. AUTOSAR modules for data transformation

This section lists the AUTOSAR modules that are involved in data transformation and briefly explains their main functionality as far as it is relevant for data transformation. You can find detailed information in the AUTOSAR software specification documents of AUTOSAR 4.2. For more information on the following AUTOSAR modules, see the respective product-specific documentation.

Rte

The Rte implements a mapping of complex data elements to a byte array by data transformation. Core functionality is provided by a transformer dispatcher. This dispatcher calls the transformer functions of the transformer chain that is associated with the mapping in the order specified in the system description. The transformed byte array is then passed to Com or LdCom module for transmission. In the reception path a byte array is received and indicated to the Rte. The Rte then uses the transformer dispatcher to execute the transformer chain in reverse order to retrieve the data element received.

SomeIpXf

The <code>SomeIpXf</code> transformer is a serializing transformer which transforms a data element to a byte array according to the SOME/IP specification. It provides APIs for serialization (in the transmission path) and de-serialization (in the reception path).

ComXf



The ComXf transformer is a serializing transformer which transforms a data element to a byte array according to the Com module configuration. It provides APIs for serialization (in the transmission path) and de-serialization (in the reception path).

E2EXf and other non-serializing transformer modules

You can add safety, security, and custom transformers as successors to a serializing transformer for specific transformation tasks. They provide APIs for transformation and inverse transformation of one byte array to another byte array calculating end-to-end checksums or message authentication codes.

Com

The Com module provides API functions:

- Com_SendDynSignalArray() and Com_ReceiveDynSignalArray() to transmit or receive data that was serialized using the ComXf module.
- Com_SendDynSignal() and Com_ReceiveDynSignal() to transmit or receive data that was serialized using the SomeIpXf module.

Additionally, you can enable other Com functionality, e.g. dead line monitoring.

LdCom

The LdCom module provides API functions for sending and receiving byte arrays:

- LdCom_IfTransmit(), LdCom_RxIndication(), LdCom_TriggerTransmit(), and Ld-Com_TxConfirmation() to transmit or receive data that fits into a single frame of the underlying network, i.e. IF-API.
- LdCom_StartOfReception(), LdCom_TpTransmit(), LdCom_CopyRxData(), LdCom_Copy-TxData(), LdCom_TpTxConfirmation(), and LdCom_TpRxIndication() to transmit or receive data that does not fit into a single frame of the underlying network and thus needs segmentation, i.e. TP-API.

It has no function other than to transfer a byte array signal into a PDU. If no other functionality is required, then using LdCom is more efficient and requires less memory than using the Com module.

4.3. Using data transformation support

This section describes the steps to use data transformation in your project.

4.3.1. Adding data transformation to the system description

To enable data transformation, add the following elements to the system description:



▶ Definitions of DATA-TRANSFORMATION-SET

DATA-TRANSFORMATION-SET describes a transformer chain. A transformer chain consists of one or several transformers where each transformer has a specific TRANSFORMATION-TECHNOLOGY which models transformer properties such as type of transformation and buffer requirements.

Data mappings between complex data elements and byte array signals

In the data transformation use case, a complex data element shall be transmitted as a byte array. Therefore, a mapping between the complex data element and a byte array signal has to be modelled. Such a mapping is only possible for signals referencing a DATA-TRANSFORMATION-SET.

4.3.2. Configuring data transformation modules using EB tresos Studio

Follow these steps to configure data transformation using EB tresos Studio:

Add the modules you want to configure to your project.

In particular add the Rte, a serializing transformer (e.g. SomeIpXf) and either Com or LdCom.

Import the system description and run the Import ECU Configuration unattended wizard.

Note that the **Import ECU Configuration** unattended wizard uses a complex rule set to determine if a signal is to be created in the <code>Com</code> module or the <code>LdCom</code> module. The <code>LdCom</code> is only used for a particular signal if this module is available and no other functionality is modeled in the system description for that signal that would require the <code>Com</code> module.

- ► Configure the serializing transformer, e.g. the SomeIpXf module:
 - Add a container XfrmImplementationMapping for each transformer and signal, i.e. configure this mapping for each transformer that is applied to a signal. For example, if two different signals are first serialized by SomeIpXf, then transformed by E2EXf, they need four mappings. You must map both signals to the SomeIpXf and also to the E2EXf.
 - ► Enable the reference XfrmTransformationBswModuleEntry for the transmission path or Xfr-mInvTransformationBswModuleEntry for the reception path. You must enable exactly one reference.
 - ▶ Generate the BSWMD. You can only reference the transformer functions after the BSWMD is generated.
 - Configure the reference XfrmTransformationBswModuleEntry for the transmission path or Xfr-mInvTransformationBswModuleEntry for the reception path. Choose the correct function references. Note that the name of the XfrmImplementationMapping container also determines the name of the generated function.



Different mappings might refer to the same BSW module definition. Due to the fact that each mapping generates its own BSW module definition entry, some entries are then unused.

- Configure the XfrmTechnology and reference the correct transformer technology from the system description.
- Configure the XfrmSignal and reference the correct signal from the system description.
- If the respective signal is used by more than one receiving software component, configure the XfrmVariableDataPrototypeInstanceRef as well in case dedicated transformer chains shall be used by the different receiving software components.

The above steps are automated by the Calculate Service Needs unattended wizard for the SomeIpXf/ComXf XfrmImplementationMapping.




Figure 4.2. Configuring SomeIpXf

4.4. ComXf module user's guide

4.4.1. Overview

This user's guide describes the <code>ComXf</code> module. From this user's guide you learn about the basic functionality of the <code>ComXf</code>. You also learn which related modules are necessary to configure the <code>ComXf</code> module. The <code>ComXf</code> module reference provides further information on configuring the <code>ComXf</code> itself.

Note that this user's guide is intended for readers who have good knowledge of AUTOSAR and about the purpose of the ComXf. The information provided here helps you to integrate the ComXf in your AUTOSAR project.

Section 4.4.2, "Background information" provides an overview of the basic functionality of the ComXf.



- Section 4.4.3, "Configuring ComXf" provides information on related modules that are needed in order to configure the ComXf.
- Section Section 4.4.4, "ComXf integration notes" provides notes for the integration of the ComXf module into your project.
- For details on configuring the ComXf itself, see the parameter descriptions provided in the ComXf module reference Chapter 5, "ACG8 Transformers module references".

4.4.2. Background information

The general concept about data transformation and large data transfer is described in <u>Section 4.2, "Background information"</u>.

The ComXf is a serializing transformer that implements data serialization according to the ComXf specification. For more information, see [1].

It is used together with the modules Rte and Com to implement data serialization according to a fixed communication matrix with packed data representations (ComSignalGroups) for the following communication paradigm:

Sender/receiver communication

ComXf provides APIs to serialize and descrialize complex data elements to byte arrays for sender/receiver communication. Its API functions are called by the Rte.

4.4.3. Configuring ComXf

To configure the <code>ComXf</code> module, add the module to your project using EB tresos Studio. Parameter descriptions are provided to guide the configuration. You find these in the module references section of this document. You also find these in the parameter description in EB tresos Studio.

The ComXf transformer has a mechanism to generate transformations with QM classification. The rationale is to allow the use of an enhanced non safety certified feature set, e.g. the use of the Com module. The optional parameter XfrmIsSafetyTransformer determines if a related transformation, which is represented by XfrmImplementationMapping, shall be used for data with safety or QM classification.

If a transformation is used to transform data with safety classification, all of the following conditions shall apply:

- XfrmIsSafetyTransformer shall be enabled AND
- XfrmIsSafetyTransformer shall be set to true

If a transformation is used to transform data without safety classification, any value is allowed.



NOTE

Significance of XfrmIsSafetyTransformer parameter



If the XfrmIsSafetyTransformer parameter is disabled, the generator determines the classification of a transformation by its own heuristic. The transformation gets a safety classification if all of the following conditions apply:

- ► The E2EXf module is part of the (de-)transformer chain
- ► The disableEndToEndCheck attribute in the EndToEndTransformation-ComSpecProps of the SystemTemplate is set to false.

In any other case, the transformation gets a QM classification.

NOTE

Consistency of XfrmIsSafetyTransformer



The XfrmIsSafetyTransformer parameter shall have the same value for all transformations of the same partition. If this is not the case, all transformations of the partition are promoted to safety classification.

To use the ComXf module, you must configure additional modules as outlined below:

- ► ACG8 RTE: The ComXf module provides API functions that are called by the Rte module in EB tresos AutoCore Generic 8 RTE.
- ACG8 COM Services: The Rte communicates the serialized data resulting from the ComXf module to the Com module, which is part of EB tresos AutoCore Generic 8 COM Services.

4.4.4. ComXf integration notes

You find module-specific information about exclusive areas, production errors, and memory mapping in the module-specific integration notes in the module references chapter of this document. See <u>Chapter 5</u>, "ACG8 <u>Transformers module references</u>" subsection Integration notes in each module.

4.5. SomelpXf module user's guide

4.5.1. Overview

This user's guide describes the <code>SomeIpXf</code> module. From this user's guide you learn about the basic functionality of the <code>SomeIpXf</code>. You also learn which related modules are necessary to configure the <code>SomeIpXf</code> module. The <code>SomeIpXf</code> module reference provides further information on configuring the <code>SomeIpXf</code> itself.



Note that this user's guide is intended for readers who have good knowledge of AUTOSAR and about the purpose of the SomelpXf. The information provided here helps you to integrate the SomelpXf in your AUTOSAR project.

- Section 4.5.2, "Background information" provides an overview of the basic functionality of the SomeIpXf.
- Section 4.5.3, "Configuring SomelpXf" provides information on related modules that are needed in order to configure the SomelpXf.
- Section Section 4.5.4, "SomeIpXf integration notes" provides notes for the integration of the SomeIpXf module into your project.
- For details on configuring the SomeIpXf itself, see the parameter descriptions provided in the SomeIpXf module reference Chapter 5, "ACG8 Transformers module references".

4.5.2. Background information

The general concept about data transformation and large data transfer is described in <u>Section 4.2, "Background information"</u>.

The SomeIpXf is a serializing transformer that implements data serialization according to the SOME/IP specification. For more information, see [1].

It is used together with the modules Rte and LdCom to enable data transformation for the following communication paradigms:

- Sender/receiver communication
 - SomeIpXf provides APIs to serialize and deserialize complex data elements to byte arrays for sender/receiver communication. Its API functions are called by the Rte.
- Client/server communication
 - Some IpXf provides APIs to serialize and descrialize complex data elements to byte arrays for client/server communication. Its API functions are called by the Rte.

4.5.3. Configuring SomelpXf

To configure the <code>SomeIpXf</code> module, add the module to your project using EB tresos Studio. Parameter descriptions are provided to guide the configuration. You find these in the module references section of this document. You also find these in the parameter description in EB tresos Studio.

The SomeIpXf transformer has a mechanism to generate transformations with QM classification. The rationale is to allow the use of an enhanced non safety certified feature set, e.g. the support of advanced data types. The



optional XfrmIsSafetyTransformer parameter determines if a related transformation, which is represented by XfrmImplementationMapping, shall be used for data with safety or QM classification.

If a transformation is used to transform data with safety classification, all of the following conditions shall apply:

- XfrmIsSafetyTransformer shall be enabled AND
- XfrmIsSafetyTransformer shall be set to true

If a transformation is used to transform data without safety classification, any value is allowed.

NOTE

Significance of XfrmIsSafetyTransformer parameter



If the XfrmIsSafetyTransformer parameter is disabled, the generator determines the classification of a transformation by its own heuristic. The transformation gets a safety classification if all of the following conditions apply:

- ► The E2EXf module is part of the (de-)transformer chain
- ► The disableEndToEndCheck attribute in the EndToEndTransformation—ComSpecProps of the SystemTemplate is set to false.

In any other case, the transformation gets a QM classification.

NOTE

Consistency of XfrmIsSafetyTransformer



The XfrmIsSafetyTransformer parameter shall have the same value for all transformations of the same partition. If this is not the case, all transformations of the partition are promoted to safety classification.

To use the SomeIpXf module, you must configure additional modules as outlined below:

- ► ACG8 RTE: The SomeIpXf module provides API functions called from the Rte module in EB tresos AutoCore Generic 8 RTE.
- EB tresos AutoCore Generic 8 LDCOM: The Rte communicates the serialized data resulting from the SomeIpXf module to the LdCom module, which is part of EB tresos AutoCore Generic 8 LDCOM.

4.5.4. SomeIpXf integration notes

You find module-specific information about exclusive areas, production errors and memory mapping in the module-specific integration notes. You find the module-specific integration notes in the module references chapter of this document. See Chapter 5, "ACG8 Transformers module references" sub-section Integration notes in each module.



5. ACG8 Transformers module references

5.1. Overview

This chapter provides module references for the ACG8 Transformers product modules. These include a detailed description of all configuration parameters. Furthermore this chapter lists the application programming interface with all data types, constants and functions.

The content of the sections is sorted alphabetically according the EB tresos AutoCore Generic module names.

For further information on the functional behavior of these modules, refer to the chapter ACG8 Transformers user's guide.

5.1.1. Notation in EB module references

EB notation may differ from the AUTOSAR standard notation in the software specification documents (SWS). This section describes the notation of *default value* and *range* fields in the EB module references.

5.1.1.1. Default value of configuration parameters

If there is no default value specified for a parameter, the default value field is omitted to prevent ambiguity with parameters that have — as default values.

Example: The parameter BswMCompuConstText of the BswM module of EB tresos AutoCore Generic 8 Mode Management has no default value field, therefore it is omitted.

5.1.1.2. Range information of configuration parameters

The range of a configuration parameter contains an upper and a lower boundary. However, in special cases the range of allowed values can be computed by means of an XPath function that is evaluated at configuration time. An XPath function can either be a standard <code>xpath:<function>()</code> or a custom <code>cxpath:<function>()</code> function. The range of a configuration parameter may be computed based on other configuration parameters that are referenced from the XPath function. For more information on custom XPath functions, see section <code>Custom XPath Functions API</code> of the EB tresos Studio developer's guide.

Example: The parameter BswMCompuConstText of the BswM module of EB tresos AutoCore Generic 8 Mode Management has the custom XPath function <code>cxpath:getCompuMethodsVT()</code> in the range field which provides the allowed values.



5.2. ComXf

5.2.1. Configuration parameters

Containers included		
Container name	Multiplicity	Description
CommonPublishedInforma- tion	11	Label: Common Published Information Common container, aggregated by all modules. It contains published information about vendor and versions.
PublishedInformation	11	Label: EB Published Information Additional published parameters not covered by Common-PublishedInformation container.
XfrmGeneral	11	Contains the general configuration parameters of the module.
XfrmImplementationMapping	1n	For each transformer (TransformationTechnology) in a transformer chain (DataTransformation) which is applied to an ISignal it is necessary to specify the BswModuleEntry which implements it. This is the container to hold these mappings.

Parameters included	
Parameter name	Multiplicity
IMPLEMENTATION_CONFIG_VARIANT	11

Parameter Name	IMPLEMENTATION_CONFIG_VARIANT
Label	Config Variant
Multiplicity	11
Туре	ENUMERATION
Default value	VariantPreCompile
Range	VariantPreCompile

5.2.1.1. CommonPublishedInformation

Parameters included	
Parameter name	Multiplicity



Parameters included	
ArMajorVersion	11
ArMinorVersion	11
ArPatchVersion	11
SwMajorVersion	11
SwMinorVersion	11
SwPatchVersion	11
ModuleId	11
Vendorld	11
Release	11

Parameter Name	ArMajorVersion
Label	AUTOSAR Major Version
Description	Major version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	4
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	ArMinorVersion
Label	AUTOSAR Minor Version
Description	Minor version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	2
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	ArPatchVersion
Label	AUTOSAR Patch Version
Description	Patch level version number of AUTOSAR specification on which the appropriate implementation is based on.



Multiplicity	11
Туре	INTEGER_LABEL
Default value	1
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwMajorVersion
Label	Software Major Version
Description	Major version number of the vendor specific implementation of the module.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	1
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwMinorVersion
Label	Software Minor Version
Description	Minor version number of the vendor specific implementation of the module. The numbering is vendor specific.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	0
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwPatchVersion
Label	Software Patch Version
Description	Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	35
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH



Parameter Name	Moduleld	
Label	Numeric Module ID	
Description	Module ID of this module from Module List	
Multiplicity	11	
Туре	INTEGER_LABEL	
Default value	175	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	Vendorld
Label	Vendor ID
Description	Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list
Multiplicity	11
Туре	INTEGER_LABEL
Default value	1
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	Release
Label	Release Information
Multiplicity	11
Туре	STRING_LABEL
Default value	
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

5.2.1.2. PublishedInformation

Parameters included	
Parameter name	Multiplicity
PbcfgMSupport	11

Parameter Name	PbcfgMSupport



Label	PbcfgM support
Description	Specifies whether or not the ComXf can use the PbcfgM module for post-build support.
Multiplicity	11
Туре	BOOLEAN
Default value	false
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

5.2.1.3. XfrmGeneral

Parameters included		
Parameter name	Multiplicity	
XfrmDevErrorDetect	11	
XfrmBufferLengthType	11	
XfrmVersionInfoApi	11	

Parameter Name	XfrmDevErrorDetect	
Description	Switches the Development Error Detection and Notification ON or OFF.	
	► TRUE: Development Error Detection mechanism is enabled (switched on).	
	FALSE: Development Error Detection mechanism is disabled (switched off).	
Multiplicity	11	
Туре	BOOLEAN	
Default value	true	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	XfrmBufferLengthType	
Description	Specifies the data type of parameter BufferLength for transformer APIs.	
Multiplicity	11	
Туре	ENUMERATION	
Default value	UINT16	
Range	UINT16	



	UINT32	
Configuration class	VariantPreCompile: VariantPreCompile	
Origin	Elektrobit Automotive GmbH	

Parameter Name	XfrmVersionInfoApi	
Description	Activate/Deactivates the version information API.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.4. XfrmImplementationMapping

Containers included		
Container name	Multiplicity	Description
XfrmVariableDataPrototypeIn- stanceRef	11	Instance reference to a VariableDataPrototype in case a dedicated transformer BswModuleEntry is required per Variable-DataPrototype access.
XfrmDemEventParameter- Refs	11	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus API in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameters DemEventId value. The standardized errors are provided in the container and can be extended by vendor specific error references.
<u>XfrmSignal</u>	11	Reference to the signal in the system description that transports the transformed data.

Parameters included		
Parameter name	Multiplicity	
XfrmTransformerBswModuleEntryRef	01	
XfrmInvTransformerBswModuleEntryRef	01	
XfrmTransformationTechnologyRef	11	
<u>XfrmIsSafetyTransformer</u>	01	



Parameters included	
XfrmOsApplicationRef	01

Parameter Name	XfrmTransformerBswModuleEntryRef	
Description	Reference to the BswModuleEntry which implements the referenced transformer on the sending/calling side.	
Multiplicity	01	
Туре	FOREIGN-REFERENCE	
Configuration class	PreCompile: VariantPreCompile	
Origin	Elektrobit Automotive GmbH	

Parameter Name	XfrmInvTransformerBswModuleEntryRef	
Description	Reference to the BswModuleEntry which implements the referenced inverse transformer on the receiving/called side.	
Multiplicity	01	
Туре	FOREIGN-REFERENCE	
Configuration class	PreCompile: VariantPreCompile	
Origin	AUTOSAR_ECUC	

Parameter Name	XfrmTransformationTechnologyRef	
Description	Reference to the TransformationTechnology in the DataTransformation of the system description for which the implementation (BswModuleEntry) shall be mapped.	
Multiplicity	11	
Туре	FOREIGN-REFERENCE	
Configuration class	VariantPreCompile: VariantPreCompile	
Origin	AUTOSAR_ECUC	

Parameter Name	XfrmIsSafetyTransformer	
Description	Specifies if the Transformer shall be considered as a safety Transformer.	
Multiplicity	01	
Туре	BOOLEAN	
Default value	false	
Configuration class	PreCompile: VariantPreCompile	
Origin	Elektrobit Automotive GmbH	



Parameter Name	XfrmOsApplicationRef	
Description	Reference to an Os application to which the BSW belongs. Enabled: Maps global variables of transformer or inverted transformer function to dedicated memory partition.	
	Disabled: No dedicated memory partition assigned.	
Multiplicity	01	
Туре	REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

${\bf 5.2.1.5.}\ X frm Variable Data Prototype Instance Ref$

Parameters included		
Parameter name Multiplicity		
TARGET	11	
CONTEXT	22	

Parameter Name	TARGET	
Description	Target of the instance reference to a VariableDataPrototype.	
	The context of the instance reference is given by the list of Context References (CONTEXT) below.	
Multiplicity	11	
Туре	REFERENCE	
Configuration class	VariantPreCompile: VariantPreCompile	
Origin	AUTOSAR_ECUC	

Parameter Name	CONTEXT
Description	List of ordered context references of the instance reference to: 1. SwComponentPrototype 2. PortPrototype
	The target of the instance reference is given with the VariableDataPrototype reference (TARGET) above.
Multiplicity	22



Туре	REFERENCE	
Range	SW-COMPONENT-PROTOTYPE	
	PORT-PROTOTYPE*	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.6. XfrmDemEventParameterRefs

Parameters included		
Parameter name	Multiplicity	
XFRM_E_MALFORMED_MESSAGE	01	

Parameter Name	XFRM_E_MALFORMED_MESSAGE	
Description	The functionality related to this parameter is not supported by the current implementation. Reference to configured DEM event to report if malformed messages were received by the transformer. Reference to configured DEM event to report if malformed messages were received by the transformer.	
Multiplicity	01	
Туре	SYMBOLIC-NAME-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.7. XfrmSignal

Containers included		
Container name	Multiplicity	Description
XfrmSignalChoice	11	Choice whether an ISignal or an ISignalGroup shall be refer-
		enced.

5.2.1.8. XfrmSignalChoice

Containers included		
Container name	Multiplicity	Description



Containers included		
<u>XfrmlSignalGroupRefChoice</u>	11	Reference to the ISignalGroup in the system description that transports the transformed data.
<u>XfrmlSignalRefChoice</u>	11	Reference to the ISignal in the system description that transports the transformed data.

5.2.1.9. XfrmlSignalGroupRefChoice

Parameters included	
Parameter name	Multiplicity
XfrmlSignalGroupRef	11

Parameter Name	XfrmlSignalGroupRef	
Description	Reference to the ISignalGroup in the system description that transports the transformed data.	
Multiplicity	11	
Туре	FOREIGN-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.10. XfrmlSignalRefChoice

Parameters included	
Parameter name	Multiplicity
XfrmlSignalRef	11

Parameter Name	XfrmlSignalRef	
Description	Reference to the ISignal in the system description that transports the transformed data.	
Multiplicity	11	
Туре	FOREIGN-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	



5.2.2. Application programming interface (API)

5.2.2.1. Type definitions

5.2.2.1.1. ComXf_ConfigType

Purpose	This is the type of the data structure containing the initialization data for the transformer.
Туре	uint8

5.2.2.2. Macro constants

5.2.2.2.1. COMXF_E_INIT_FAILED

Purpose	Error code if an invalid configuration set was selected.
Value	0x02U

5.2.2.2. COMXF_E_PARAM

Purpose	API Service called with wrong parameter.
Value	0x03U

5.2.2.2.3. COMXF_E_PARAM_POINTER

Purpose	API Service called with invalid pointer.
Value	0x04U

5.2.2.2.4. COMXF_E_UNINIT

Purpose	Error code if any other API service, except GetVersionInfo is called before the trans-
	former module was initialized with Init or after a call to Delnit.



Value

5.2.2.2.5. COMXF_INSTANCE_ID

Purpose	Id of instance of ComXf provided to Det_ReportError().
Value	0x00U
Description	EB_Automotive_C_Source_File

5.2.2.2.6. COMXF_SID_DEINIT

Purpose	API Service ID for ComXf_Delnit().
Value	0x02U

5.2.2.2.7. COMXF_SID_GETVERSIONINFO

Purpose	API Service ID for ComXf_GetVersioninfo().
Value	0x00U

5.2.2.2.8. COMXF_SID_INIT

Purpose	API Service ID for ComXf_Init().
Value	0x01U

5.2.2.2.9. COMXF_SID_SR_INV_TRANSFORMER

Purpose	API Service ID for ComXf_Inv_transformerId() of Sender/Receiver communication.
Value	0x04U

5.2.2.2.10. COMXF_SID_SR_TRANSFORMER

Purpose	API Service ID for ComXf_transformerId() of Sender/Receiver communication.
Value	0x03U



5.2.2.3. Functions

5.2.2.3.1. ComXf_DeInit

Purpose	Deinitialize the ComXf module.
Synopsis	<pre>void ComXf_DeInit (void);</pre>
Service ID	0x02
Sync/Async	Synchronous
Reentrancy	Non-Reentrant
Description	This function deinitializes the ComXf module.

5.2.2.3.2. ComXf_GetVersionInfo

Purpose	Get version information of the ComXf mode	ule.
Synopsis	void ComXf_GetVersionInfo (Std	
	VersionInfoType	* VersionInfo);
Service ID	0x00	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (out)	versioninfo	Pointer to where to store the version information of this module.
Description	This service returns the version information cludes: Module Id Vendor Id Vendor specific version numbers	n of this module. The version information in-

5.2.2.3.3. ComXf_Init

Purpose	Initialize the ComXf module.
Synopsis	<pre>void ComXf_Init (const ComXf_ConfigType * config);</pre>
Service ID	0x01
Sync/Async	Synchronous



Reentrancy	Non-Reentrant	
Parameters (in)	config	Points to the implementation specific structure
Description	This function initializes the ComXf module.	

5.2.2.3.4. ComXf_Inv_transformerId

Purpose	The COM deserializer interface for 'ComXf	_Inv_ <transformerid>'.</transformerid>
Synopsis	<pre>uint8 ComXf_Inv_transformerId (const uint8 * buffer , uint16 bufferLength , < type > * dataElement);</pre>	
Parameters (in)	buffer	Buffer allocated by the RTE, where the still serialized data are stored by the Rte.
	bufferLength	Used length of the buffer.
Parameters (out)	dataElement	Data element which is the result of the transformation and contains the deserialized data element.
Return Value	Result of request to serialize the dataElement	
	0x00	(E_OK): Serialization successful
	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
Description	This function deserializes a Sender/Receiver communication using the deserialization of COM Based Transformer. It takes the uint8 array containing the serialized data as input and outputs the original data element which will be passed to the Rte. Preconditions: The COM module must be initialized.	

5.2.2.3.5. ComXf_transformerId

Purpose	The COM transformer interface for 'ComXf	_ <transformerid>'.</transformerid>
Synopsis	_	<pre>(uint8 * buffer , uint16 type > * dataElement);</pre>
Parameters (in)	dataElement	Data element which shall be transformed.
Parameters (out)	buffer	Buffer allocated by the RTE, where the transformed data has to be stored by the transformer.



	bufferLength	Used length of the buffer.
Return Value	Result of request to serialize the dataElement	
	0x00	(E_OK): Serialization successful
	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
Description	This function transforms a Sender/Receive COM Based Transformer. It takes the data ray contain- ing the serialized data. Preconditions: The COM module must be in	element as input and outputs an uint8 ar-

5.2.3. Integration notes

5.2.3.1. Exclusive areas

Exclusive areas are not used by the ComXf module.

5.2.3.2. Production errors

Production errors are not reported by the ComXf module.

5.2.3.3. Memory mapping

General information about memory mapping is provided in the EB tresos AutoCore Generic documentation. Refer to the section Memory mapping and compiler abstraction in the Integration notes section for details.

The following table provides the list of sections that may be mapped for this module:

Memory section
CODE
VAR_FAST_INIT_UNSPECIFIED
CONFIG_DATA_UNSPECIFIED
VAR_INIT_8
VAR_NO_INIT_UNSPECIFIED



CONST_32

5.2.3.4. Integration requirements

WARNING

Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user's guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

5.2.3.4.1. ComXf.EB.IntReq.RequiresCom01

Description	The EB Com module shall be initialized before the invocation of ComXf_Init() and de- initialized only after ComXf_DeInit() returned. This behaviour only applies if a least one non safety related BSW entry is configured within the XfrmImplementationMap- ping of the ComXf module.
Rationale	The EB ComXf module requires the usage of Autocore Com module (reference to product description: ASCPD-288) if a least one non safety related BSW entry is configured within the XfrmImplementationMapping of the ComXf module. For these non safety related BSW entries the EB ComXf module uses the post-build configuration and library APIs of the EB Com module. It eases the implementation of the module. The configuration of the ComXf module and the Com module have to be consistent regarding the configuration of signal groups, which is ensured if the same configuration is used.

5.2.3.4.2. ComXf.EB.IntReq.InitRoutines

Description	ComXf_Init() and ComXf_DeInit() must not be invoked from the context of a safe application.
Rationale	Different transformations might be mapped to different partitions. Any module-wide de-/initialization routine shall de-/initialize only non-safety relevant data. Partitions containing safetly relevant transformations shall provide their own individual de-/initialization routine (if needed).

5.2.3.4.3. ComXf.EB.IntReq.RequiresE2E01

Description	If only safety related BSW entries are configured within the XfrmImplementationMap-
	ping of the ComXf module, no de-/initialization of the ComXf module is required.



Rationale

The EB ComXf module requires the usage of Autocore E2E library if a least one safety related BSW entry is configured within the XfrmImplementationMapping of the ComXf module. For these safety related BSW entries the EB ComXf module uses library macros of the EB E2E library and the system configuration itself. This means no usage of the post-build configuration and library APIs of the EB Com module applies. Nevertheless, the configuration of signal groups within the system configuration (for the ComXf module) and the Com module have to be consistent.

5.2.3.4.4. ComXf.EB.IntReq.EB_INTREQ_Com_0002

Description

Restrictions to prevent race conditions in Com's Tx-path. The Com module exhibits several race conditions in its transmission path that can cause inconsistent and/or mutilated data to be transmitted. The transmission of an I-PDU can be triggered by a Tx-signal API if the I-PDU has a direct part (transmission mode is DIRECT or MIXED). The Tx-signal APIs are Com SendSignal(), Com SendDynSignal(), Com SendSignalGroup(), and Com SendSignalGroupArray(). The Tx-signal APIs have write access to the Com-internal I-PDU buffer. Note that (the internal implementations of) these APIs are also used in context of Com MainFunctionRouteSignals(). Additionally the transmission of an I-PDU can be triggered in context of Com MainFunction-Tx(), Com TriggerIPDUSend(), or Com IpduGroupControl(), or Com SwitchIpduTx-Mode. Triggering of a transmission in general requires the read access to the Cominternal I-PDU buffer by the Com lower layers. Depending on the implementation of a Tx-callout (ComlPduCallout and ComlPduTriggerTransmitCallout), it requires read and/or write access to the Com-internal I-PDU buffer. The callouts are invoked when a transmission is triggered. Depending on the underlying bus system, the API Com -TriggerTransmit() is invoked, which requires read access to the Com-internal I-PDU buffer. A race occurs when an ongoing transmission (access to the Com-internal I-PDU buffer by Com lower layer and Com callout) is interrupted by an invocation of a Tx-signal API. A race occurs when an ongoing transmission is interrupted by an API which triggers another transmission for the same I-PDU and a configured Com callout changes data. This behavior leads to the following cases:

- An I-PDU has a direct part. It also has a call to a Tx-signal API to a signal/signal group, in which one of the following transfer properties is interrupted by another Tx-signal API call of a signal of the very same I-PDU: TRIGGERED,
- TRIGGERED ON CHANGE,
- ${\tt TRIGGERED_ON_CHANGE_WITHOUT_REPETITION, or}$
- TRIGGERED_WITHOUT_REPETITION.
- A call to a Tx-signal API for a signal/signal group that belongs to



the I-PDU interrupts a call to one of the following APIs of the very same I-PDU: Com_TriggerIPDUSend(),

Com IpduGroupControl(),

Com_SwitchIpduTxMode(), or

Com TriggerTransmit().

- A call to a Tx-signal API interrupts a call to

Com_MainFunctionTx().

 A callout uses the data of the I-PDU for a calculation (e.g. to calculate a CRC) and a call to Tx-signal API interrupts the sending of the I-PDU.

With a call to Com_SendDynSignal() not only the content of an I-PDU may change, but also the length of the I-PDU. Work-around To prevent inconsistencies in the I-PDU, ensure the following:

- A call to a Tx-signal API that triggers a transmission does not interrupt a call to a Tx-signal API for signals which belong to the same I-PDU.
- A call to a Tx-signal API does not interrupt one of the following APIs: Com TriggerIPDUSend(),

Com_SwitchIpduTxMode(), or

Com_TriggerTransmit().

- A call to a Tx-signal API does not interrupt

Com MainFunctionTx().

- Additionally, if a callout is configured that modifies I-PDU data:

Ensure that the APIs:

Com_TriggerIPDUSend()and

Com SwitchlpduTxMode() and

Com_TriggerTransmit() and

Com_MainFunctionTx()

do not interrupt each other for the very same I-PDU.

Rationale

This issue could be avoided if you lock the PDU buffer or use expensive double buffers. However if you lock the PDU buffer while the callout function or the PduR_-ComTransmit function is called, it leads to an undefined locking time. It is not acceptable to disable interrupts for too long. Therefore a usage restriction has been defined in the work-around section to avoid race conditions.

5.2.3.4.5. ComXf.EB.IntReq.EB_INTREQ_Com_0003

Description	The access to the shadow buffer of a signal group is not protected. Therefore restric-
	tions apply to the mutually possible preemptions.



	 On the Tx-side: A call to Com_UpdateShadowSignal() shall not get interrupted by Com_SendSignalGroup() for the signal group to which the group signal belongs to. On the Rx side: A call to Com_ReceiveShadowSignal() shall not get interrupted by Com_ReceiveSignalGroup() for the signal group to which the group signal belongs to.
Rationale	Restriction on allowed mutual preemptions. Work-around: - Ensure that Com_SendSignalGroup() does not interrupt Com_UpdateShadowSignal() for the signal group to which the group signal belongs to. - Ensure that Com_ReceiveSignalGroup() does not interrupt Com_ReceiveShadowSignal() for the signal group to which the group signal belongs to.

5.2.3.4.6. ComXf.EB.IntReq.EB_INTREQ_Com_0005

Description

Limitation on Com signals/signal groups with update-bits. AUTOSAR COM SWS specifies that signals/signal groups with update-bits which have not been updated shall be discarded. However, if after an update of an I-PDU the value of a signal changes from e.g. x to y without the update bit is set, a call to Com_ReceiveSignal()/Com_ReceiveSignalGroup()-Com_ReceiveGroupSignal() returns the changed value (i.e. y) and not the last received value (i.e. x). Note: It is very unlikely that the receiver receives an updated value without the update-bit set. Because at sender side, the sender always sets the update-bit in case a new value is transmitted. The value of a signal/signal group only changes when the Com_SendSignal()/Com_SendSignal-Group() is invoked which sets the update-bit. An impact may only occur if the value on the sender is changed while the update-bit is not set. If this conditions occur this has no impact on the following use-cases:

- For applications (SWCs), at least if the EB-optimization
 DirectReadFromCom in Rte is not used. Since the Rte
 reads the value from the Com module only if it is notified by the Com
 module. This does not happen when the update-bit is not set. Also it
 writes the received value into a buffer and reads requests from the
 application and uses the value of the buffer.
- For applications which only use Com APIs when ComNotification is received.



Rationale	without ComNotification, changed values may be read that have no update-bit set. The following work-around is only applicable in this case. Work-around for signals of type U/SINT8/16/32 Configure a filter (ComFilterAlgorithm) NEW_IS_WITHIN, with the parameters [ComFilterMin, ComFilterMax] = maximum possible value range. This limitation allows a more efficient implementation and for the application usually
	The following work-around is only applicable in this case. Work-around for signals of type U/SINT8/16/32 Configure a filter (ComFilterAlgorithm) NEW_IS_WITHIN, with the
	However, this conditions may have an impact on the following use-case: Applications, which directly use the Com APIs, usually get the correct value, since the value of a signal usually does not change without setting the undate bit. If you use the Com APIs

5.3. SomelpXf

5.3.1. Configuration parameters

Containers included		
Container name	Multiplicity	Description
CommonPublishedInforma- tion	11	Label: Common Published Information Common container, aggregated by all modules. It contains published information about vendor and versions.
PublishedInformation	11	Label: EB Published Information Additional published parameters not covered by Common- PublishedInformation container.
XfrmGeneral	11	Contains the general configuration parameters of the module.
XfrmImplementationMapping	1n	For each transformer (TransformationTechnology) in a transformer chain (DataTransformation) which is applied to an ISignal it is necessary to specify the BswModuleEntry which implements it. This is the container to hold these mappings.

Parameters included		
Parameter name	Multiplicity	
IMPLEMENTATION_CONFIG_VARIANT	11	

Parameter Name	IMPLEMENTATION_CONFIG_VARIANT
Label	Config Variant



Multiplicity	11
Туре	ENUMERATION
Default value	VariantPreCompile
Range	VariantPreCompile

5.3.1.1. CommonPublishedInformation

Parameters included		
Parameter name	Multiplicity	
ArMajorVersion	11	
ArMinorVersion	11	
ArPatchVersion	11	
SwMajorVersion	11	
SwMinorVersion	11	
SwPatchVersion	11	
ModuleId	11	
Vendorld	11	
Release	11	

Parameter Name	ArMajorVersion
Label	AUTOSAR Major Version
Description	Major version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	4
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	ArMinorVersion
Label	AUTOSAR Minor Version
Description	Minor version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	11



Туре	INTEGER_LABEL
Default value	2
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	ArPatchVersion
Label	AUTOSAR Patch Version
Description	Patch level version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	1
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwMajorVersion
Label	Software Major Version
Description	Major version number of the vendor specific implementation of the module.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	1
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwMinorVersion
Label	Software Minor Version
Description	Minor version number of the vendor specific implementation of the module. The numbering is vendor specific.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	0
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwPatchVersion
----------------	----------------



Label	Software Patch Version
Description	Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	44
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	Moduleld
Label	Numeric Module ID
Description	Module ID of this module from Module List
Multiplicity	11
Туре	INTEGER_LABEL
Default value	174
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	Vendorld
Label	Vendor ID
Description	Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list
Multiplicity	11
Туре	INTEGER_LABEL
Default value	1
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	Release
Label	Release Information
Multiplicity	11
Туре	STRING_LABEL
Default value	
Configuration class	PublishedInformation:



Origin	Elektrobit Automotive GmbH	
--------	----------------------------	--

5.3.1.2. PublishedInformation

Parameters included	
Parameter name	Multiplicity
PbcfgMSupport	11

Parameter Name	PbcfgMSupport
Label	PbcfgM support
Description	Specifies whether or not the SomelpXf can use the PbcfgM module for post-build support.
Multiplicity	11
Туре	BOOLEAN
Default value	false
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

5.3.1.3. XfrmGeneral

Parameters included		
Parameter name	Multiplicity	
XfrmDevErrorDetect	11	
XfrmBufferLengthType	11	
XfrmVersionInfoApi	11	

Parameter Name	XfrmDevErrorDetect	
Description	The functionality related to this parameter is not supported by the current implementation.	
	Switches the Development Error Detection and Notification ON or OFF.	
	► TRUE: Development Error Detection mechanism is enabled (switched on).	
	FALSE: Development Error Detection mechanism is disabled (switched off).	
Multiplicity	11	
Туре	BOOLEAN	



Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	XfrmBufferLengthType		
Description	Specifies the data type of parameter B	Specifies the data type of parameter BufferLength for transformer APIs.	
Multiplicity	11	11	
Туре	ENUMERATION		
Default value	UINT16		
Range	UINT16		
	UINT32		
Configuration class	VariantPreCompile:	VariantPreCompile	
Origin	Elektrobit Automotive GmbH		

Parameter Name	XfrmVersionInfoApi		
Description	Activate/Deactivates the version information API.		
Multiplicity	11	11	
Туре	BOOLEAN		
Default value	false		
Configuration class	VariantPreCompile:	VariantPreCompile	
Origin	Elektrobit Automotive GmbH		

5.3.1.4. XfrmImplementationMapping

Containers included		
Container name	Multiplicity	Description
XfrmVariableDataPrototypeInstanceRef	11	Instance reference to a VariableDataPrototype in case a dedicated transformer BswModuleEntry is required per Variable-DataPrototype access.
XfrmDemEventParameter- Refs	11	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus API in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameters DemEventId value. The standardized errors are provided in



Containers included		
		the container and can be extended by vendor specific error references.
<u>XfrmSignal</u>	11	Reference to the signal in the system description that transports the transformed data.

Parameters included		
Parameter name	Multiplicity	
XfrmTransformerBswModuleEntryRef	01	
XfrmInvTransformerBswModuleEntryRef	01	
XfrmTransformationTechnologyRef	11	
XfrmIsSafetyTransformer	01	
XfrmOsApplicationRef	01	

Parameter Name	XfrmTransformerBswModuleEntryRef	
Description	Reference to the BswModuleEntry which implements the referenced transformer on the sending/calling side.	
Multiplicity	01	
Туре	FOREIGN-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	XfrmInvTransformerBswModuleEntryRef	
Description	Reference to the BswModuleEntry which implements the referenced inverse transformer on the receiving/called side.	
Multiplicity	01	
Туре	FOREIGN-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	XfrmTransformationTechnologyRef
Description	Reference to the TransformationTechnology in the DataTransformation of the system description for which the implementation (BswModuleEntry) shall be mapped.
Multiplicity	11
Туре	FOREIGN-REFERENCE



Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	XfrmlsSafetyTransformer		
Description	Specifies if the Transforme	Specifies if the Transformer shall be considered as a safety Transformer.	
Multiplicity	01	01	
Туре	BOOLEAN		
Default value	false		
Configuration class	PreCompile:	VariantPreCompile	
Origin	Elektrobit Automotive Gmb	Н	

Parameter Name	XfrmOsApplicationRef	
Description	Reference to an Os application to which the BSW belongs.	
	Enabled: Maps global variables of	
	function to dedicated memory partition.	
	Disabled: No dedicated memory partition assigned.	
Multiplicity	01	
Туре	REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

${\bf 5.3.1.5.}\ X frm Variable Data Prototype Instance Ref$

Parameters included		
Parameter name	Multiplicity	
TARGET	11	
CONTEXT	22	

Parameter Name	TARGET
Description	Target of the instance reference to a VariableDataPrototype.
	The context of the instance reference is given by the list of Context References (CONTEXT) below.
Multiplicity	11



Туре	REFERENCE	
Configuration class	VariantPreCompile: VariantPreCompile	
Origin	AUTOSAR_ECUC	

Parameter Name	CONTEXT	
Description	List of ordered context references of the instance reference to: 1. SwComponentPrototype 2. PortPrototype	
	The target of the instance reference is given with the VariableDataPrototype reference (TARGET) above.	
Multiplicity	22	
Туре	REFERENCE	
Range	SW-COMPONENT-PROTOTYPE	
	PORT-PROTOTYPE*	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.3.1.6. XfrmDemEventParameterRefs

Parameters included	
Parameter name Multiplicity	
XFRM_E_MALFORMED_MESSAGE 01	

Parameter Name	XFRM_E_MALFORMED_MESSAGE	
Description	The functionality related to this parameter is not supported by the current implementation. Reference to configured DEM event to report if malformed messages were received by the transformer. Reference to configured DEM event to report if malformed messages were received by the transformer.	
Multiplicity	01	
Туре	SYMBOLIC-NAME-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	



5.3.1.7. XfrmSignal

Containers included		
Container name	Multiplicity	Description
<u>XfrmSignalChoice</u>	11	Choice whether an ISignal or an ISignalGroup shall be referenced.

5.3.1.8. XfrmSignalChoice

Containers included		
Container name	Multiplicity	Description
<u>XfrmlSignalGroupRefChoice</u>	11	Reference to the ISignalGroup in the system description that transports the transformed data.
<u>XfrmlSignalRefChoice</u>	11	Reference to the ISignal in the system description that transports the transformed data.

5.3.1.9. XfrmlSignalGroupRefChoice

Parameters included		
Parameter name Multiplicity		
XfrmlSignalGroupRef	11	

Parameter Name	XfrmlSignalGroupRef	
Description	Reference to the ISignalGroup in the system description that transports the transformed data.	
Multiplicity	11	
Туре	FOREIGN-REFERENCE	
Configuration class	VariantPreCompile: VariantPreCompile	
Origin	AUTOSAR_ECUC	

5.3.1.10. XfrmlSignalRefChoice

Parameters included		
Parameter name	Multiplicity	
XfrmlSignalRef	11	



Parameter Name	XfrmlSignalRef	
Description	Reference to the ISignal in the system description that transports the transformed data.	
Multiplicity	11	
Туре	FOREIGN-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.3.2. Application programming interface (API)

5.3.2.1. Functions

5.3.2.1.1. SomelpXf_CS_transformerId

Purpose	The SOME/IP serialization interface for 'SomeIpXf_CS_transformerId' at client or server side.	
Synopsis	<pre>uint8 SomeIpXf_CS_transformerId (const Rte_Cs_Trans- actionHandleType * TransactionHandle , uint8 * Buffer , uint16 * BufferLength , Std_ReturnType * ReturnVal- ue , ParamlType Data_1 , const Param2Type * Data_n);</pre>	
Parameters (in)	TransactionHandle	Transaction handle needed to differentiate between multiple requests.
	ReturnValue	Return value of the server runnable which needs to be serialized on server side for transmission to the calling client. This argument is only available for serializers of the response of a Client/Server communication and if the ClientServerOperation has at least one PossibleError defined.
	Data_1	First client/server operation argument of scalar 'Param1Type' which shall be transformed.
	Data_n	n-th client/server operation argument of type 'Param2Type' which shall be transformed.



Parameters (out)	Buffer	Buffer allocated by the RTE, where the transformed data has to be stored by the transformer.
	BufferLength	Used length of the buffer.
Return Value	Result of request to serialize the data elements	
	0x00	(E_OK): Serialization successful
	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
Description	This function serializes a Client/Server communication using the serialization of SOME/IP. It takes n operation argument(s) as input and outputs an uint8 array containing the serialized data. The length of the serialized data shall be calculated by the transformer during runtime and returned in the OUT-parameter bufferLength. It may be smaller than the maximum buffer size used by the RTE for buffer allocation.	

${\bf 5.3.2.1.2.}\ SomelpXf_Inv_CS_transformerId$

Purpose	The SOME/IP deserialization interface for 'SomelpXf_Inv_CS_transformerId' at client or server side.	
Synopsis	uint8 SomeIpXf_Inv_CS_transformerId (Rte_Cs_Trans-actionHandleType * TransactionHandle , const uint8 * Buffer , uint16 BufferLength , Std_ReturnType * Return-Value , ParamlType * Data_1 , Param2Type * Data_n);	
Parameters (in)	Buffer Buffer Buffer Buffer allocated by the RTE, where the still serialized data are stored by the F	
	BufferLength	Used length of the buffer.
Parameters (out)	TransactionHandle	Transaction handle needed to differentiate between multiple requests.
	ReturnValue	Return value of the server runnable which needs to be serialized on server side for transmission to the calling client. This argument is only available for deserializers of the response of a Client/Server communication and if the ClientServerOperation has at least one PossibleError defined.
	Data_1	First client/server operation argument of type 'Param1Type' which shall be transformed.



	Data_n	n-th client/server operation argument of type 'Param2Type' which shall be transformed.
Return Value	Result of request to deserial	lize the uint8 array
	0x00	(E_OK): Deserialization successful
	0x01	(E_NO_DATA): No data available which can be deserialized
	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
	0x87	(E_SER_WRONG_PROTO- COL_VERSION): The version of the re- ceiving transformer did not match the sending transformer.
	0x88	(E_SER_WRONG_INTER-FACE_VERSION): Interface version of serialized data is not supported.
	0x89	(E_SER_MALFORMED_MESSAGE): The received message is malformed. The transformer is not able to produce an output.
	0x8a	(E_SER_WRONG_MESSAGE_TYPE): The received message type was not expected.
Description	This function deserializes a Client/Server communication using the deserialization of SOME/IP. It takes the uint8 array containing the serialized data as input and outputs the return value of the server runnable and n operation argument(s) which have to be passed from the server to the client.	

5.3.2.1.3. SomelpXf_Inv_ET_transformerId

Purpose	The SOME/IP deserialization interface for 'SomelpXf_Inv_ET_transformerId' on trigger sink side.	
Synopsis	<pre>uint8 SomeIpXf_Inv_ET_transformerId (con- st uint8 * Buffer , uint16 BufferLength);</pre>	
Parameters (in)	Buffer	Buffer allocated by the RTE, where the still serialized data are stored by the Rte.



	BufferLength	Used length of the buffer.
Return Value	Result of request to deserialize the external trigger event	
	0x00	(E_OK): Serialization successful
	0x01	(E_NO_DATA): No data available which can be deserialized
	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
	0x87	(E_SER_WRONG_PROTO- COL_VERSION): The version of the re- ceiving transformer did not match the sending transformer.
	0x88	(E_SER_WRONG_INTER-FACE_VERSION): Interface version of serialized data is not supported.
	0x89	(E_SER_MALFORMED_MESSAGE): The received message is malformed. The transformer is not able to produce an output.
	0x8a	(E_SER_WRONG_MESSAGE_TYPE): The received message type was not expected.
Description	This function deserializes an external trigger event using the deserialization of SOME/IP.	

${\bf 5.3.2.1.4.} \ SomelpXf_Inv_SR_transformerId$

Purpose	The SOME/IP deserialization interface for 'SomeIpXf_Inv_SR_transformerId' at sender side.	
Synopsis	<pre>uint8 SomeIpXf_Inv_SR_transformerId (const uint8 * Buffer , uint16 BufferLength , ParamType * DataElement);</pre>	
Parameters (in)	Buffer	Buffer allocated by the RTE, where the still serialized data are stored by the Rte.
	BufferLength	Used length of the buffer.
Parameters (out)	DataElement	Data element which is the result of the transformation and contains the deserialized data element.



Return Value	Result of request to deserialize the uint8 array	
	0×00	(E_OK): Deserialization successful
	0x01	(E_NO_DATA): No data available which can be deserialized
	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
	0x87	(E_SER_WRONG_PROTO- COL_VERSION): The version of the re- ceiving transformer did not match the sending transformer.
	0x88	(E_SER_WRONG_INTER-FACE_VERSION): Interface version of serialized data is not supported.
	0x89	(E_SER_MALFORMED_MESSAGE): The received message is malformed. The transformer is not able to produce an out- put.
	0x8a	(E_SER_WRONG_MESSAGE_TYPE): The received message type was not expected.
Description	This function deserializes a Sender/Receiver communication using the deserialization of SOME/IP. It takes the uint8 array containing the serialized data as input and outputs the original data element 'ParamType' which will be passed to the Rte.	

5.3.2.1.5. SomelpXf_SR_transformerId

Purpose	The SOME/IP serialization interface for 'SomeIpXf_SR_transformerId' at receiver side.	
Synopsis	<pre>uint8 SomeIpXf_SR_transformerId (uint8 * Buffer , uint16 * BufferLength , const ParamType * DataElement);</pre>	
Parameters (in)	DataElement Which shall be transformed	
Parameters (out)	Buffer	Buffer allocated by the RTE, where the transformed data has to be stored by the transformer.
	BufferLength	Used length of the buffer.
Return Value	Result of request to serialize the data element	
	0x00	(E_OK): Serialization successful



	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
Description	This function transforms a Sender/Receive SOME/IP. It takes the data element of 'Para ray containing the serialized data. The leng by the transformer during runtime and returnay be smaller than the maximum buffer s	amType' as input and outputs an uint8 ar- ith of the serialized data shall be calculated rned in the OUT-parameter bufferLength. It

5.3.2.1.6. SomelpXf_TE_transformerId

Purpose	The SOME/IP serialization interface for 'SomelpXf_TE_transformerId' on trigger source side.	
Synopsis	<pre>uint8 SomeIpXf_TE_transformerId (uint8 * Buffer , uint16 * BufferLength);</pre>	
Parameters (out)	Buffer	Buffer allocated by the RTE, where the transformed data has to be stored by the transformer.
	BufferLength	Used length of the buffer.
Return Value	Result of request to serialize the external trigger event	
	0x00	(E_OK): Serialization successful
	0x81	(E_SER_GENERIC_ERROR): A generic error occurred
Description	This function transforms an external trigger event using the serialization of SOME/IP. It takes trigger as input and outputs an uint8 array. The length of the transformed data shall be calculated by the transformer during runtime and returned in the OUT parameter BufferLength. It may be smaller than the maximum buffer size used by the RTE for buffer allocation.	

5.3.3. Integration notes

5.3.3.1. Exclusive areas

Exclusive areas are not used by the ${\tt SomeIpXf}$ module.



5.3.3.2. Production errors

Production errors are not reported by the SomeIpXf module.

5.3.3. Memory mapping

General information about memory mapping is provided in the EB tresos AutoCore Generic documentation. Refer to the section Memory mapping and compiler abstraction in the Integration notes section for details.

The following table provides the list of sections that may be mapped for this module:

Memory section
CODE
VAR_FAST_INIT_UNSPECIFIED
CONFIG_DATA_UNSPECIFIED
VAR_INIT_8
VAR_CLEARED_UNSPECIFIED
CONST_32
<partitionnameinfix>_VAR_CLEARED_16</partitionnameinfix>
<partitionnameinfix>_VAR_CLEARED_ASIL_D_16</partitionnameinfix>

5.3.3.4. Integration requirements

WARNING

Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

Integration requirements are not listed for the SomelpXf module.



6. Bibliography

Bibliography

[1] AUTOSAR Specification of COM Based Transformer, Issue AUTOSAR 4.2.1, Publisher: AUTOSAR

[1] AUTOSAR Specification of SOME/IP Transformer, Issue AUTOSAR 4.2.1, Publisher: AUTOSAR