

## **SIGNAL COORDINATION (VAP)**

## **Short description**

Demonstration of communication between two signal controllers (SC), for example for coordination purposes.

## Requirements

PTV Vissim Module: VAP

## Modelling technique

In this example SC 1 informs SC 2 about the current stage as soon as it starts an interstage. According to that information SC 2 switches to this stage one controller time step later (here: 1 simulation second).

In Vissim, a channel link between the two controllers is established: Via **Signal Control - Signal Controller Communication** channel no. 2 of SC 1 is linked with channel no. 11 of SC 2. The channel numbers can be freely chosen but need to be the same as used in the VAP commands Marker get and Marker put.

You can easily test the simulation without coordination by deleting the communication channel from Vissim. Then SC 2 remains at continuous green.

© PTV AG 2015 Page 1/1