



BATTERY PACK 6-CELL

21.6V

2600 mAh



BATTERY BMS (STANDARD | ECO)

OPERATIONAL & CHARGING

- *● **FLASHING BLUE** Vacuum is ON, Battery charge level 1-3
- *● **BREATHING BLUE** Battery is Charging, level 1-3
- **SOLID BLUE** Charging is complete (IDLE)
- *●● **RAPID BLUE FLASH** Battery Low (first LED only)

DIAGNOSTICS & SAFETY

- **CHARGING PAUSE / CELL STABILISATION**
- **TEMP NORMALIZATION LOCK**
- **FLASHING RED** **FAULT / ERROR CODE**

BATTERY CAPACITY (After Trigger Release)

- 0% - 33%
- 33% - 66%
- 66% - 100%

ON CHARGER CONNECT / DISCONNECT (Dual-Function)

- CELL BALANCE IN **STANDARD** MODE (1 Flash = 50mV)
- CELL BALANCE IN **ECO** MODE (1 Flash = 50mV)

TO CHANGE MODE: Hold trigger down while connecting charger cable

- 10 RAPID FLASHES + ●●● 1 FLASH **STANDARD MODE** (4.15V)
- 10 RAPID FLASHES + ●●● 1 FLASH **ECO MODE** (4.00V)

For the Error codes and more information about custom firmware, please scan QR code.