



BATTERY PACK 6-CELL

21.6V

2600 mAh



BATTERY BMS

OPERATIONAL & CHARGING

- ★ ● **FLASHING BLUE** Vacuum is ON, Battery charge level 1-3
 - ★ ● **BREATHING BLUE** Battery is Charging, level 1-3
 - ● ● **SOLID BLUE** Charging is complete (IDLE)
 - ★ ● ● **RAPID BLUE FLASH** Battery Low (first LED only)
-

DIAGNOSTICS & SAFETY

- ● ● **CHARGING PAUSE / CELL STABILISATION**
 - ● ● **TEMP NORMALIZATION LOCK**
 - ● ● **FLASHING RED** **FAULT / ERROR CODE**
-

BATTERY CAPACITY (After Trigger Release)

- ● ● 0% - 33%
 - ● ● 33% - 66%
 - ● ● 66% - 100%
-

ON CHARGER CONNECT / DISCONNECT (Dual-Function)

- ● ● CELL BALANCE IN **STANDARD** MODE (1 Flash = 50mV)
 - ● ● CELL BALANCE IN **ECO** MODE (1 Flash = 50mV)
-

TO CHANGE MODE: Hold trigger down while connecting charger cable

- ● ● 10 RAPID FLASHES + ● ● ● 1 FLASH **STANDARD MODE** (4.15V)
- ● ● 10 RAPID FLASHES + ● ● ● 1 FLASH **ECO MODE** (4.00V)

For the Error codes and more information about custom firmware, please scan QR code.