

Xumo Stream Box

Complete Setup, Account & Troubleshooting Guide

This guide combines everything you need to set up, activate, and troubleshoot your Xumo Stream Box, including how to sign in with your internet provider and manage your Xumo account.

1. Getting Started with Your Xumo Stream Box

What is Xumo Stream Box?

Xumo Stream Box is a streaming device that plugs into any TV, giving you access to all your streaming services without downloading apps individually. You can search for shows across apps using just your voice.

With the **My List** feature, you can save your favorites across your apps in one place, and even create different lists for family members. You also get 300+ free channels with Xumo Play, the built-in streaming service.

Before You Start

Make sure you have the following ready:

- 1 A working internet connection with WiFi enabled (or an Ethernet cable for a wired connection)
- 1 Your WiFi network name and password
- 1 A separate device with an internet browser for activation and account registration
- 1 The make and model of your TV and external speaker system (if applicable)

Step 1: Connect to Your TV

- 1 Connect the HDMI cable to your Xumo Stream Box and TV
- 2 Plug the power supply into an electrical outlet (use only the supplied power adapter; avoid outlets controlled by dimmers)
- 3 Turn on your TV and select the correct HDMI source/input

Step 2: Activate and Pair

Follow the on-screen instructions to pair your remote and activate your device. You can quickly link your Xumo account or TV provider using the on-screen prompts.

Safety note: Xumo will never charge you a fee to activate your device. Avoid fraudulent websites or technical support scams.

Provider-Specific Instructions

- 1 **Spectrum:** Select Spectrum to link your Xumo account, then use your Spectrum credentials to complete setup
- 1 **Xfinity:** Select Xfinity as your TV provider to access your live TV and favorite content
- 1 **Mediacom:** Select Mediacom, then scan the QR code or visit xumo.com/activate and enter the 6-digit code shown on your TV
- 1 **Cox:** Select Cox, then scan the QR code or visit xumo.com/activate and enter the 6-digit code shown on your TV
- 1 **No TV provider:** Select "Do it myself," then scan the QR code or visit xumo.com/activate and enter the 6-digit code shown on your TV

Troubleshoot Common Setup Issues

If your Xumo Stream Box is unresponsive:

- 1 Reset it by unplugging the power supply and plugging it back in

- 1 Ensure both ends of the HDMI cable are secure
- 1 Try a different HDMI port on your TV
- 1 Press the Power button to wake the device

If your remote is unresponsive:

- 1 **Check batteries:** If no red or green light appears when pressing buttons, replace the batteries
- 1 **Line of sight:** Stay within three feet of the device with a clear line of sight
- 1 **Re-pair:** Press and hold the 1 and 3 buttons for three seconds until the light flashes green

Pairing the remote to TV/speakers:

If you cannot control volume or power, go to **Settings > Connected devices > Remote**. Select Control your TV or Control a speaker system and follow the prompts to enter your device brand and model number.

Get to Know Your Home Screen

Once activation is complete, you can navigate your home screen using rows such as **Recommendations**. The Currently Playing tile features live content from your TV provider or Xumo Play. Navigate left to see recently watched apps, or right for curated recommendations based on your watch history.

2. Troubleshooting Guide

Use these solutions to address activation code errors, connection problems, software update delays, and other technical issues.

Why is my activation code not working?

Make sure you're entering your 6-digit activation code displayed on-screen at the correct web address, xumo.com/activate.

If your activation code still isn't working, complete a power cycle to generate a new one:

- 1 Remove the power cable from your Xumo Stream Box
- 2 Remove the power cable from your TV
- 3 Wait 15 seconds, then plug both back in
- 4 Once your Xumo Stream Box has restarted, go to xumo.com/activate to enter the new code

Note: Each activation code is valid for only 10 minutes. If you still haven't received a working code, contact Xumo customer support via Start Chat.

What should I do if I see a specific error message on-screen?

First check your internet strength: **Settings > Network > Network connection**. If your WiFi connection is weak, restart your modem and try again.

Tip: For a faster connection, use an Ethernet cord and avoid hotspots.

What should I do if I'm having issues connecting to WiFi?

Confirm you are using the correct password, and try an Ethernet cord if issues persist.

The software update is taking a long time to finish. What should I do?

On first connection, the device may take up to 15 minutes to finish downloading the latest software. If it takes longer, perform a power cycle:

- 1 Unplug the power cable from the back of your Xumo Stream Box
- 2 Wait 15 seconds
- 3 Plug the power cable back in

Allow the device to restart; it should resume and complete the update.

My Xumo Stream Box is showing a black screen. What should I do?

This may mean the device has entered standby mode. Press the Home button on your Xumo remote once, then wait 15 seconds.

Important: Hold the remote close to the device with no obstructions. Do not hold the Home button down — just press and release.

If that doesn't resolve it:

- 1 Try connecting to HDMI-1 on the Xumo Stream Box

- 2 Test the HDMI connection by connecting a different device to the same slot
- 3 Check if that device functions as expected to isolate an HDMI connection issue

Why is "Continue with Spectrum" not working?

You may already have a Xumo account set up with the same email address, causing an error. Sign in with your existing Xumo credentials to continue.

Note: If "Continue with Spectrum" doesn't redirect you, try again in a few minutes (possible server error). You can always create an account directly through Xumo instead — in that case you'll always sign in with your email and password rather than via Spectrum.

3. Sign In to Xumo with Your Internet Provider

Signing in with your service provider credentials makes activation faster and easier — you can use your existing provider login to create your Xumo account instead of creating a new username and password.

Which providers can I use to sign in?

Currently, Spectrum customers can use their Spectrum credentials to create and sign in to their Xumo account.

How do I sign in with my provider?

During device activation, select Spectrum to link your Xumo account. You'll be asked to agree to the Privacy Policy, Terms of Use, and Data Sharing Policy, then use your Spectrum credentials to finish setup.

What if I do not want to log in with my provider?

Select "Do it myself" when prompted to pick your internet provider. Then link your account using the on-screen QR code or by visiting xumo.com/activate and entering the 6-digit activation code.

How do I sign in to my Xumo account with my Spectrum account?

If logging in via xumo.com, select the option to sign in with your provider. You'll be redirected to Spectrum to sign in, then returned to xumo.com.

How can I sign in if my internet provider isn't listed?

Currently only Spectrum sign-in is supported. Check back for additional provider options in the future.

Can I link my existing Xumo account with my provider?

If you have an existing Xumo account, you cannot currently link it to your provider.

Can I unlink my provider from my Xumo account?

Yes. Select Unlink, then create a password for your account to finish unlinking.

I created an account through my provider. Why can't I access the Xumo portal?

You'll need a verified email address to access your account through xumo.com. Sign in to xumo.com via your provider, then follow the on-screen instructions to verify your email.

I switched providers and can't log in to Xumo. What should I do?

- 1 If you have a verified email address on file: create a password for your account and unlink your provider
- 1 If you do not have an email address on file: create a new Xumo account

Note: You can still use your device to watch content without updating your account, but you won't have access to all Xumo account benefits and features.

4. Do I Need a Xumo Account?

Yes — you must register your Xumo Stream Box with a Xumo account to use your device. All you need is an email and password. Spectrum customers can access their Xumo account via Spectrum credentials.

Note: Xfinity customers do not need a separate Xumo account — use your Xfinity username and password instead.

Your account allows you to:

- 1 Activate and start using your Xumo Stream Box right away
- 1 Manage your Xumo app subscriptions, preferences, and payment methods in one place
- 1 Link and manage multiple Xumo devices under a single account
- 1 Access a full history of your purchases and rentals
- 1 Take advantage of exclusive offers and free trials for account holders

Creating Your Xumo Account

- 1 Follow the on-screen setup instructions
- 2 When the QR code appears, scan it using your smartphone or tablet
- 3 You'll be taken to the Xumo account creation page
- 4 Enter your email address and create a secure password
- 5 (Optional) Add a credit or debit card to make purchases from your Xumo Stream Box

Note: Spectrum customers can choose "Continue with Spectrum" to log in with Spectrum credentials instead.

I don't see a pairing code on my Xumo Stream Box. What should I do?

Enter the 6-digit code shown on-screen at xumo.com/activate. If you reach the "Link your Account" screen and don't see a code:

- 1 Wait 30 seconds
- 1 If still no code: select "Skip & Set up later," confirm skipping, select the Xumo tile, and repeat if necessary
- 1 If a code still doesn't appear, unplug the device, plug it back in, and repeat activation

Managing Your Xumo Account

How can I manage my method of payment?

Add, change, or remove your payment method any time at xumo.com/account.

How do I reset my password?

- 1 Go to xumo.com/account
- 2 Enter the email address associated with your Xumo account
- 3 Select "Forgot your Password?"
- 4 Follow the instructions to reset your password via email

Note: Spectrum customers who signed in with Spectrum credentials should reset their password via Spectrum: select "Continue with Spectrum" on the Xumo login page, then select "Forgot Username or Password" on Spectrum's sign-in page.

Using Your Xumo Account Across Multiple Devices

Yes, you can link multiple Xumo devices — including Xumo TV and Xumo Stream Box — to the same account. Just sign in with your Xumo account during setup.

5. Connect Your Xumo Stream Box to the Internet

A reliable internet connection lets you enjoy streaming without interruptions.

Connect During Activation

You'll be prompted to connect to the internet during activation — follow the on-screen instructions.

Note: You can also use an Ethernet cable (not included) for a wired connection. Make sure everything is plugged in securely.

Check Your WiFi Status

- 1 Go to Settings
- 2 Select Network
- 3 Choose Network connection

Your WiFi status will show as one of: **Excellent, Good, Fair, Bad, or Disconnected.**

Note: If connected via Ethernet, status will show as Connected or Disconnected instead.

Manage Your Networks

Reconnect to a disconnected WiFi network

- 1 Go to Settings > Network > Network Connection > WiFi using password
- 1 Select your network and enter the password

Connect to a different WiFi network

- 1 Go to Settings > Network > Network Connection
- 2 Select Reset, then select Confirm
- 3 Select WiFi using password
- 4 Select your new network and enter the password

Troubleshooting Internet Connection Issues

Step 1: Use the on-screen help

Select Help on the Network connection screen for connection tips.

Step 2: Fix WiFi password errors

Make sure you've selected the correct network name (SSID) and entered the right password. Passwords are case sensitive.

Step 3: Check your modem or router

Confirm your modem or router is connected to the internet by testing another device on the same network.

- 1 If other devices connect fine, try restarting your modem or router
- 1 If speeds seem slow, move the modem/router closer to the device or contact your ISP

Step 4: Troubleshoot mobile hotspot connections

- 1 Make sure your hotspot has a good connection and other devices can connect to it
- 1 If connected but slow, try restarting your mobile hotspot
- 1 If speed doesn't improve, connect the Stream Box to another WiFi or Ethernet network — it may have a compatibility issue with your hotspot

Find Your Device's MAC Address and Serial Number

Both are located on the bottom of your Stream Box. The MAC address uses the format XX:XX:XX:XX:XX:XX.

- 1 **ES1 Xumo Stream Box:** MAC address is printed on the bottom of the device, labeled "MAC"
- 1 **EntOS Xumo Stream Box:** Go to Settings > System management > System info > MAC address Ethernet

Connectivity Requirements

An internet connection is required to use your Xumo Stream Box. Most home broadband services work well, but higher-quality content like 4K or HDR may need faster speeds or more bandwidth. Contact your ISP to find out what's available in your area.

Still need help? Contact a Xumo agent 24/7 by selecting Start Chat on the Xumo support site.