

TO
IS:10270-1982 GUIDELINES FOR DESIGN AND CONSTRUCTION
OF PRESTRESSED ROCK ANCHORS

(Page 7, clause 5.2.2):

- a) Lines 1 and 5 - Substitute the word 'Fixed' for 'Free'.
- b) Line 6 - Substitute the words 'additional fixed' for 'free'.

[Page 9, Table 1, Sl No.(vii), col 3] - Substitute '3.50 kgf/cm²' for '3.50 kgf/mm²'.

[Page 11, clause 7.1(b)] - Substitute 'Tendon' for 'Tandon'.

(Pages 10 and 11, clause 6.7, Note) - Add the following at the end:

'The factors such as relaxation of wires and creep will be considered before the anchor is finally locked and grouted. For this, once the anchor is locked at the design load, it will be kept undisturbed for minimum seven days or till one day after the last anchor has been stressed in a particular unit, whichever is later and then checked for the losses due to relaxation, creep, etc, for the individual anchor. The anchor is then restressed to the design load and free length of anchor is finally grouted. Certain type of anchor designs are possible in which free length is enclosed in plastic sheathing, it is however ensured that no grout should come in contact with the steel in the fixed length portion of the anchor. Due to prestressing force the settlement/movement of the structure itself can be measured by placing 3 dial gauges around the anchor head.'

(BDC 43)