

ShopCPS.com

CONCRETE
PUMP SUPPLY

SLICK WILLIE 2



SLICK WILLIE 2

Slick Willie 2 is America's favorite powdered concrete pump primer.

FEATURES & BENEFITS

WELL KNOWN industry leader combines speed and performance together

SAFE has a non-alkaline formula, sets up quickly and will not dry out concrete, chemically neutral

EASY works with any type of concrete pump

SIMPLE can be pumped into forms, although we always recommend priming out

EFFECTIVE coats the insides of your pipe and hose system and provides unmatched protection

PACKAGING OPTIONS

50 EACH	4 OZ. PACKETS PER BOX
50 EACH	4 OZ. PACKETS PER PAIL
750 EACH	4 OZ. PACKETS PER DRUM

INSTRUCTIONS

1 Prepare the Slick Willie 2 mix

- Pour 1 packet of SW2 into a container of 5 Gallons of water.
- Stir this mixture for 1 minute, or until the material has thickened.
- Let the mix stand for at least 2 minutes.
- The mix can stand for longer before use, but it should be stirred again if left overnight.

2 Prime the Pump

- If the pump has a priming port (CAPS): Pour the SW2 mix into the primer port just ahead of the ready-mix concrete.
- If primed directly from the hopper: Pour the SW2 mix into the hopper, so the SW2 mix is charged in the system ahead of the ready-mix.

HOW MUCH PRIMER SHOULD BE USED?

One packet of SW2 mixed with 5 Gallons of water will successfully prime 150 ft. of 5" system. Horizontal or downhill pumping jobs may require more priming mix. Place a ball ahead of the mixture to ensure all interior surfaces are completely coated. SW2 primer provides lubrication for pipe and hose. Concrete pump primers vary in chemical content, but most synthetic polymers will not affect the slump of concrete. Nevertheless, Concrete Pump Supply recommends "priming out" before continuing with a pour.

Click [here](#) or Scan QR code for instructions and disclaimer information.



1 STOP SHOP!

© 2023 Concrete Pump Supply

Georgia > Texas > California > Florida **TO ORDER** Call 877.434.7867 Go Online [ShopCPS.com](#)