

1
WIFI / BLE BOT
WORKING CONDITION
NOT WORKING
INWARRANTY
BEFORE SENDING QC TEAM WILL VERIFY
SEND VENDOR FOR REPLACEMENT
CHECK WARRANTY
OUT WARRANTY
SEND FOR REWORK
WORKING
MOVE TO CLEANING PROCESS
REFER QC ANEXURE 8 FOR ACCEPT / REJECT
MOVE TO PRODUCTION
2
PUMP
NOT WORKING
INWARRANTY
SEND VENDOR FOR REPLACEMENT
BEFORE SENDING QC TEAM WILL VERIFY (TIMELINE 1 WEEK)
CHECK WARRANTY
OUT WARRANTY
SCRAP
WORKING
CHECK PUMP FLOW RATE/AT 1Kg/ Cm² PRESSUE INPUT WATER
SEND TO CLEANING PROCESS
REJECT
SCRAP
ACCEPT
REFER QC ANEXURE 7 FOR ACCEPT / REJECT
MOVE TO PRODUCTION
2
UV LAMP
NOT WORKING
SCRAP
WORKING
CLEANING
MOVE TO PRODUCTION
2
UV BALAST
NOT WORKING
INWARRANTY
SEND VENDOR FOR REPLACEMENT
BEFORE SENDING QC TEAM WILL VERIFY
CHECK WARRANTY
OUT WARRANTY
SEND TO VENDOR FOR REFURBISH
SCRAP
WORKING
CLEANING
MOVE TO PRODUCTION
2
UV HOUSING / QG TUBE
CHECK PHYSICAL DAMAGE
NOT OK
SCRAP
OK
CLEANING
MOVE TO PRODUCTION
2
REFER QC ANEXURE 9 FOR ACCEPT / REJECT
RO MEMBRANE CHECK PHYSICAL APPERANCE
CHECK FLOW RATE/AT 1Kg/ Cm² PRESSUE INPUT WATER
REJECT
SCRAP
ACCEPT
REFER QC ANEXURE 10 FOR ACCEPT / REJECT
MOVE TO PRODUCTION
2
ALL CONNECTORS
SEND TO CLEANING PROCESS
REJECT
SCRAP
ACCEPT
REFER QC ANEXURE11 FOR ACCEPT / REJECT
MOVE TO PRODUCTION
2
POWER ADAPTOR WORKING FUNCTION
NOT WORKING
INWARRANTY
BEFORE SENDING QC TEAM WILL VERIFY (TIMELINE 1 WEEK)
SEND VENDOR FOR REPLACEMENT
CHECK WARRANTY
OUT WARRANTY
SCRAP
WORKING
ACCESSORIES PACKING
CLEANING
REFER QC ANEXURE 12 FOR ACCEPT / REJECT
2