# TITLE: CABINET CLEANING PROCESS.

## 1. MATERIAL REQUIRED:

| S. No. | Item Name | Qty |
|---|---|---|
| 1. | Cabinet | 1 |
| 2. | Power adaptor 2A | 1 |
| 3. | RO Housing | 1 |
| 4. | Tank | 1 |

## 2. TOOLS REQUIRED:

| S. No. | Item Name | UOM | Qty. |
|---|---|---|---|
| 1. | Cleaning brush | Nos | 1 |
| 2. | Cif polish | Nos | 1 (60 devices) |
| 3. | Moto max cream | Nos | 1(100 devices) |
| 4. | 3M Rubbing component (or Equivalent) | Nos | 1(100 devices) |
| 5. | Colin liquid | Ltr | 5 (300 devices) |
| 6. | Cleaning Cloth | Nos | 1 |
| 7 | Sand paper – Emery sheet | Nos | 1 |

## 3. ACTIVITIES:

1. **Thorough Cleaning with CIF Cream and Yellow Cream:**
    - Apply CIF cream to a cleaning cloth.
    - Thoroughly clean the exterior of the device, ensuring all surfaces are covered.
    - If any scratch found on cabinet need use the Rubbing component for remove the scratches.
    - Use yellow cream for any areas that require additional cleaning power.
    - Wipe off the cream with a clean, damp cloth.
2. **Sticker Removal:**
    - Use a heat gun to gently warm up the stickers on the device. This will help to loosen the adhesive.

- Carefully peel off the stickers without damaging the surface of the device.
- Once all stickers are removed, clean the areas thoroughly to remove any remaining adhesive residue.

3. **Application of New Stickers:**
   - Position the new stickers on the device as per the original location.
   - Use a squeezer to apply the stickers, ensuring there are no air bubbles.
   - Smooth out the stickers to ensure they adhere properly to the device.
4. **Final Cleaning:**
   - Inspect the device for any remaining stains or marks.
   - Clean any remaining spots to ensure the device is spotless.
   - Verify that there are no streaks or residues left on the device.
5. **Adapter Inspection and Cleaning:**
   - Check the adapter for any signs of damage or malfunction.
   - If the adapter is functioning properly, clean it with suitable cleaning cloth.
   - Place the cleaned adapter back into the device.

## 4. SCRAP DISPOSAL INSTRUCTIONS:

- Keep polythene covers in respective bins only.

## 5. SAFETY INSTRUCTIONS:

- Keep the materials away from the gangway.

## 6. CHECK: Check the device for any scratches or damages.

## 7. RESPONSIBILITY: Operator

## 8. Quality Check:

- Ensure the device is completely clean, with no visible stains or marks.
- Confirm that the all the stickers are removed & verify the adapter's functionality and cleanliness.

| PREPARED BY | REVIEWED BY | APPROVED BY | ISSUED BY |
|---|---|---|---|
| | | | |