DRINKPRIME WATERWALA LABS PVT LTD

TITLE: WI FOR PUMP ASSEMBLY.

1. MATERIAL REQUIRED:

S.NO.	ITEM NAME	ITEM CODE	UOM	QTY.
1	PUMP CX 100-GPD	100059	No.	1
2.	PUMP ELBOW 1/4" (1/4" PF TO THREAD)	100031	Nos	2
3.	TEFLON TAPE	100099	MTR	1

2. TOOLS REQUIRED:

S.NO.	ITEM NAME	UOM	QTY.
1.	Spanner	No.	1
2.	End plug	No.	1
3.	Pressure Gauge	No.	1
4	Colin	No.	1

3. ACTIVITIES:

3.1 Take PUMP ELBOW 1/4" (1/4" PF TO THREAD) and wound the Teflon tape on the threaded portion with approx. 20 to 30 rounds.
3.2 insert the PUMP ELBOW 1/4" pump head thread & tighten with the help of spanner tool & make ensure without damage.
3.3 Check for leakage, pass the 80-90 PSI air in the inlet of the pump head & close the outlet with End plug.
3.4 Spray the colin liquid on the pump head threaded area, Check for leakage.
3.5 Leak test passed, Clean the pump head and move to production line, otherwise sent for rework.

4. SCRAP DISPOSAL:

4.1 Keep the scrap in the respective bins only.

5. SAFETY INSTRUCTIONS:

5.1 Keep the material away from the gang way

6. CHECKS:

6.1 Ensure that all the connections are tightened properly.

7. RESPONSIBILITY:

Operator & QC person.

PREPARED BY	REVIEWED BY	APPROVED BY	ISSUED BY