# Angle Modulation 1. Frequency 2. Phase Modulation

# **Angle Modulation**




FIGURE 7-3 Phase and frequency modulation of a sine-wave carrier by a sine-wave signal:

<sup>[</sup>a] unmodulated carrier; [b] modulating signal; [c] frequency-modulated wave;

<sup>(</sup>d) phase-modulated wave

#### Equation of FM

Let 
$$f_c = Carrier frequency$$

$$v_m = V_m \cos \omega_m t = Modulating signal$$

Refer figure 5.1.

In FM, the carrier frequency is modulated. The new f is given as:

$$f = \text{New frequency} = f_c + \text{Deviation}$$

where deviation = 
$$k f_c v_m$$
 (: frequency depends on instantaneous value of  $v_m$ )

noitaubi ati 1

noitaluboM ele-

and whote liew i.e. 
$$f = f_c + k f_c V_m \cos \omega_m t$$
 to the Modulation A Lemma 1.... (1)

i.e. 
$$2\pi f = 2\pi f_c + 2\pi f_c k V_m \cos \omega_m t$$

$$\therefore \omega = \omega_c + \omega_c \, k \, V_m \cos \omega_m t$$

where 
$$\omega = 2\pi f$$

$$\therefore \omega = \omega_c [1 + k V_m \cos \omega_m t] \qquad \dots (2)$$

in, = 2-1 and t = frequent

In FM, the amplitude of the signal remains constant but the frequency varies according to modulating signal.

.. we can write equation of FM as

$$v_{\rm FM} = A \sin \theta$$




Fig. 5.1

We can find value of  $\theta$  as follows:

$$\omega = \frac{d\theta}{dt} \qquad (t_m \cos_m V + t_m \omega) \cos A = \rho_0 \omega$$

$$|t_{\rm PM}| = A \sin \left( \omega_{\rm e} t + m_{\rm e} \sin \omega_{\rm m} t \right) \quad \text{th} \, \omega = \theta \; :.$$
 where  $m_{\rm e} = k \, V_{\rm m} = \text{Phase modulation index}$ 

Substitute equation (2),

$$= \omega_c t + \omega_c k V_m \left[ \frac{\sin \omega_m t}{\omega_m} \right] + \phi \quad \text{where, } \phi = \text{Phase}$$

200679 JUNE 1

$$\therefore \theta = \omega_c t + \omega_c k V_m \left[ \frac{\sin \omega_m t}{\omega_m} \right] \qquad \dots \{ \phi = 0 \text{ at initial position} \}$$

$$\theta = \omega_c t + k \frac{2\pi f_c}{2\pi f_m} V_m \sin \omega_m t$$

$$\therefore \theta = \omega_c t + \frac{k V_m f_c}{f_m} \sin \omega_m t$$

$$\therefore \theta = \omega_c t + \frac{\delta}{f_m} \sin \omega_m t$$

where & = Maximum frequency deviation

$$\therefore v_{FM} = A \sin \left[ \omega_c t + \frac{\delta}{f_m} \sin \omega_m t \right]$$

Modulation index  $(m_i)$  for FM is defined as :

$$m_f = \frac{\text{Maximum frequency deviation}}{\text{Modulating frequency}} = \frac{\delta}{f_m}$$

$$\therefore \quad v_{FM} = A \sin \left[ \omega_c t + m_f \sin \omega_m t \right]$$

The above expression gives frequency modulated carrier signal.

#### 5.1.2 Phase Modulation

#### Q. Explain the relationship between FM and PM.

If the phase of carrier signal is varied according to the instantaneous amplitude of modulating signal, then it is called phase modulation.

Let 
$$v_{PM} = A \sin [\omega_c t + \phi]$$

where \$ = Phase angle

and ø ∝ Modulating signal

$$\therefore \phi = k v_m = k V_m \sin \omega_m t$$

$$\therefore v_{PM} = A \sin \left[ \omega_c t + k V_m \sin \omega_m t \right]$$

$$\therefore v_{PM} = A \sin \left[ \omega_c t + m_p \sin \omega_m t \right]$$

where  $m_p = k V_m =$ Phase modulation index

and it is proportional to amplitude of modulating signal and independent of frequency.

## Difference Between FM & PM

#### Q. Differentiate FM and PM.

Sr.	FM	A APPROVED THE A PERSON AND A P	
(1)	The frequency of the carrier is varied according to instantaneous value of modulating signal.		
(2) 200	Equation: $v_{FM} = V_{c} \sin \left[\omega_{c} t + m_{f} \sin \omega_{m} t\right]$	Equation: $v_{PM} = V_{c} \sin \left[\omega_{c} t + m_{p} \sin \omega_{m} t\right]$	
(3)	Modulation index depends upon the modulating frequency.	Modulation index does not depend upon modulating frequency.	
	Equation: $m_f = \frac{\delta}{f_m} : \text{notation}$	$m_p = kV_m \text{ nolloup3}  (2)$	
(4)	Noise immunity is better than both AM and PM	Noise immunity is better than AM but worse than FM.	
(5)	Applications: Radio, TV transmission, wireless devices, point to point communication.	Applications: Used in Mobile systems.	

$$v_{\text{FM}} = A \sin \left[ \omega_{\text{c}} t + m_f \sin \omega_{\text{m}} t \right]$$

Above signal can be expanded by using Bessel's function of the first kind  $J_n(m_f)$  to get different component in FM.

$$v_{\text{FM}} = A \Big\{ J_0(m_f) \sin \omega_c t + J_1(m_f) \left[ \sin \left( \omega_c + \omega_m \right) t - \sin \left( \omega_c - \omega_m \right) t \right] \\ + J_2(m_f) \left[ \sin \left( \omega_c + 2\omega_m \right) t + \sin \left( \omega_c - 2\omega_m \right) t \right] + \dots \Big\}$$

From the above equation, it is seen that output consists of carrier frequency along with infinite number of sidebands.

If we substitute different values of  $m_f$  and n then the amplitude of each sideband can be calculated as:

$$J_n(m_f) = \sum_{r=0}^{\infty} \frac{(-1)^r \left(\frac{m_f}{2}\right)^{2r+n}}{r! \left[n+r+1\right]}$$

$$= \left(\frac{m_f}{2}\right)^n \left\{ \frac{1}{n!} - \frac{\left(\frac{m_f}{2}\right)^2}{1! (n+1)!} + \frac{\left(\frac{m_f}{2}\right)^4}{2! (n+2)!} - \dots \right\}$$

Note: To expand a sine of sine function i.e. a function like  $f(x) = \sin(a + b \sin x)$ we need Bessel's function.

Table 5.1 gives amplitude of number of sidebands for different values of  $m_i$ .

mf	Jo	$J_1$	$J_2$	J <sub>3</sub>	J <sub>4</sub>	J <sub>5</sub>	1 American 2 2
0.0	1.0	i i					
0.25	0.98	0.12	-		-	100	Ministra O
0.5	0.94	0.03	_	HINELE A	_	and the same	r leopir edi ti
1.0	0.77	0.44	0.11	0.02	_	la l	

Table 5.1

If 
$$m_f = 1$$
 and  $A = 1$  V, then

Amplitude of 1<sup>st</sup> sideband 
$$(\omega_c \pm \omega_m) = 0.44 \text{ V}$$

Amplitude of 
$$2^{nd}$$
 sideband  $(\omega_c \pm 2\omega_m) = 0.11 \text{ V}$ 

Amplitude of 
$$3^{rd}$$
 sideband  $(\omega_c \pm 3\omega_m) = 0.02 \text{ V}$ 




Fig. 5.2

#### 5.3 Carson's Rule

This rule is used to estimate BW (bandwidth) of all angle modulated systems regardless of modulation index.

Carson's rule states that we can neglect any frequency component (i.e. sideband) beyond n such that  $n=m_f+1$  and  $m_f$  is modulation index.

$$\therefore \text{ BW of FM} = 2n f_m = 2(m_f + 1) f_m \text{ where } m_f = \frac{\delta}{f_m}$$

$$= 2\left(\frac{\delta}{f_m} + 1\right) f_m$$

BW of FM = 
$$2(\delta + f_m)$$
 abandular to redimend to the figure 28 of  $\delta$ 


# Difference Between Narrow and wide Band FM

Q.	Compare Wideband and Narrow band	FM.
Sr.	Wideband FM	Narrowband FM (8)
(1)	It is type of FM where $m_f$ normally exceeds unity $m_f > 1$ .	It is type of FM where $m_f$ slightly greater than 0 but less than 1.
(2)	Maximum deviation $\delta = 75 \text{ kHz}.$	Maximum deviation $\delta = 5 \text{ kHz}$
(3)	Range of modulating frequency $f_m$ is 30 Hz to 15 kHz.	Range of modulating frequency $f_m$ is upto 3 kHz.
(4)	Bandwidth is almost 15 times greater than that of narrowband FM.	Bandwidth is comparatively less.
(5)	Due to large bandwidth effect of noise is more.	Effect of noise less.
(6)	There are more than two sidebands having significant amplitude.	There are only two sidebands.

# Noise Triangle

If the signal noise frequency falls within the passband of the receiver then it affects the output of the receiver.

The noise frequency gets added to the FM signal and produces unwanted changes as shown in figure 5.3.




In case (i) : Amplitude changes but phase change is zero.

In case (ii) : Amplitude as well as phase changes.

In case (iii) : Amplitude changes and phase changes to its maximum.

The amplitude change can be eliminated by Amplitude limiter. The phase change can not be eliminated. But it can be minimized using pre-emphasis and de-emphasis (explained later). Noise triangle thus shows how noise is related to frequency of the incoming signal.


Noise triangle is shown in figure 5.4.




- . The noise modulation index remains almost constant for all frequencies.
- In AM, modulation index is  $\frac{V_m}{V_c}$  i.e. it is independent of frequency. Hence noise in AM is almost constant.
- Similarly we can say that, noise in PM is almost constant. Since,  $m_p = kV_m$ .
- For FM, modulation index  $m_f$  is  $\frac{\delta}{f_m}$ . Hence as frequency  $f_m$  increases, the modulation index  $m_f$  decreases.
- Hence  $\frac{m_n}{m_f}$  increases. This gives shape of Triangle. Hence known as Noise Triangle.

- Q.1. Why is pre-emphasis required in FM generation. Explain the working of pre-emphasis and de-emphasis.
- Q.2. Explain pre-emphasis and de-emphasis in F.M.
- From noise triangle of FM, we can see that the effect of noise increases if higher audio frequencies are used for frequency modulation.


- To overcome above problem, the higher audio frequencies are boosted at the transmitter and accordingly attenuated at the receiver.
- The artificial boosting of higher order frequencies at the transmitter is done with the help of pre-emphasis circuit.
- Similarly attenuation of the boosted frequencies at receiver is done with the help of de-emphasis circuit.
  - Pre-emphasis Circuit: This circuit consists of high pass circuit with time constant of 60 μs.



 De-emphasis Circuit: This circuit is nothing but a low pass circuit with a time constant of 60 μs.



 The pre-emphasis and de-emphasis in done according to the pre-defined curve shown in figure 5.7.



 When the signal at the transmitter is boosted, care should be taken not to over modulate the higher order frequencies. Otherwise distortion will take place.

# Difference between AM & FM

Sr.	AM	FM
(1)	In amplitude modulation, the amplitude of carrier is varied w.r.t	In frequency modulation frequency of carrier is varied w.r.t instantaneous
end	instantaneous amplitude of modulating signal.	amplitude of modulating signal. (8)
(2)	Equation: WH = mm	Equation:
	$v_{AM} = [V_c + mV_c \sin \omega_m t] \sin \omega_c t$	$v_{\rm FM} = V_c \sin \left[\omega_c t + m_f \sin \omega_m t\right]$
(3)	Modulation index $m = \frac{V_m}{V_c}$	Modulation index $m_f = \frac{\delta}{f_m} M$
(4)	Bandwidth 2 f <sub>m</sub> .	Bandwidth = $2[\delta + f_m]$ .
(5)	Bandwidth is much less than FM.	Bandwidth is large.

## Difference between AM & FM

TAV + Dusics of Analog and Digital Commonication of

(6)	Frequency range of modulated signal $f_s = 540 \text{ kHz}$ to 1650 kHz.	Frequency range of modulated signal $f_s = 88 \text{ MHz}$ to $108 \text{ MHz}$ .	
(7)	Less complex	More complex.radahiVI araquad	
(8)	Information is contained in amplitude variation of carrier.	Information is contained in frequency variation of carrier.	
(9)	AM wave	2) - Washing my > 1 sysw M7  (2) - Washing Market M	
(10)	Applications: Radio and TV transmission.	Applications: Radio and TV transmission, point to point communication.	

