VKA - BRUSH CUTTER SPARE PARTS

1 VKA-35 SAFETY GUARD



2 VKA-35 SAFETY GUARD ECO

3 VKA-43 CC - 52CC SAFETY GUARD

4 VKA-GEAR CASE 28MM (HEAVY)

5 VKA-GEAR CASE 28MM (REGULAR)



6 VKA-GEAR CASE 26MM (HEAVY)

7 VKA-GEAR CASE 26MM (REGULAR)



8 VKA-BRUSH CUTTER LOCK PLATE



9 VKA-BLADE HOLDER WASHER A 10 TEETH



10 VKA-BLADE HOLDER WASHER B 10 TEETH

11 VKA-NUT LEFT THREAD M10



12 VKA-GEAR CASE BODY 28 MM

13 VKA-GEAR CASE BODY WITH GEAR 28MM



14 VKA- GREASE NUT FOR BRUSH CUTTER

15 VKA-UPPER HANDEL BASE

16 VKA-DOWN HANDEL BASE



17 VKA- MIDDLE HANDEL BASE



18 VKA-HANDLE CONNECTOR PART 28MM (ECO)

19 VKA-HANDLE CONNECTOR PART 28MM (PREMIUM)

20 VKA-HANDLE CONNECTOR PART 28MM (HEAVY)



21 VKA-HANDLE CONNECTOR PART 26MM (ECO)



22 VKA-HANDLE CONNECTOR PART 26MM (HEAVY)

23 VKA-CLUTCH HOUSING RUBBER

24 VKA-VIBRATION REDUCER RUBBER



25 VKA ACCELERATOR RIGHT HANDLEHEAVY YELLOW TRIGGER

26 VKA-ACCELERATOR RIGHT HANDLE RED TRIGGER

27 VKA-ACCELERATOR CABLE

28 VKA-HANDLE ROD

29 9 TEETH ONLY DRIVE SHAFT



30 VKA-PIPE WITH BUSH 28MM



31 VKA-CLUTCH DRUM

32 VKA- CLUTCH HOUSING ONLY BODY

33 VKA-CLUTCH HOUSING ASSEMBLY

34 VKA-BELT HOOK FOR BRUSH CUTTER

35 VKA-CLUTCH HOUSING FOR BACKPACK