1 **In Robot TP**

1.1 Make Teach Pendant **ON**-- Controller **T1**

1.2 Press **Select** button --Go to **Home program** -- **Execute**(Hold deadman+ Hold shift button and press FWD)

1.3 Press **Select** button --Go to **AutoHome program** -- **Execute**(Hold deadman+ Hold shift button and press FWD))

1.4 Press **FCTN** button-- Go to **ABORT ALL** press **Enter**

1.5 Press **Select** -- Go to **PNS001** Main program -- Press **Enter**

1.6 Make Teach Pendant **OFF --** Controller **Auto**

2 Manual Resetting procedure In **HMI**

2.1 Press **cycle stop --** Turn the switch to **Manual mode --** Press both **Reset Button**

2.2 After **Idle**

2.3 Press **cycle stop --** Turn the switch to **Auto mode --** Press both **Reset Button**

2.4 After **Idle**

2.5 Press **Cycle start**