

```
0addr=xxxxxxx,inst_out=xxxxxxxxxxxxxxxxx
10addr=0000000,inst_out=1011000000010010
20addr=00000001,inst_out=1100001101000101
30addr=00000010,inst_out=1101011001111000
40addr=00000011,inst_out=1110100110100000
50addr=00000100,inst_out=0000101010110000
60addr=00000101,inst_out=0001110001010101
70addr=00000110,inst_out=0010001101010000
80addr=00000111,inst_out=0011110100000000
90addr=00110010,inst_out=xxxxxxxxxxxxxxxxx
```

