PROFESSIONAL
 EDUCATION
 STORE
 Search on Arduino.cc



HARDIVARE

SOFTWARE

CLOUD

DOCUMENTATION


COMMUNITY

BLOG

ABOUT

This page is also available in 2 other languages Change language

English



The Arduino Reference text is licensed under a Creative Commons Attribution-Share Alike 3.0 License.

Find anything that can be improved? Suggest corrections and new documentation via GitHub.

Doubts on how to use Github? Learn everything you need to know in this tutorial.



Last Revision: 2019/02/21

Last Build: 2021/10/13

EDIT THIS PAGE

Reference > Language > Functions > Communication > Serial > Readstringuntil

Serial.readStringUntil()

Description

readStringUntil() reads characters from the serial buffer into a Str The function terminates if it times out (see setTimeout()).

Serial.readStringUntil() inherits from the Stream utility class.

Syntax

Serial.readStringUntil(terminator)

Parameters

Serial: serial port object. See the list of available serial ports for eaboard on the Serial main page.

terminator: the character to search for. Allowed data types: char.

Returns

The entire String read from the serial buffer, up to the terminator character

Notes and Warnings

The terminator character is discarded from the serial buffer.

See also

LANGUAGE Serial

LANGUAGE begin()



PROFESSIONAL EDUCATION STORE Search on Arduino.cc

F:A RD VARE SOFTWARE CLOUD DOCUMENTATION COMMUNITY BLOG ABOUT

LANGUAGE peek()

LANGUAGE flush()

LANGUAGE print()

LANGUAGE println()

LANGUAGE write()

LANGUAGE SerialEvent()

LANGUAGE stream.parseFloat()

Back to top

Trademark Help CenteNEWSLETTER FOLLOW US

Contact Us

Distributors Enter your email to sign up

Enter your email to sign up

Careers

© 2021 Arduino Terms Of Service Privacy Policy Security Cookie Settings

