




DIGITALIZED DPR — USER MANUAL

Integrated Project Management System — Adani Renewables

Document Type:	User Manual
Application:	Digitalized Daily Progress Reporting (DPR) System
Organization:	Adani Renewables
Version:	1.0
Document Status:	User Reference Guide

TABLE OF CONTENTS

1. Introduction
2. Application Overview
3. User Roles and Responsibilities
4. User Access and Login
5. Projects Screen
6. Navigation and Common Controls
7. Daily Progress Report Lifecycle
8. Supervisor – Daily Progress Entry
9. Working with DPR Sheets
10. Data Entry Rules
11. Adding DPR Activities
12. Auto-save and Manual Save
13. Solar Project Sheets
14. Wind Project Sheets
15. PSS Project Sheets
16. BESS Project Sheets
17. BESS Productivity

-
18. BESS Charging Schedule
 19. Issues and Hindrance Management
 20. Site PM – Review and Approval
 21. PMAG – Final Approval and P6 Push
 22. P6 Push Snapshot
 23. Send Delay Alerts
 24. Super Admin – Administration
 25. Common Features
 26. Drone Verification
 27. Reporting and Exports
 28. Notifications
 29. Automated System Behaviour
 30. Important Business Rules
 31. Troubleshooting
 32. Best Practices for Users
 33. Glossary

1. Introduction

1.1 Purpose of the Manual

The Digitalized DPR User Manual provides a comprehensive guide for users of the Digitalized Daily Progress Report application.

The manual explains the complete process of using the application, starting from user login and project access through daily progress entry, review, approval, and publishing approved progress to Oracle Primavera P6.

The application is designed to standardize daily progress reporting across renewable energy projects and eliminate dependency on manually maintained and circulated Excel reports.

1.2 Scope

This manual covers the following project types:

- Solar Projects
- Wind Projects
- Pooling Sub-Station (PSS) Projects
- Battery Energy Storage System (BESS) Projects

It also covers the responsibilities and workflows applicable to:

- Supervisors
 - Site PMs
 - PMAG Users
 - Super Administrators
-

2. Application Overview

Digitalized DPR provides a centralized platform for capturing, reviewing, approving, and publishing project progress.

The application integrates with Oracle Primavera P6 to ensure that users work with the latest project schedule and activity information.

2.1 Key Capabilities

Oracle P6 Integration

Project schedules, activities, WBS structures, planned dates, baseline dates, and related information are synchronized from Oracle P6.

Approved progress can subsequently be published back to Oracle P6.

Daily Progress Reporting

Supervisors can record daily progress through project-specific sheets designed for Solar, Wind, PSS, and BESS projects.

Review and Approval

Site PMs review submitted progress, make corrections where required, provide comments, approve sheets, or reject them for revision.

Final Approval and P6 Publishing

PMAG users perform the final review and can push approved progress to Oracle P6.

Issue and Hindrance Management

Users can record project issues, hindrances, delays, affected activities, required actions, and supporting attachments.

Reporting and Analytics

The application provides dashboards, charts, project summaries, exports, approval tracking, and progress analysis.

3. User Roles and Responsibilities

The application uses role-based access control. The features available to a user depend on the assigned role.

3.1 Supervisor

The Supervisor is responsible for day-to-day project progress reporting.

Responsibilities include:

- Entering daily progress
- Updating assigned DPR sheets
- Recording manpower and machinery information
- Adding DPR-level activities where permitted
- Recording issues and hindrances
- Reviewing entered information
- Submitting completed sheets to the Site PM
- Synchronizing project information from P6
- Exporting DPR information

Landing Screen:

Projects → Supervisor Dashboard

3.2 Site PM

The Site PM is responsible for reviewing and approving Supervisor submissions.

Responsibilities include:

- Reviewing submitted DPR sheets
- Editing submitted information when required
- Providing cell-level comments

- Rejecting incorrect entries
- Approving completed sheets
- Creating Supervisor accounts
- Managing Supervisor project assignments
- Monitoring submission status and performance

Landing Screen:

Projects → PM Dashboard

3.3 PMAG

PMAG is responsible for final review and approval before progress is published to Oracle P6.

Responsibilities include:

- Reviewing Site PM-approved sheets
- Performing final approval
- Rejecting submissions when required
- Pushing approved progress to Oracle P6
- Monitoring P6 push history
- Reviewing analytics
- Sending delay alerts
- Managing project access
- Managing projects within assigned scope

Landing Screen:

Projects → PMAG Dashboard

3.4 Super Admin

The Super Admin has complete administrative access to the application.

Responsibilities include:

- User management
- Access request management
- Project management
- Role management
- Workflow management
- Sheet entry monitoring
- System analytics
- System logs
- P6 password maintenance
- Administrative project assignment

Landing Screen:

4. User Access and Login

4.1 Opening the Application

Open the Digitalized DPR application URL using a supported web browser.

The Digitalized DPR welcome screen provides two login options:

- SSO LOGIN
- EMAIL ACCESS

4.2 SSO LOGIN

SSO is the recommended login method for Adani users.

Steps:

1. Select SSO LOGIN.
2. The application redirects the user to the Adani Single Sign-On page.
3. Enter the corporate credentials.
4. Complete the authentication process.
5. The user is redirected to the Digitalized DPR application.

No separate Digitalized DPR password is required for SSO users.

4.3 EMAIL ACCESS

Users who are permitted to use email authentication can log in using their registered credentials.

Steps:

1. Select EMAIL ACCESS.
2. Enter the registered email address.
3. Enter the password.
4. Select LOGIN.

Select GO BACK to return to the login selection screen.

4.4 First-Time Access Request

If a user successfully authenticates through SSO but does not yet have an application role, the system displays the Welcome to Digitalized DPR screen.

The user must:

1. Verify the displayed email address.
2. Select the required role.
3. Enter a Justification, if required.
4. Select Request Access.

Available role requests include:

- Supervisor
- Site PM
- PMAG (Admin)

After submission, the system displays the Request Submitted screen.

The system automatically checks the access status periodically.

The Check Status option can be used to perform an immediate status check.

Once access is approved, the system displays Access Granted.

The user must select Enter Platform and sign in again to obtain the updated permissions.

4.5 Sign Out

To sign out:

1. Select the circular user avatar in the top-right corner.
2. Select Log out.

5. Projects Screen

After successful authentication, users are taken to the Projects screen based on their role and access permissions.

5.1 Project Search and Filters

The following filters are available:

Filter	Purpose
Search	Searches projects by name
Type	Filters Solar, Wind, PSS, or BESS projects
Year	Filters projects by financial year
EPS	Filters projects based on the parent EPS

Projects are displayed 10 per page.

Changing a filter automatically resets the page to Page 1.

Recently accessed projects appear at the top and are marked with a Recent badge.

5.2 Project Card Information

Each project card can display:

- Project Name
- P6 Project ID

- Project Type
- On Hold status
- Assigned sheet permissions
- Sync Date
- P6 Updated timestamp

For P6 Updated information, hovering over the value provides additional information about the last update.

5.3 Project Actions

Action	Applicable Users	Purpose
Assign	Site PM, PMAG, Super Admin	Assigns project access
Sync	All roles	Synchronizes project information from P6
Summary	Site PM, PMAG, Super Admin	Opens project summary
Project Card	All roles	Opens the project dashboard

6. Navigation and Common Controls

The top navigation bar provides access to frequently used application features.

6.1 Application Logo

The Adani logo is displayed on the navigation bar.

When working inside a project, the project name and P6 ID are also displayed.

6.2 Theme Toggle

The Theme Toggle allows users to switch between:

- Light Mode
- Dark Mode

6.3 Notifications

The notification bell displays:

- New submissions
- Approvals
- Rejections
- Other workflow notifications

The red badge indicates the number of unread notifications.

Users can open an individual notification or select Mark all as read.

6.4 Issues Notification

Site PM and PMAG users can access the Issues notification bell.

The orange badge indicates newly raised issues.

6.5 E&D Sheets

The E&D Sheets section provides access to:

- Summary
- Engineering
- Ordering
- Delivery

6.6 Live Sheets

Live Sheets provides direct access to the project's DPR data-entry sheets.

6.7 User Avatar Menu

The avatar menu provides access to role-specific functions such as:

- Home
- View Issues
- Add Issue
- Dashboard
- Manage Projects
- Snapshot Filter
- Projects
- Log out

7. Daily Progress Report Lifecycle

Each DPR sheet follows a controlled workflow.

The standard process is:

Supervisor → Site PM → PMAG → Oracle P6

7.1 Workflow Stages

Status	Description
Draft	Sheet is being prepared by the Supervisor

Status	Description
Submitted to PM	Sheet has been submitted for Site PM review
Approved by PM	Site PM has approved the sheet
Final Approved	PMAG has completed final approval
Pushed to P6	Approved progress has been published to Oracle P6
Rejected by PM	Sheet has been returned to the Supervisor
Rejected by PMAG	Sheet has been returned to the Site PM

The workflow stepper displayed on the sheet indicates the current stage.

7.2 Rejection Process

When a sheet is rejected, the reviewer can provide:

- Overall rejection reason
- Cell-level rejection comments
- Specific correction instructions

The user must correct the identified information and resubmit the sheet.

8. Supervisor – Daily Progress Entry

8.1 Opening a Project

1. Open the Projects screen.
2. Locate the required project.
3. Select the project card.
4. The Daily Progress Report screen opens.

If the project cannot be loaded, select Select Project and return to the Projects screen.

8.2 Report Date

The Report Date determines the date for which progress is being entered.

The default value is the current date.

Future dates cannot be selected.

Before entering data, always verify the Report Date.

All sheets, saved values, and submissions are associated with the selected report date.

8.3 Header Actions

The Daily Progress Report screen provides the following actions:

Action	Purpose
Sync Project	Retrieves the latest project information from P6
Global Submit	Submits all changed draft sheets
Compare with Drone	Compares DPR quantities with drone data where enabled
Change Project	Returns to the Projects screen

8.4 Project-Specific Sheets

Solar

- Summary
- DP Qty
- DC Side
- AC Side
- Testing & Commissioning
- Labour Days
- Manpower (Contractor)
- Machinery Sheet
- Issues

Additional Rajasthan sheets:

- Switchyard
- Transmission Line
- Infra Works

Wind

- Summary
- Progress Sheet
- Stone Column
- 33KV
- Erection
- Labour Days
- Manpower (Contractor)
- Machinery Sheet
- Productivity
- Issues

Additional sheets may include:

- PSS
- EHV

PSS

- Summary
- Civil and PEB
- Electrical
- 400KV Transmission Visual
- 400KV Transmission
- Manpower
- Manpower (Contractor)
- Issues

BESS

- Summary
- DP Qty
- Civil
- Electrical
- Testing & Comm.
- Manpower
- Productivity
- Charging Schedule
- Issues

9. Working with DPR Sheets

9.1 Grid Toolbar

The standard DPR grid provides:

- Save
- Submit
- Filters
- Changed Only
- Cols
- Export
- Fullscreen

9.2 Save

The Save option stores the changes made to the sheet.

A confirmation message may be displayed before saving.

9.3 Submit

Submit sends the current sheet to the next workflow stage.

The system requests confirmation before submission.

9.4 Filters

Filters allow users to narrow the displayed records based on column values.

Selecting Clear removes the applied filters.

9.5 Changed Only

Changed Only displays only rows that have been modified.

This is useful for reviewing updates before submission.

9.6 Columns

Cols allows users to show or hide individual columns.

9.7 Export

Two export options are available:

- This Sheet – exports the current sheet
- Entire Project – exports all project sheets into one Excel workbook

9.8 Fullscreen

Fullscreen expands the data grid to use the available screen area.

10. Data Entry Rules

10.1 Editable and Read-Only Cells

Cells can be classified into:

- Editable cells
- Read-only cells
- Calculated cells

Information received directly from P6, such as Activity ID, Block, Status, and baseline dates, is generally read-only.

Calculated values such as Balance, Gap, and certain progress percentages are also system-controlled.

10.2 Entering Data

To enter information:

1. Select the required cell.
2. Enter the required value.
3. Move to another cell.
4. Review the highlighted changes.

Supported data types may include:

- Text
- Numbers
- Dates
- Dropdown values

10.3 Clipboard Operations

The following standard keyboard shortcuts are supported:

- Ctrl + A – Select
- Ctrl + C – Copy
- Ctrl + V – Paste
- Ctrl + X – Cut

10.4 Column Resizing

Column widths can be adjusted by dragging the right edge of the column header.

Column width changes apply during the current session.

11. Adding DPR Activities

Certain sheets support activities that are not available in P6.

11.1 Add DPR Activity

Add DPR Activity allows users to create an individual DPR-level activity.

Typical information includes:

- Description
- Quantity / Scope
- Section
- Location
- Vendor
- Priority
- Duration
- Feeder
- Remarks

11.2 Upload Activities

Upload Activities allows multiple DPR activities to be uploaded using Excel.

Process:

1. Select the download template option.
2. Complete the template.

3. Upload the completed file.
4. Review the uploaded rows.
5. Correct or remove invalid rows.
6. Confirm the upload.

11.3 Generate DPR Activities

Generate DPR Activities is available only for BESS Civil, Electrical, and Testing & Comm. sheets.

The function reads applicable P6 activities and automatically creates corresponding DPR-level activities.

The function:

- Avoids duplicate activities
- Supports new activities added to P6
- Groups activities under appropriate headings
- Creates initial values for scope and status

The Activity Filter can be set to DPR Level Activities to review the generated records.

12. Auto-save and Manual Save

12.1 Draft Sheets

Draft sheets are automatically saved approximately two seconds after the user stops editing.

12.2 Submitted or Approved Sheets

Auto-save is disabled after submission or approval.

If an authorized user modifies a submitted or approved sheet, the user must explicitly select Save.

This prevents approved data from unintentionally returning to Draft status.

13. Solar Project Sheets

13.1 Solar Summary

The Solar Summary is a read-only roll-up of project progress.

It includes:

- S.No
- Description
- UOM
- Scope
- Completed
- Balance

- Percentage Completed
- Required Labour
- Available Labour
- Labour Gap
- MW information
- Baseline Dates
- Actual Dates

The summary primarily consolidates information from DP Qty, Labour Days, DC Side, and AC Side. Only P6 activities coded as CC are included in the Solar Summary.

13.2 DP Qty

DP Qty is a read-only consolidated quantity view.

It displays:

- Activity
- Description
- Status
- UOM
- Scope
- Completed
- Balance
- Baseline Dates
- Actual Dates
- Forecast Dates
- Historical progress
- Previous-day progress
- Current-day progress

Users should enter quantities in the relevant source sheets rather than directly in DP Qty.

13.3 DC Side

The DC Side sheet contains DC-related project activities.

Editable fields include:

- Description
- Priority
- Contractor Name
- UOM
- Scope
- Physical Progress %
- Actual Start
- Actual Finish
- Resource
- Historical date values

- Previous-day quantity
- Current-day quantity

Read-only fields include:

- Activity ID
- Block
- Completed
- Balance
- Baseline Dates
- Forecast Dates

13.4 AC Side

The AC Side sheet follows the same structure as the DC Side sheet and is used for AC-related activities.

The editable and read-only field behaviour follows the same rules as the DC Side sheet.

13.5 Testing and Commissioning

The Testing and Commissioning sheet follows the DC/AC progress structure.

The Resource field is not included.

Editable information includes:

- Description
- Priority
- Contractor Name
- UOM
- Scope
- Physical Progress %
- Actual Dates
- Historical progress
- Daily progress

13.6 Labour Days

The Labour Days sheet records manpower requirements and availability.

Fields include:

- Activity ID
- Description
- Block
- Hours/Day
- Required
- Available
- Gap
- Percentage Completion

- Historical dates
- Previous-day values
- Current-day values

Gap and Percentage Completion are calculated by the system.

13.7 Manpower – Contractor

This sheet provides a time-phased contractor manpower plan.

Each date contains:

- Contractor
- Required
- Available
- Gap

Contractor, Required, and Available values are editable.

Gap is calculated automatically.

13.8 Machinery Sheet

The Machinery Sheet records equipment deployed by contractors.

Fields include:

- S.No
- Contractor Name
- Machinery
- UOM
- Date-wise quantities
- Remarks
- Actions

Contractor Name, date-wise quantities, and Remarks can be updated.

13.9 Rajasthan-Specific Sheets

Certain Rajasthan Solar projects include:

- Switchyard
- Transmission Line
- Infra Works

These sheets follow the general structure of the AC Side sheet.

They are displayed only when the project WBS contains the corresponding scope.

14. Wind Project Sheets

14.1 Wind Summary

The Wind Summary provides a consolidated view of project achievement.

It includes:

- Scope
- Achieved
- Balance
- Weekly Plan
- Weekly Achieved
- Weekly Balance
- Monthly Plan
- Monthly Achieved
- Monthly Balance

14.2 Progress Sheet

The Progress Sheet is the primary Wind activity sheet.

It includes:

- Activity ID
- Description
- Status
- Substation
- SPV
- Location
- Activity Group
- Feeder
- Vendor details
- Foundation information
- Soil Test Status
- Coordinates
- Resource
- Scope
- Completed
- Physical Progress %
- Baseline Dates
- Actual Dates
- Forecast Dates

The sheet also provides a No of Days field.

When the Date Filter is changed to Delayed Activities, the sheet displays No of Days Delay.

14.3 Stone Column

The Stone Column sheet records ground-improvement activity.

Fields include:

- Location
- Vendor
- PSS
- Drawing Status
- RIG
- Length
- Number of Columns
- Plan
- Achieved
- Balance
- Start Date
- Finish Date
- Date-wise Plan
- Date-wise Actual

14.4 33KV

The 33KV sheet varies depending on project configuration.

Underground Cabling

Fields include:

- Cable From
- Cable To
- Total Length
- Termination End
- Jointing Kit
- Today
- Cumulative
- Balance
- Jointing Cumulative
- Jointing Balance
- Termination Cumulative
- Termination Balance

Overhead Lines

Fields include:

- Vendor
- Feeder Name
- Type of Line
- Back-to-Back Line

- Final Line
- Total Locations
- Activity-specific Scope
- Completed
- Balance

14.5 Erection

The Erection sheet records WTG erection milestones.

It includes:

- WTG Location
- Crane Number
- Crane Assembly dates
- Crane Boom dates
- Tower Erection dates
- Nacelle Erection dates
- DT Erection dates
- Hub Erection dates
- Blade Erection dates
- Nacelle Cover completion
- Crane Dismantling dates
- Crane Intercarting dates
- Remarks

It also records time-loss information related to:

- High Wind / Rain
- AGEL ROW
- Front availability
- WTG material availability
- Crane breakdown
- Tools and tackles breakdown
- Crane manpower
- Contractor issues
- Tensioning and torquing manpower/tools

14.6 Wind Labour Days

The Wind Labour Days sheet records:

- Activity ID
- Description
- Block
- Hours/Day
- Budgeted Days

- Actual Days
- Remaining Days
- Percentage Completion
- Actual Start
- Actual Finish
- Forecast Start
- Forecast Finish
- Previous-day value
- Current-day value

14.7 Wind Productivity

The Productivity sheet tracks monthly productivity for:

1. Stone Column
2. WTG Foundation
3. WTG Erection
4. WTG Commissioning

Users enter resource information, such as:

- Rigs
- Gangs
- Crane Packages
- Commissioning resources

The system calculates the corresponding output and productivity.

15. PSS Project Sheets

15.1 PSS Summary

The PSS Summary is an editable sheet.

Fields include:

- S.No
- Description
- Duration
- Start Date
- End Date
- UOM
- Scope
- Completed
- Balance
- Actual Start

- Actual Finish
- Forecast Start
- Forecast Finish
- Remarks

Balance is calculated automatically.

15.2 Civil and PEB

The Civil and PEB sheet records project execution activities.

Fields include:

- Description
- Block
- Status
- Priority
- Duration
- Plan Start
- Plan Finish
- Actual Start
- Actual Finish
- Forecast Start
- Forecast Finish
- SO Vendor Name
- UOM
- Scope
- Completed
- Physical Progress %
- Balance
- Remarks

Physical Progress % and Balance are system-controlled.

15.3 Electrical

The Electrical sheet follows the same general structure as Civil and PEB.

15.4 400KV Transmission

The 400KV Transmission sheet uses the same general progress structure.

15.5 400KV Transmission Visual

This sheet provides a simplified quantity tracker.

Fields include:

- S.No
- Description
- UOM
- Total Quantity

- Completed
- WIP
- Balance

15.6 PSS Manpower

The Manpower sheet records:

- Activity
- Description
- Area
- Department
- Scope
- Cumulative Completed
- Historical values
- Previous-day value
- Current-day value

16. BESS Project Sheets

16.1 BESS Summary

The BESS Summary provides a plan-versus-actual comparison.

It includes:

- Activity
- UOM
- Total Scope Quantity
- Completed
- Yesterday Progress
- Base Plan
- Catch Up Plan
- Actual
- Cumulative Base Plan
- Cumulative Catch Up Plan
- Cumulative Actual
- Deviation Plan vs Actual
- Balance Quantity
- Status Percentage
- Remarks

The Trade Filter allows users to select:

- Civil

- Electrical
- Testing
- All Trades

The default selection is Civil.

16.2 BESS DP Qty

DP Qty is a read-only roll-up of BESS quantity progress.

The values are derived from:

- Civil
- Electrical
- Testing & Commissioning

Users should enter daily quantities in the respective work sheets.

16.3 BESS Civil

The Civil sheet contains P6-backed activities.

Fields include:

- Activity ID
- Description
- Block
- Status
- Priority
- Duration
- Vendor
- UOM
- Scope
- Completed
- Physical Progress %
- Balance
- Baseline Dates
- Actual Dates
- Forecast Dates
- Historical dates
- Daily quantities
- Remarks

16.4 BESS Electrical

The Electrical sheet follows the same structure as the Civil sheet.

16.5 BESS Testing and Commissioning

The Testing and Commissioning sheet follows the same general structure.

16.6 BESS Manpower

The BESS Manpower sheet records:

- Activity
- Description
- Area
- Department
- Scope
- Cumulative Completed
- Historical values
- Previous-day value
- Current-day value

DPR-level activities can also be added where permitted.

17. BESS Productivity

The BESS Productivity sheet is a standalone checklist.

The sheet includes:

- Container Make
- Block Number
- Serial Number
- Activity
- Seven date-wise columns

The sheet initially displays no data.

Selecting Add Row loads the complete productivity checklist.

The checklist contains:

- Civil activities
- Electrical activities

A subsequent Add Row action creates another complete copy of the checklist.

The delete/bin action removes the most recently added copy.

18. BESS Charging Schedule

The Charging Schedule tracks the commissioning and energization activities of BESS containers.

18.1 Information Captured

The sheet includes:

- Container Make

- Block Number
- Containers at Site
- MWh
- IDT Charging / Commissioning Start
- Trail-Run End Date
- COD
- Activity
- Progress
- EDC
- New EDC
- Vendor
- Productivity
- Manpower
- Total Mandays
- Remarks

18.2 Progress Calculation

Progress consists of:

- Scope
- Completed
- Balance

Balance is automatically calculated as:

Scope – Completed

18.3 P6 Integration

Where the activity matches a P6 activity, Scope and Completed values are automatically populated.

These values are displayed in blue and bold and become read-only.

Activities without a corresponding P6 record can be updated manually.

18.4 Automatic Date Calculation

When IDT Charging / Commissioning Start is entered:

Trail-Run End Date = IDT Date + 3 Days

COD = Trail-Run End Date + 2 Days

The calculated dates remain editable.

The system displays a status indicator showing whether the COD interval follows the standard two-day gap.

19. Issues and Hindrance Management

The Issues module provides centralized tracking of project hindrances and delays.

19.1 Creating an Issue

Select Add Issue from the Issues sheet or the user menu.

Enter:

- Description
- Location
- WBS
- Activity
- Start Date
- Finished Date
- Delayed Days
- Status
- Priority
- Action Required
- Notification Email
- Remarks
- Attachment

19.2 Issue Status

Available statuses include:

- Open
- In Progress
- Resolved
- Closed

19.3 Issue Priority

Available priorities include:

- Low
- Medium
- High
- Critical

19.4 Managing Existing Issues

Users with appropriate permissions can:

- Edit issues
- Delete issues
- Update issue status
- Review issue details

Site PM and PMAG users can monitor issues through the Issues notification area.

20. Site PM – Review and Approval

20.1 PM Dashboard

The PM Dashboard provides:

- Project information
- Submission statistics
- Sheet status
- Supervisor performance
- Charts
- Refresh option

Selecting a statistic tile opens the corresponding sheet list.

20.2 Reviewing a Sheet

To review a submitted sheet:

1. Open the PM Dashboard.
2. Select the relevant statistic tile.
3. Select the required sheet.
4. Select Edit.
5. Review the submitted information.
6. Correct information where necessary.
7. Add comments or rejection marks if required.
8. Save or approve the sheet.

20.3 Cell-Level Review

The Site PM can flag individual cells rather than rejecting the complete sheet.

The flagged cells are displayed to the Supervisor with rejection highlighting and comments.

20.4 Approval

Select Approve to move the sheet to Approved by PM.

The sheet is then available to PMAG for final review.

20.5 Rejection

Select Reject and provide a clear reason.

A specific reason should be provided so the Supervisor understands the required correction.

Example:

■ *"Block 4 DC quantity exceeds the approved scope."*
is preferable to:

■ *"Incorrect data."*

21. PMAG – Final Approval and P6 Push

21.1 PMAG Dashboard

The PMAG dashboard provides key statistics including:

- Approved Sheets
- Pushed Sheets
- Archived Sheets
- Team Members

Additional tools include:

- Compare with Drone
- P6 Push Snapshot
- Send Delay Alerts

21.2 Final Review

PMAG can:

- Edit
- Save
- Approve
- Reject
- Push to P6

The PMAG user must verify the information before publishing it to Oracle P6.

21.3 Push to P6

To publish approved progress:

1. Open Approved Sheets.
2. Select the required sheet.
3. Review the data.
4. Select Push to P6.

Alternatively, use Save & Push when changes are made during the review.

The application displays the push progress.

After completion, the application automatically synchronizes the project with P6.

If errors occur, the system displays the relevant error information.

21.4 P6 Password Expiry

If the P6 integration password has expired, the push process is blocked.

The Super Admin must update the P6 password before integration activities can resume.

22. P6 Push Snapshot

The P6 Push Snapshot provides historical and analytical information.

It includes:

- Push History
- Date-to-Date Comparison
- Top Movers by Variance
- Push Frequency
- Push Success Rate
- Cumulative Progress Trend
- Sheet Type Breakdown

This information can be used to monitor the quality and frequency of P6 updates.

23. Send Delay Alerts

PMAG users can generate the Delayed Activities report and send it to the configured recipients.

The generated report provides information about activities that are experiencing schedule delays.

24. Super Admin – Administration

24.1 Users

The Users tab provides complete user management.

Information includes:

- Name
- Email
- Role
- Status
- Created At

Administrators can:

- Search users
- Filter users
- Create users
- Edit users
- View users
- Assign projects

PMAG users can also be assigned an EPS.

24.2 Access Requests

The Access Requests tab displays pending access requests.

Information includes:

- User
- Request Type
- EPS / Project
- Justification
- Status
- Date

Administrators can:

- Approve requests
- Reject requests
- Assign roles
- Review request history

24.3 Projects

The Projects tab provides centralized project administration.

Information includes:

- Project ID
- Project Name
- Type
- Start Date
- End Date
- Visibility

Filters include:

- Project Name
- Status
- Visibility
- Type
- Year

Project actions include:

- View
- Edit
- Sync from P6

24.4 Bulk Project Actions

Administrators can select multiple projects and perform:

- Sync Selected
- Mark Live
- Put Hold
- Sync New Projects

24.5 Sheet Entries

The Sheet Entries tab provides access to DPR sheet records across projects.

This section supports monitoring, auditing, and administrative troubleshooting.

24.6 Role Management

The Role Management section provides:

- Role information
- Assigned permissions
- User count
- Permission management

24.7 Workflow Overrides

Workflow Overrides allows authorized administrators to manage exceptional workflow situations.

Information includes:

- Sheet ID
- Project
- Submitted By
- Status
- Available Override Action

Overrides require confirmation before execution.

24.8 Analytics

The Analytics tab provides system-wide information across projects and users.

24.9 System Logs

System Logs provide an audit trail of application activities.

Automatic system actions, including auto-approvals, are also recorded with the applicable reason.

25. Common Features

25.1 E&D Sheets

Engineering and Delivery information can be accessed through:

- Summary
- Engineering

- Ordering
- Delivery

Each section provides search and date filtering.

The current tab or all tabs can be exported to Excel.

25.2 Project Summary

Authorized users can select Summary from a project card.

The Project Summary provides:

- Activity Table
- Charts

The information is read-only.

26. Drone Verification

Drone Verification is available for selected drone-enabled projects.

The feature compares reported DPR progress against drone survey information.

The comparison includes:

- Source API
- DPR Cumulative
- Drone Total
- Variance
- Status

Activities identified as Over-Reported are highlighted for review.

27. Reporting and Exports

The application supports Excel-based exports.

27.1 This Sheet

Exports the currently selected sheet.

27.2 Entire Project

Exports all available project sheets into a single Excel workbook.

27.3 Historical Analytics

Historical exports may include an Analytics tab containing progress analysis and category-wise reporting.

Wind Productivity also supports a dedicated export.

28. Notifications

The notification system provides workflow-related alerts.

Notifications may be generated for:

- Sheet submissions
- Approvals
- Rejections
- Other workflow events

Users can select a notification to navigate directly to the relevant sheet.

The Mark all as read option clears the unread notification count.

29. Automated System Behaviour

The application performs several automated activities.

Automated Function	Frequency / Trigger	Purpose
Draft Auto-Save	Approximately 2 seconds after editing	Protects draft work
Charging Schedule Date Calculation	When IDT date is entered	Calculates Trail-Run and COD
Charging Schedule P6 Lookup	When sheet loads	Retrieves matching P6 quantities
Auto-Approval	Hourly	Prevents sheets remaining indefinitely in review
Auto-Finalisation	Hourly	Prevents approved sheets remaining indefinitely
Project Synchronization	Daily at 01:00	Retrieves new and updated P6 information
P6 Password Check	Daily at 10:00	Identifies upcoming credential expiry
Access Status Check	Every 30 seconds	Updates pending access requests
Maintenance Detection	When backend is unavailable	Displays system maintenance information

30. Important Business Rules

30.1 Project Assignment

A project is normally assigned to a user when the user is created.

The assignment cannot normally be changed afterward.

If a project needs to be assigned to another person, a new user should be created with the appropriate project assignment.

Super Admin users have additional administrative assignment capabilities.

30.2 Project Access

Supervisors and Site PMs generally see projects assigned to them.

PMAG users can have project-level or EPS-level access.

30.3 P6-Controlled Information

Information originating from P6 is generally protected from direct modification.

Users should update the appropriate editable DPR fields instead of attempting to overwrite system-controlled values.

30.4 Daily Reporting

Each sheet is maintained separately for each report date.

Submitting one sheet does not automatically submit another sheet unless Global Submit is used.

31. Troubleshooting

Issue: Welcome to Digitalized DPR is displayed after login

The user does not yet have an approved application role.

Solution:

Submit an access request by selecting the required role and selecting Request Access.

Issue: Access has been approved but the application still shows the old permissions

Solution:

Sign out and sign in again.

A previously issued session does not automatically receive the newly approved role.

Issue: Expected project is not visible

Check:

1. Project filters.
2. User project assignment.
3. Project status.
4. Project visibility.
5. Whether the project is On Hold.

Contact the Site PM, PMAG, or Super Admin if the project remains unavailable.

Issue: Required sheet is not visible

Check the user's sheet permissions.

Some sheets are conditionally displayed depending on:

- Project type
- Project WBS
- Project location
- Project configuration

Issue: 33KV sheet is different between two Wind projects

This is expected.

Different Wind project locations may use different 33KV layouts, such as underground cabling or overhead-line reporting.

Issue: BESS Summary contains limited information

Check the Trade Filter.

The default selection is Civil.

Select Electrical, Testing, or All Trades as required.

Issue: Solar Summary displays "No matching CC activities found"

The Solar Summary uses P6 activities coded as CC.

Ask the project planner to verify the P6 activity coding.

Issue: Physical Progress % cannot be edited

Physical Progress % is system-controlled for applicable PSS and BESS sheets.

Update Completed instead.

Issue: DP Qty cannot be edited

DP Qty is a roll-up sheet.

Enter progress in the applicable source sheet.

The values will be reflected in DP Qty automatically.

Issue: BESS Productivity or Charging Schedule is empty

Select Add Row to load the required checklist.

Issue: Add Row was selected multiple times

Each Add Row action creates another complete checklist copy.

Use the bin icon to remove the most recently added copy.

Issue: Generate DPR Activities does not create activities

The P6 activities may not follow the standard BESS activity naming structure.

Use Upload Activities to add the required activities manually.

Issue: Deleted activities reappear after Generate DPR Activities

This is expected behaviour.

Generate DPR Activities recreates activities that are missing from the standard list.

Issue: Charging Schedule Scope or Completed is read-only

Blue and bold values indicate that the information has been matched to P6.

Update the applicable source DPR sheet instead.

Issue: Charging Schedule rows are highlighted yellow

These are DPR-level Electrical activities without corresponding P6 scope.

They should be entered and maintained manually.

Issue: Activities or dates are outdated

Select Sync Project to retrieve the latest P6 information.

Verify the Sync Date and P6 Updated information on the project card.

Issue: Unknown Project Type

The project type has not been correctly configured.

Contact the Super Admin and request an update in the Projects section.

Issue: Global Submit does not find changed sheets

Check:

- Report Date
- Whether changes were made
- Whether sheets have already been submitted

The selected Report Date must match the date for which the data was entered.

Issue: Changes to an approved sheet are not automatically saved

This is expected.

Auto-save is disabled after submission or approval.

Select Save explicitly.

Issue: Push to P6 fails because of password expiry

The P6 integration password has expired.

Contact the Super Admin to update the P6 credentials.

Issue: Sheet was automatically approved

Sheets that remain in the Submitted to PM state beyond the configured threshold may be automatically approved.

The automatic action is recorded in the system logs.

Issue: Maintenance screen is displayed

The application backend may be temporarily unavailable.

Wait for the service to become available and reload the application.

If the issue continues, contact the system administrator.

32. Best Practices for Users

Users should follow the practices below to maintain accurate and reliable DPR information.

1. Always verify the Report Date before entering progress.
2. Synchronize the project when schedule information appears outdated.
3. Enter progress only in the appropriate editable fields.
4. Do not attempt to modify P6-controlled or calculated fields.
5. Review Changed Only before submitting a sheet.
6. Use meaningful comments when responding to rejected cells.
7. Record project hindrances as soon as they are identified.
8. Verify quantities and dates before submitting.
9. Use Global Submit only after confirming that all required sheets are complete.
10. Review the workflow status after submission.
11. Site PMs should provide specific rejection reasons.
12. PMAG users should verify approved information before pushing it to P6.
13. Super Admins should regularly monitor access requests, system logs, and P6 credentials.

33. Glossary

Term	Definition
DPR	Daily Progress Report
P6	Oracle Primavera P6 scheduling system
P6 ID	Project identifier in Oracle P6
EPS	Enterprise Project Structure
WBS	Work Breakdown Structure
PMAG	Project Management Assurance Group
BESS	Battery Energy Storage System
PSS	Pooling Sub-Station
WTG	Wind Turbine Generator
Block	Location unit used primarily in Solar and BESS projects
SPV	Special Purpose Vehicle
PEB	Pre-Engineered Building
WIP	Work in Progress
BCT	Battery Container Terminal

Term	Definition
IDT	Initial Dispatch Test
COD	Commercial Operation Date
EDC	Expected Date of Completion
Catch Up Plan	Recovery plan quantity used in BESS reporting
DPR-Level Activity	Activity maintained in DPR but not available in P6
Baseline	Approved schedule dates maintained in P6
Forecast	Projected schedule dates
Data Date	Date representing the current schedule position in P6
CC Activity	P6 activity coded as CC
Draft	Sheet currently being prepared
Push	Transfer of approved progress from Digitalized DPR to P6
Live	Project is active and visible to authorized users
On Hold	Project has been temporarily paused
Sheet Entry	One DPR sheet for one project and one report date
UOM	Unit of Measurement