Equipment

JULY 31, 2026



Contents

Overview....4
Inheritance....5
The Equipment Menu Bar....6
The Notification Area....9
The Nameplate Section....10
Additional Tabs....11
Information Tab....12
Administration –....13
Documentation Center....14
Lifecycle Tab....15
Risk Setup....16
History Log....17
Scheduled Events....18
Warranty....21
Information Services....22
Expansion....23
List View....24
The Tool Bar....24
View All Macros....24
Macro....24
Update....24
Risk Setup....24
Select Columns....25
Filter....25
Export....25
Popout View....25
Global Equipment Lookup....26
Schedule Event Change....27
Physical Inventory Verification....29
Model Equipment Sync....30
Conclusion....31

Equipment is the foundation of most Computerized Maintenance Management Systems (CMMS). Administrators manage a collection of assets that must be maintained, tracked, and cataloged. With modern CMMS platforms and comprehensive data collection, these systems are no longer limited to managing Scheduled Work Orders. Administrators can categorize equipment, analyze risk, configure Information Technology settings, support Capital Planning, and much more.

To achieve a full return on investment, administrators must understand essential workflows and key data elements. This begins with ensuring the safety of internal and external customers who rely on the organization's equipment. Regulatory requirements should then guide how equipment is maintained. Finally, employees must have an accessible and intuitive method for requesting repairs.

🛠️ Planning for Equipment Management

Some classes of Equipment require discussion and planning before they are added to the CMMS. These discussions should consider available labor, organizational policies, government regulations, and regulatory agency requirements.
For example, an organization may choose to track exit signs as individual assets. This approach offers several advantages:

- Individual maintenance history
- Accurate count of scheduled Work Orders
- Trending and analysis by area

However, this also means technicians may need to close hundreds of Work Orders instead of one. In such cases, a workflow must be created to streamline completion. There is no universal "one-size-fits-all" policy—organizations should regularly review their equipment management strategy as they grow or change.


📏 Equipment Standardization

Many organizations have multiple administrators entering data. Even with good intentions, data can become inconsistent or "dirty." It is important to standardize items such as descriptions, serial number formatting, and other fields that may allow for subjective interpretation.

For example, the same device may be entered as "Infusion Pump" or "Pump, Infusion." These minor differences can significantly affect reporting accuracy and system usability.
Phoenix Data Systems offers consulting services to help organizations establish best practices and maintain clean, consistent data across all equipment records.

Overview

The Equipment Control is located on the left side of the frame, just below the home option. Clicking the down arrow next to Equipment reveals additional options such as List View, Global Equipment Lookup, Scheduled Event Change, Physical Inventory Verification, and Model Equipment Sync. Selecting List View displays a complete list of all Equipment in the system. Clicking either the Equipment icon or the word Equipment opens the last Equipment record viewed by the user in the main viewing pane. Users will see four distinct areas within an Equipment Record:



- **Equipment Menu Bar**
- **Notification Area**
- **Nameplate Section**
- **Additional Tabs**

Each tab contains one or more groups of fields designed to capture relevant information for that section. These fields may include dropdowns, free-text fields, and date/time fields. Some fields also include input masks. For example, the IP Address field only accepts entries formatted as valid IP addresses.

Note: Red asterisks designate fields as required fields. Other fields can be set as required in System Setup.

Inheritance

AIMS 3 includes a function that allows records to inherit settings from other records. For example, if a User adds documents to a Model record, all Equipment linked to that Model will automatically inherit those documents. Any Work Orders created for those Equipment records will inherit the same documents as well. Because of this, it is not necessary to attach files to individual Equipment records. Using inheritance wherever possible is recommended to reduce manual work and ensure consistency.

Documents and other attributes should be placed at the highest level where they will still be effective. For example, if all Equipment of a specific Equipment Type requires an Incoming Inspection, the Incoming Inspection Schedule should be added to the Equipment Type not the Model. If every piece of Equipment added to the system requires an Incoming Inspection, it is best to configure this through Automation.

Note: If Administrators need additional consulting or training, Phoenix Data Systems can assist at any level. Please contact our sales Department or Project Managers for more information.

The Equipment Menu Bar

The Equipment Menu Bar provides quick access to common tasks. Some icons will be immediately recognizable, while others may not. To help users, AIMS 3 displays a tooltip showing what each button does when the user hovers the cursor over the icon. The Menu Bar is consistent for all users, ensuring a uniform experience across the system.



 **Save** - Allows User to Save an Equipment record once required fields have been populated.

 **New -** Creates a new Equipment record.

 **Duplicate** - This duplicates the Equipment record currently being viewed.

 **Delete** - Deletes any Saved or Unsaved Equipment record.

 **Undo –** Resets the Equipment to the previous save point.

 **First –** Returns the User to the first Equipment record in the Equipment List.

 **Previous –** Returns the User to the previous Equipment record in the Equipment List.

 **Next –** Advances to the next Equipment record in the Equipment List.


 **Last** – Advances to the last Equipment record in the Equipment List.

 **Link -** Allows the user to copy the displayed Equipment record's URL to the clipboard for forwarding or pasting into another location (e.g., email, webpage). Clicking the down arrow provides additional options, including emailing the link through the default browser and marking or unmarking the Equipment as a **Favorite**. Favorited Equipment and other records appear in the **Favorites** widget on the Home Screen.

 **Vendor Directory** – Opens the Vendor Directory to the listing of the Equipment's Manufacturer.




Find – Directs User to the Search Query screen where a single Equipment record, or multiple Equipment records can be filtered.



a) **General Search** – The Equipment Find window allows Users to search from a selection of Equipment and Equipment Fields and displays the results at the bottom of the window. Users can adjust which fields and grids are visible by clicking the Select Search Fields button  in the upper right corner of the window.


The dropdown "Grid Columns" allows the User to change the information viewed in the results grid. Equipment Filters change which fields the User can search. These changes are User-specific.

Clicking the Search button  in the Find window runs the search.


b) **History** – The History field records the ten previous searches and the quantity of results per User. Selecting a search and clicking "Rerun" will rerun the search with updated results. The rerun search will move the search to the top of the results instead of duplicating the search in the list.




Master Report – This will produce the Equipment Report showing all data for the Equipment record.



Notes – Contains all notes regarding the Equipment, including Equipment notes.




System Component – Allows the User to view or add any System/Component relationship for the Equipment.




Tools – Allows the User to conduct advanced functions regarding the Equipment.

Note: Depending on a User's access, they will see all, some, or none of the following items!



Hours of Operation – Shows the hours of operation for both the Equipment and the Cost Center (if assigned).



Change Tag Number – Allows the User to change the Tag Number.



Merge Tag Number – Allows the User to merge a Tag Number into another.




Cost Summary – A report which shows all historical costs for the Equipment.



System Component – Allows the User to designate the Equipment as a parent or child record to other Equipment.



View Parts Assigned – Shows all parts related to the Equipment. These can be assigned at the Model or Scheduled Event level. Parts used on previous Work Orders will also be displayed.



Customize IS – Allows the User to change the Information Services fields.



Audit Trail – Allows Users to view all previous changes to the Equipment.



Equipment Type/Model Expansion – Shows the Expansion fields (if applicable) on the Equipment Type and Model Data Managers.





Edit Data Manager – Allows Users to edit Data Managers on the fly without having to navigate to the Data Manager component. This depends on the User's Security Level.

Note: All drop-down menus throughout AIMS3 are managed by Data Managers. If a selection in a dropdown is not correct or does not exist, it must be entered through the Data Manager. Having the ability to adjust the Data Manager from the Equipment record saves time and effort for the user.


The Notification Area

The Notification Area provides administrators with a dedicated space to communicate valuable information directly on the Equipment record. This feature uses Custom Critical Messages, which allow administrators to highlight warnings, instructions, or status updates that users must be aware of when interacting with the Equipment.

Custom Critical Messages are fully configurable. Administrators can choose the color, priority, and wording of each message to ensure it stands out appropriately. For example, a red message may indicate a safety concern, while a yellow message may highlight an upcoming inspection or a temporary operational limitation. These messages appear prominently in the Notification Area, making them immediately visible to technicians, managers, and other users who open the Equipment record.
Administrators can tailor messages to fit a wide range of scenarios, such as:

- **Safety alerts** (“Do not operate—electrical hazard identified.”)
- **Regulatory reminders** (“This device requires annual calibration per state guidelines.”)
- **Operational instructions** (“Use only approved accessories with this equipment.”)
- **Temporary conditions** (“Unit is loaned to ICU until further notice.”)


Because these messages are customizable, administrators can ensure that critical information is communicated clearly and consistently across the organization. This helps reduce errors, improves compliance, and ensures that all users interacting with the Equipment have the most up-to-date information.



Custom Critical Messages are configured in the **System Setup → Custom Critical Messages** section of the software. Administrators can create, edit, and manage all notification types from this area, including message text, color coding, and priority level. Once configured, these messages become available for use across all Equipment records.

Custom Critical Messages are also visible to Requestors through **EasyNet**, ensuring that vital information such as safety warnings, operational limitations, or regulatory notes is communicated not only to technicians and administrators but also to end-users submitting service requests.

The Nameplate Section



The Nameplate Section holds the basic information regarding the equipment. This includes:

Tag Number – (free text) This is the primary identifying number for the equipment. Changing the Tag Number will show the new Equipment's record. A code reader has been provided to quickly add a Tag Number.
Asset Number – (free text) This is an alternate number for the equipment (vendor ID number, old tag number, etc.).
Manufacturer – (dropdown) This denotes the current manufacturer for the Model assigned to the Equipment.
Model – (dropdown) This is the Model number used by the manufacturer.


New Model- (Plus Icon) The New Model button is designed to assist staff when entering a new Equipment tag into the database and the required Model does not already exist. If a user is adding or updating an Equipment tag and no matching Model is available, clicking New Model allows administrators to quickly locate tags that do not have an existing Model and create the missing Model in the database.
Type – (dropdown) This field is to classify the type of Equipment. These can include:

- Air Handling Unit
- Exhaust Fan
- Fan Coil Unit
- Infusion Pump
- MRI

Model Name – (free text) This field can be used if the Model's name differs from the original Model number.
Description – (free text) This is a general description of the Equipment.
Serial – (free text) The assigned serial number by the manufacturer.
Original Manufacturer – (free text) The name of the manufacturer who originally built the Equipment, should the manufacturer have changed.
Risk Classification – (dropdown) Allows for the option to denote Equipment as "High Risk" or "Non-High Risk."

Note: Once established in System Set Up, the Risk Classification will auto populate once the Risk Set Up has been configured.

Additional Tabs

Using the Additional Tabs allows administrators to apply a wide range of important data to the Equipment record. These tabs help build a complete profile of each asset and support reporting, regulatory compliance, and long-term lifecycle management. Information available in these tabs includes:

- **General Information**
- **Lifecycle Information**
- **Risk Setup**
- **History Log**
- **Scheduled Events**
- **Warranty Information**
- **Information Services Data**
- **Custom Field**


While some fields may be required, it is not necessary to complete every field in every tab. Each organization must determine how much information is *wanted* versus *needed*. This balance often depends on staffing levels, reporting expectations, regulatory requirements, and the overall maturity of the CMMS program.

When developing Equipment workflows, administrators must evaluate whether the additional time spent entering detailed data will provide a meaningful return on investment through future reporting, analytics, or compliance tracking. Some organizations prefer minimal data entry to streamline operations, while others require extensive detail to meet internal standards or external regulatory demands.

To maintain consistency, organizations benefit from codifying these workflows, documenting which fields should be used, when they should be populated, and who is responsible for maintaining them. Clear guidance helps ensure long-term data quality and reduces confusion as staff roles change.

Note: As described in the Overview, certain information may be automatically inherited from the Type, Manufacturer, or Model level. This inheritance reduces repetitive data entry and helps maintain consistency across similar assets.

Information Tab



The **Information** tab contains core administrative data related to the Equipment. This includes three major components:

- **Location**
- **Administration**
- **Document Center**

These fields help define where the Equipment is physically placed, how it is managed, and what documentation is associated with it.

The **Location** field is driven by the organization's **Location Tree**, which is managed through **Data Managers → Location Tree**. The Location Tree is a hierarchical structure that represents physical areas across the organization. It follows a top-down format:

- **Facility**
- **Building**
- **Wing**
- **Floor**
- **Room**
- **Location**
- **Spot**


The tree filters options dynamically:

- After selecting a **Facility**, only Buildings within that Facility appear.
- After selecting a **Building**, only Wings within that Building appear.
- This continues down the hierarchy until the final Spot is selected.

A **Free Text Location** field is also available for unique or highly specific placement details that may not fit neatly into the hierarchical tree (e.g., "Nurse Station Cabinet," "Under Counter," "Temporary Storage Area").

> **Note: The Location Tree is optional. If the Location Tree is not used, it is recommended to make the Free Text Location field required. This ensures that every Equipment record still contains meaningful location information for technicians, administrators, and requestors.**

Administration – The Administration section contains fields regarding the Equipment ownership and status. By default, only Status and Service Department are required, but it is advised to utilize as many fields as possible for quality reporting.




- **Employees Assigned — Assigns specific employees or teams to the Equipment for all scheduled work.**
- **Vendor Assigned — Assigns a vendor, typically for warranty or contracted Equipment.**
- **Cost Center — Identifies the department or account that financially owns the Equipment.**
- **Responsible Center — Identifies the department where the Equipment is used or located.**
- **Status — Shows the current operational status of the Equipment.**
- **Status As Of — Date/time when the Status was last updated.**
- **Condition — Indicates the physical condition of the Equipment.**
- **Condition As Of — Date/time when the Condition was last updated.**
- **In Service Date — Date/time the Equipment was placed into service.**
- **Ownership — Indicates whether the Equipment is owned, rented, or leased.**
- **Service Department — Department(s) responsible for maintaining the Equipment.**
- **Trade — Assigns the trade responsible for servicing the Equipment.**
- **Site ID — Free-text field for vendor-assigned identification numbers.**
- **Equipment Classification — Displays the Classification linked to the Equipment Type.**
- **Critical Equipment/System — Marks the Equipment as critical to the organization.**

Documentation Center- Stores all files, documents, and images associated with the Equipment's Tag Number. Administrators and authorized users can:

- Click **New** to add a file
- Use **Browse** to locate and upload the file
- Add an optional description
- Designate an image file as the **default image** for the Equipment

Users with defined rights can also choose where each file will be visible:

- **Non-PM Work Orders**
- **PM Work Orders**
- **EasyNet**




This ensures that critical documents, such as manuals, photos, inspection reports, and vendor files, are available to the correct audience across the system.




Save - Saves the attachment.



New – Adds a new attachment. When the plus is clicked the window will include a section on the right side to "Browse" for the file or Users can drag and drop the file in the "File Details" section.






Additional Document Options — The drop-down arrow next to the plus icon gives staff three additional ways to add documentation to an Equipment record.

- **Network Path —** Allows users to enter a network path that points to a document stored online or on a shared drive.
- **Physical Location —** Lets users record where a physical, non-digital document is stored.
- **URL** — Allows users to save a web link instead of uploading a file.

Note: On mobile devices, browsing files will present the user with three options: taking a photo, selecting a photo from the Photo Library, or accessing the devices files application.

Lifecycle Tab

The Lifecycle tab helps administrators plan for Equipment retirement. By using lifecycle details along with cost tracking, administrators can determine when an asset should be replaced.




Manufactured Date – Indicates the date the Equipment was produced.
Purchase Information
Estimated Purchase Cost – Checkbox when used, the Purchase Cost displayed in next field is not an exact amount and simply an estimate.
Purchasing Facility – The Facility where the Equipment was purchased.
Purchasing Department – The Cost Center where the Equipment was purchased.
Supplier – The Supplier of the Equipment. This must be a Vendor with the "Equipment Supplier" checkbox checked in the Vendor Data Manager.
Purchase Order – Purchase Order number associated with purchase of Equipment.
Purchase Date – Date Equipment was purchased by the Organization.
Purchase Cost – Cost (exact or estimated amount) of Equipment.
End of Life
Replacement Cost – Cost of new, used, or comparable replacement Equipment.
Replacement Date – Date Equipment was replaced. If set by an Administrator, this field will automatically calculate from the Useful Life and In Service Date fields.
Salvage Value – Value of salvaged Equipment.
Salvage Date - Date Equipment was salvaged.
Life Expectancy
Manufactured Date – Date Equipment was manufactured.
Depreciated Life – Number of years Equipment has depreciated in useful life.
Useful Life – Number of years Manufacturer recommends using Equipment before replacing.
End of Support – Allows the user to enter dates and to show when support will end. This information can be added directly to the Equipment of can be inherited from the Model.

Risk Setup

The Risk Setup tab lets users assign a pre-configured Risk Type to the Equipment. Risk Types are usually set at the Model level for consistency, but administrators can override them at the Equipment level when needed.


- **Risk Types:** Are created in the System Setup component and must be assigned to Service Departments inside of the Data Managers component after they are created.



Note: For a complete overview of the Risk function, Users should refer to the Risk How-To Guide.

History Log

This area lets users review the Work Order history for any Equipment Record inside of your Database. By selecting the Go To icon on the far right of the Work Order line, users can open Work Orders tied to the Equipment record they are currently viewing.



A Model History button is included in the upper left corner to show Work Orders from all Equipment records of the same Model.

A column selector is included in the upper right corner to allow users to add or remove displayed columns. Next to the column selector is an export button, so the user can export the list to an Excel file. To the right of the Export button is a Pop Out View button.



Open PM – Indicates whether there currently is an Open Preventative Maintenance Work Order on this Equipment.

Next PM – Indicated when the next Preventative Maintenance Work Order is scheduled to be generated.

Last Closed PM – Indicates date of last closed Preventative Maintenance Work Order.


Last Inventoried - Shows the date the Equipment was last inventoried.

Inventoried By - Shows the user who completed the most recent inventory check.

Note: If you click on the icon, it allows users to see more information regarding the open, upcoming, or last closed PM.


Scheduled Events

The Scheduled Events tab lets users assign Preventative Maintenance procedures, frequencies, and intervals to the Equipment. Scheduling is usually set at the Model level, but this tab allows users to adjust or add schedules for individual Equipment when needed.




The PM Requirement field lets Administrators choose the correct Preventative Maintenance requirement for the Equipment.

- **PM Needed Per Policy** — Default selection indicating PM is required.
- **No PM Needed Per Manufacturer** — Indicates the manufacturer does not require PM.
- **No PM Needed Per AEM** — Indicates PM is not required under the AEM program.

Clicking the 

icon in the upper left opens a New Scheduled Event screen, where users can configure a new Preventive Maintenance schedule for the Equipment.



Note: Red asterisks indicate a required field to Save!

Active – Indicates if the PM schedule is Active or Inactive.
Schedule Rates – Indicates if the PM schedule is OEM (default) or AEM.
Schedule Type – Defines how the schedule behaves. This field contains two options:

- **Fixed** – The Scheduled Event will occur on the same frequency and interval.
- **Floating** – The next Scheduled Event will occur depending on when the last Scheduled Event was closed.

General Details – Provides the default settings for Work Order creation.
Tag Number – Control number associated with the specific Equipment. Populating the Tag Number field will auto-populate the Model and Type fields as well.
Model – The Model associated with the Equipment.
Type – Type associated with the Equipment.
WO Type – The specific type of Work Order that will be created when it is generated.
Procedure – The pre-configured Procedure that will be associated with the Work Order.
Priority – Priority ranking associated with the Work Order.
Problem – Allows user to add specific notes that will be populated on the Work Order once its generated.
Service Department – The Service Department(s) assigned to the Work Order.


Employee Assigned – The users/teams who will be assigned to the Work Order once it is generated.
Vendor Assigned – The vendor who will be assigned to the Work Order once it is generated.
Estimated Hours – Estimated Labor time it will take to complete the Work Order.
Schedule – Provides the frequency and next date for the Schedule.
Frequency – Number associated with how often a Work Order will be generated for this specific Equipment. This field is directly tied to the Interval field.
Interval – pre-configured intervals indicating how often the specific Equipment will generate a Work Order to include metered intervals.
Next Even Date Time – The Date and Time the next Work Order will be generated.
Grace Period – Establishes the number of days the work order will be available for completion and be counted as On Time.
Frequency – The Date Part allowed before Work Order is considered Overdue.
Interval – Grace Period Interval**.**
Season – Allows the user to set a beginning and end date for seasonal equipment.

- **Beginning** – Date when Work Order will begin generating for a specific Equipment.
- **Ending** – Date Work Order will stop generating for a specific Equipment.

Note: Seasonal Dates must be turned on in System Setup->Other Options!



The Oil Can Icon located on the top tool bar of the Scheduled Event pop out screen, assigns Parts or Part Kits directly to the Scheduled Event for reporting and forecasting. If the Part Number is known, it can be entered in the Part field; otherwise, a Find button has been provided. A quantity is required.



Warranty

This area allows users to enter warranty information for the Equipment. Clicking on the + New Warranty icon opens the Warranty screen. This allows the user to enter the Warranty data for the Equipment.



Vendor – The Vendor supplying the warranty.

Start Date – The start date of the Warranty.

End Date – The end date of the Warranty.

Note – Any additional details regarding the Warranty not covered by the other included fields.

Coverage Options – This multi-select dropdown allows the users to declare what is covered by the Warranty.

Response Time (Hours) – States what the average response time is by the Vendor.

Review Date – This date is when the Warranty should be reviewed before expiration. On this date, the Reviewer (next field) will receive an email reminding them to review the contract.


Reviewer – The person or persons responsible for renewing the contract.

Turn On Automatic Notifications – Allows for automatic emails to the Reviewers regarding this contract.

Service Hours – Provides the service hours of the Vendor.

Information Services

The Information Services tab is a highly customizable area that organizations can tailor to their needs. Administrators should review the setup inside of **System Setup → Setup Information Services** to ensure it aligns with their workflows.



Connected To Network – Informs the user if the Equipment is connected to the network.

Wireless and Wired Fieldsets – Two fieldsets are provided to inform the user whether the Equipment is connected to the network via wired or wireless means or both. In each fieldset, the user can declare:

IP Address – The user can declare either a Dynamic or Static address as well as if it is IPv4 or IPv6. Only addresses which conform to address rules can be entered. Users will receive an error for incomplete or improper addresses.

MAC Address – Users can enter a MAC address for the equipment. Only addresses which conform to address rules can be entered. Users will receive an error for incomplete or improper addresses.

Frequencies – Frequencies used by the device.

Other areas include other relevent information:

Router – Information about the Router the Equipment connects to.

Device – Shows whether the Equipment is computer-based and how it is recognized on the network.

Hardware – Hardware specifications for the Equipment.

Software – The type and version of installed software. Custom Critical Messages can be set up to show if the Equipment has the recommended software installed.


HIPAA – Shows the HIPAA compliance for the Equipment.

Sub-Devices – Shows the sub-devices of the Equipment.


Expansion

The Expansion tab allows organizations to add custom field sets and fields when standard CMMS fields do not meet their needs. These fields do not have to remain in the Expansion tab, administrators can move them to the Work Order Header when appropriate.


a. **Create a Field set** - Right-Click within the expansion section. You will see the +Add Fieldset icon. Click on +Add Fieldset icon and populate the Field name you want to create and click OK.




b. **Customize Fieldset** – Once the Field has been created, Right Clicking on the Field displays Fieldset or +Add Field icons. Clicking Fieldset allows users to either Rename or Delete the custom field. Clicking on +Add Field allows users to choose the format of the customize field. Right Clicking inside the custom field displays either the Edit or Delete icons.



Required/Add Field to Nameplate – By editing the field, Administrators can delare the field required and/or Add to Header. Once in the header, fields can be rearranged to suit the need of the organization.




List View




The List View is a powerful way to view the Equipment in the database. The List View is located under the Equipment listing on the side menu. With the List View, users can replance values of fields for multiple pieces of Equipment, select various colums to view their data, filter their data, export to an Excel file, and pop out the view to use in a different window.

The  refresh button in the upper left-hand corner will refrsh the list as needed.



The Tool Bar – The tool bar contains buttons to affect the data in the list or how the list is viewed.
View All Macros – This is an Administrator function to show all Macros in the system regardless of who created them.
Macro – Allows the User to select the desired Macro to run.
Update – Allows the User to update the values of certain fields. Fields to be adjusted must be selected by the Column Selector before “Update” is clicked. Once the “Update” button is clicked, a pop-up window will appear and any fields which can be changed have a column header allowing the User to enter new information.


Note: All records selected will have the same information!!! Do not use this feature if all records must have different values!!!





Risk Setup – This allows the User to change the Risk on several Equipment records at the same time. It will make the process easier to start with a filtered list. The user must declare which Service Department to affect first, then the Risk Scores. Each record has its own checkbox, or the User can select the top checkbox to select all records in the list.

When the User is confident of the selections, clicking the Update button in the upper right corner will update the Equipment records.

Note: There is no undo for this function. To change the records back, the utility must be run again or a restore of the database is necessary!







Select Columns – This option allows Users to select which columns they would like to view in the List View. This option is User-specific and will remain until the view is changed. Therefore, if a User selects specific columns for their list view, it will not affect the views of other Users. However, the columns they selected will remain as selected until changed. After the User selects the desired fields to be viewed, they should click the "Ok" button to apply the changes.

Filter – The Filter allows Users to refine which data they see in the list view. Clicking on the Filter button will bring up a pop-up window with a list of fields which can be filtered. In this window, Users can click the field they would like to filter and click the filter at the bottom of the window. This will display the field with its filter options. After the selections are made, clicking "OK" will accept the selections or "Clear" will cancel them. Once the User has filtered the needed fields, clicking "OK" returns the User to the List View with the revised data. Clicking the "Macro" button in the window will launch the Macro window. From here, the User can load a previously saved Macro, or they can choose to save their selected filter as a new Macro. The "Global" checkbox will make it available to all Users. Deselecting the checkbox allows the creator to share the Macro with other specific Users.


Export – The Export button exports the current list to an Excel file.

Popout View – The Popout View button creates another window with the current view. If a User clicks on the Go To button of the new window, the original window will show the selected record. The new window retains the Refresh, Column Selector, Filter, and Export buttons. At the bottom of the new window is the last time the view was refreshed.


Global Equipment Lookup

The Global Equipment Lookup feature allows authorized users to search for Equipment records across all Facilities, regardless of their assigned Facility or Assignment Profile. This lookup is view-only, meaning users can analyze Equipment details without navigating away from the current screen or opening the Equipment record.


This feature appears inside the Equipment Submenu and opens a pop-up window. It includes its own security settings, which are disabled by default for all user levels.



Schedule Event Change



Schedule Event Change allows Administrators to update or remove existing Scheduled Events. This includes, but is not limited to, new scheduled dates, assignments, procedures, and Work Order settings. To start a change or remove, users must use **at least one** search filter on the initial page. A Setup button is included in the top right corner to allow the user to change the search fields. When the filter has been set, the user clicks the Preview button on the lower left portion of the screen. A list of changeable fields and the filtered events will be displayed on a new screen.



At the top right of the new screen is a toggle switch for the user to select to change or remove selected Scheduled Events.

Update – To update Scheduled Events, the user uses the available grids to make the necessary changes. Below the update fields are the records to be updated. Users must select **at least one** record to update. A "select all" checkbox has been provided to update the complete list, even though the full list may not be visible.

Note: Ensure all records have been reviewed before choosing to update! This process cannot be reversed through AIMS 3!

Once the records have been reviewed, users must click the Update button in the upper right corner. If the user would like to refine the search, they can click the Back button and change the search criteria.


Remove – When the toggle switch is moved to "Remove," all update fields are greyed out and cannot be used. The user must select **at least one** schedule to delete.

Note: Ensure all records have been reviewed before choosing to remove! This process cannot be reversed through AIMS 3!


Once the records have been reviewed, users must click the Remove button in the upper right corner. If the user would like to refine the search, they can click the Back button and change the search criteria.

Physical Inventory Verification

Organizations routinely want to take an inventory of all Equipment. Physical Inventory Verification allows Users to enter Tag Numbers and adjust information before saving the record as “inventoried.”




Tag Numbers can be added by manually typing them in or by using the bar code scanner button to the right of the field. When a Tag Number is entered, the Equipment’s information will populate in the other fields. This also includes the Location grid. Once the information is updated, the User clicks save, and the screen resets and the inventoried Equipment is display at the bottom of the page in the History grid.



Users can review what was inventoried by manipulating the Inventoried and Inventoried By fields.

Model Equipment Sync

Model Equipment Sync helps users standardize the information on Equipment records. It updates Equipment by forcing Model defaults to Equipment records. Therefore, it is important the Model's information is correct. Model Equipment Sync allows for the correction of Model information before a sync is performed.



Model Equipment Sync has three main areas:

1. **The Manufacturer/Model Selector** – This selects the Equipment to be synced. The "Show Out of Sync Equipment Only" will show only the Equipment which does not match the Model.
2. **Model Details** – This will display the Model's current information. If it needs to be corrected, the User must correct it in the fields provided and click the Update button.
3. **Equipment Grid** – This contains all the Equipment out of sync from the model if the "Show Out of Sync Equipment Only" is checked. If it is not checked, it will show all Equipment for the Manufacturer/Model. The user must utilize the checkboxes to the left of the Equipment or the top checkbox to select all records.

Once the records are selected, clicking the Update button in the upper right corner will update the records.

Note: There is no undo for this function. To change the records back, restoration of the database is necessary!

Conclusion

As the backbone of any CMMS, Equipment must be carefully maintained physically and within the software. AIMS 3 allows Administrators and users to maintain their Equipment through a streamlined software with a robust report engine.

If Administrators require additional consulting or training, Phoenix Data Systems is available to assist at any level. Please contact our sales Department or Project Managers for more information.

Appendix

To support your learning, we have created a step-by-step video guide that visually walks you through the entire process. Simply click the link below to visit our YouTube channel, where you can watch the full Equipment Course of tutorials at your own pace. This is a great way to follow along, review key steps, and build confidence with the workflow as you learn.

Equipment Component