Work Orders

JUNE 2, 2026



CLASSIFICATION: FOR PUBLIC USE

Contents

Overview 5
Inheritance 6
The Work Order Tool Bar 7
The Notification Area 10
The Request Information Section 11
The Equipment Information Section 12
Additional Tabs 13
Dispatch/Location 13
Location 13
Dispatch 14
Documentation Center 15
Update 16
Labor – 16
Apply Material – 17
Apply Part Kit – 17
Closing Information – 18
Totals – 18
The Close Button – 18
Expansion 18
History Log 19
Other Open Work Orders 19
List View 21
The Tool Bar 21
View All Macros 21
Macro 21
Update 21
Select Columns 22
Filter 22
Export 22
Popout View 22
Scheduled Events 23
General Details 24

CLASSIFICATION: FOR PUBLIC USE

Schedule 24
Generate Events 25
Generate Events – 25
Batch Open Work Orders 26
The Request Information Section 26
Dispatch 27
Equipment 27
Individually 27
Group 27
Documentation Center 28
Quick Apply Labor 29
Generating Purchase Requests 30
Request Information 30
Supplier Information 31
Line Items 31
Custom Work Order Forms 32
Conclusion 33
Appendix 34

CLASSIFICATION: FOR PUBLIC USE

Work Orders allow Administrators to realize work performed, costs, and compliance efforts using a Computerized maintenance management system (CMMS). Administrators have a collection of assets, which must be maintained and catalogued. Using copious data collection for each asset, CMMS are no longer simply a way to manage Scheduled Work Orders. Administrators can now record work performed, show Preventative Maintenance Compliance, and track costs for specific pieces of Equipment.

For Administrators to receive a full return of investment on their CMMS, it is important to recognize essential workflows and key data. First, this should be for the safety of internal and external customers who come in contact and rely on this Equipment on a regular basis. From here, regulatory requirements should guide how the Equipment is maintained. Finally, a system for employees to request repairs should be readily accessible and easy to use.

Planning for Equipment Management: Some classes of Equipment can call for discussion and planning regarding their management. These discussions should include available labor, organizational policy, government regulations, and regulatory agency requirements. For example, an organization may want to include exit signs as individual assets. There are many advantages to this way of management:


- Individual maintenance history
- True number of scheduled Work Orders
- Trending in areas

However, instead of closing one Work Order, technicians will have to close hundreds. Therefore, a workflow needs to be created to close them all. There is no perfect "one-size-fits-all" policy for all organizations and policies should be reviewed as organizations expand and contract.

Workflow Standardization: Many organizations employ multiple Administrators. While they employ their best intentions for the data, sometimes the data can become "dirty." Therefore, it is important to discuss items such as Work Order Type, Work Order Statuses, and other fields which can allow for "judgement calls." For example, the Status Field could include "Open" and "In Progress." These small but significant differences affect the usefulness of the system and reporting. Phoenix Data Systems can assist customers with a wide array of consulting options to guide them in the best direction.

CLASSIFICATION: FOR PUBLIC USE

Overview



The Work Order Control is in the Menu just below the Equipment Control. Clicking the down arrow next to the word "Work Order" will show additional options, such as "List View," "Scheduled Events," "Generate Events," "Batch Open Work Orders," and "Quick Apply Labor." Clicking on List View will initially show a complete list of Work Orders in the system. Clicking either the icon or the word "Work Order" will open the last Work Order viewed by the User in the main viewing pane. The number next to the Work Order Control refers to the number of Work Orders assigned to the current User. Users will notice five distinct areas regarding the Work Order Record:

- The Work Order Menu Bar
- The Notification Area
- The Request Information Section
- The Equipment Information Section
- Additional tabs

Each tab will have a group or several groupings of fields to help capture relevant data regarding the specific tab. These fields consist of dropdown fields, free-text fields, and date/time fields. Users will find certain fields which contain a mask.

Note: There are other components that also refer to the Work Order Component. To see how this interacts with the Home Screen, please see our How-To Guide: The Home Screen.

CLASSIFICATION: FOR PUBLIC USE

Inheritance

AIMS3 utilizes a function which allows records to “inherit” settings from other records. For example, if a User creates documents on the “Model” record, all Equipment will “inherit” those documents. Furthermore, Work Orders with those Equipment records will inherit the documents as well. It is not necessary to add files to individual Equipment. It is advised to use this function with as much as possible to save time and manpower.

In addition, documents and other attributes should be placed as high as possible and still be effective. An example would be if all Equipment of the same Equipment Type will require an Incoming Inspection. This Schedule should be placed on the Equipment Type and not the Model. If every piece of Equipment added to the system will need an Incoming Inspection, it would be best to set it up through Automation.

If Administrators require additional consulting or training, Phoenix Data Systems is available to assist at any level. Please contact our Sales Department or Project Managers for more information.

CLASSIFICATION: FOR PUBLIC USE

The Work Order Tool Bar



The Work Order Menu Bar allows Users to accomplish common tasks. While some icons will be immediately recognizable, others may not. To assist Users, AIMS3 allows Users to see which each button does by simply hovering the cursor over the icon. The Menu Bar will be consistent from User to User.


Save - Allows User to Save a Work Order record once required fields have been populated.


New - Creates a new Work Order record. Selecting the down arrow on the button will pop up the Quick Entry Form (see the System Setup How-To for more information).


Duplicate - This duplicates the Work Order record currently being viewed.


Delete - Deletes any Saved or Unsaved Work Order record.


Undo – Resets the Work Order to the previous save point.


First – Returns the User to the first numbered Work Order record in the Work Order List.


Previous – Returns the User to the previously numbered Work Order record in the Work Order List.


Next – Advances to the next numbered Work Order record in the Work Order List.


Last – Advances to the last numbered Work Order record in the Work Order List.


Link - Allows User to copy displayed Work Order record's URL onto a Clipboard to Forward or Paste to another location (i.e.: email, webpage). Clicking the down arrow allows the User to email the link using their default browser or Favorite and un-Favorite a Work Order. Favorited Work Orders and other records show in the "Favorites" widget on the Home Screen.


Send Message – Sends a message to all assignees based on the Messaging defaults setup in the System Setup and the Employee Data Manager.



Vendor Directory – Opens the Vendor Directory to the listing of the Work Order's Manufacturer.

CLASSIFICATION: FOR PUBLIC USE




Find – Directs User to the Search Query screen where a single Work Order record or multiple Work Order records can be filtered.

a) **General Search** – The Work Order Find window allows Users to search from a selection of Work Order and Equipment Fields and displays the results at the bottom of the window. Users can adjust which fields and grids are visible by clicking the Select Search Fields button  in the upper right corner of the window.



The dropdown "Grid Columns" allows the User to change the information viewed in the results grid. The Work Order Filters changes which fields the User can search. These changes are User-specific.

Clicking the Search button  in the Find window runs the search.


b) **History** – The History field records the ten previous searches and the quantity of results per User. Selecting a search and clicking "Rerun" will rerun the search with updated results. The rerun search will move the search to the top of the results instead of duplicating the search in the list.




Master Report – This will produce the Work Order Report showing all data for the Work Order record.



Purchase Request – Allows the User to either create a new Purchase Request or view existing Purchase Requests for the Work Order. This will be covered later.



Notes – Contains all notes regarding the Work Order, including Equipment notes.




Procedure – Allows the User to view the procedure on the Work Order and enter tasks results.

CLASSIFICATION: FOR PUBLIC USE



Parent/Child Work Orders – Allows the User to view or add any Parent or Child Work Orders relative to the existing Work Order.



Tools – Allows the User to conduct advanced functions regarding the Work Order.

Note: Depending on a User's access, they will see all, some, or none of the following items!



Parent/Child Work Order – Allows the User to designate the Work Order as a parent or child record when creating related Work Orders.

Note: When Creating Parent/Child Work Orders, you can leave any Work Orders open, and the Status of each Work Order will be displayed on screen.



Messaging Log – Shows all previous messaging regarding the Work Order.



Audit Trail – Allows Users to view all previous changes to the Work Order.




Edit Data Manager – Allows Users to edit Data Managers on the fly without having to navigate to the Data Manager component. This depends on a User's Security Level.





Close – Follows the workflow to close Work Orders.

Note: Work Orders can only be closed by utilizing the Close button! If a User tries to close the Work Order through the Status field, they will be redirected to the Close button!



Re-Open – Follows the workflow to re-open Work Orders.

CLASSIFICATION: FOR PUBLIC USE

The Notification Area


The Notification Area allows Administrators the ability to notify Users important messages regarding the Work Order and/or Equipment using Custom Critical Messages. These messages are customized by the Administrator and can be different colors and include customized wording, such as stating a piece of Equipment is retired:



Notifications are customized in the System Setup->Custom Critical Messages section of the software. These messages are available to be seen on Easynet for Requestors as well.

CLASSIFICATION: FOR PUBLIC USE

The Request Information Section



The Request Information Section contains the basic information regarding the Work Order. This includes:

Work Order # – (System Generated Integer) This is the primary identifying number for the Work Order.
Request Date – (Date Format) This is the creation date of the Work Order for all non-PM Work Orders and the start date for PM Work Orders.
Status – (dropdown) This denotes the status of the Work Order. These can include:

- Open
- Closed
- Canceled
- Awaiting Parts
- Parts Received
- Awaiting Vendor


Status Date – (Date Format) The date of the most recent Status.
Type – (dropdown) This field is to classify the type of Work Order. This usually refers to the source of the Work Order. These can include:

- Preventative Maintenance
- Corrective Maintenance
- Initial Inspection
- Compliance Round

Requester – (free text) The name of the person requesting work.
Phone # – (free text) The phone number of the person requesting work.
Email – (free text) The email of the person requesting work.
Problem – (free text) The description of the work to be performed.

CLASSIFICATION: FOR PUBLIC USE

The Equipment Information Section




The Nameplate Section contains the basic information regarding the Equipment. This includes:

Tag Number – (free text) This is the primary identifying number for the Equipment. Changing the Tag Number will reassign the Work Order to the new Equipment. A code reader has been provided to quickly add a Tag Number to a new Work Order.
Manufacturer – (dropdown) This denotes the current manufacturer for the model assigned to the Equipment.
Model – (dropdown) This is the model number used by the manufacturer.
Type – (dropdown) This field is to classify the type of Equipment. These can include:

- Air Handling Unit
- Exhaust Fan
- Fan Coil Unit
- Infusion Pump
- MRI

Description – (free text) This is a general description of the Equipment.
Serial – (free text) The assigned serial number by the manufacturer.
Model Name – (Free Text) The Model Name of the Equipment.
Status – Shows the current status of the Equipment.
Nameplate Manufacturer – (free text) The name of the manufacturer who originally built the Equipment, should the manufacturer have changed.
Condition – (dropdown) Current Condition of the Equipment.
Risk Classification – (dropdown) Allows for the option to denote Equipment as "High Risk" or "Non-High Risk."

Depending on the User's Security Level, Users can change Equipment information directly from the Work Order. The User will be prompted to confirm the changes.



CLASSIFICATION: FOR PUBLIC USE


Additional Tabs

Using additional tabs allows Administrators to apply helpful data to the Equipment. This includes:

- Dispatch/Location
- Update
- Expansion
- History Log
- Other Open Work Orders (conditional)

While there may be required fields, it is not necessary to fill in all fields. Organizations will wrestle with how much information is wanted versus needed. When developing Work Order workflows, Administrators must decide is the extra time entering data worth the return of investment in future reporting. Other Administrators will want many more fields, depending on organization and regulatory needs. It helps to codify these workflows for future reference.

Note: As mentioned in Inheritance above, information will be "inherited" if set at the Type, Manufacturer, and Model level.



Dispatch/Location - This tab contains general administrative data concerning the Equipment.

Location – The Location grid is managed through Data Managers->Location Tree. It is a hierarchical list of locations throughout the organization. The tree operates as follows:


- Facility
- Building
- Wing
- Floor
- Room
- Location
- Spot

CLASSIFICATION: FOR PUBLIC USE

After a Facility is selected, only Buildings under the selected Facility will be presented to the User. After a Building is selected, only Wings under the selected Building will be presented and so on. A Free Text Location field is available for specific locations.

Depending on the User's Security Level, Users can change the Equipment's location directly from the Work Order. The User will be prompted to confirm the changes. If the User chooses to not update the Equipment, the location will be for the Work Order only.

Note: The Location grid is not mandatory. However, if the Location grid is not used, it is advised to make the Free Text Location field required.



Dispatch – The Dispatch section contains fields regarding the Work Order ownership and status. By default, Cost and Responsible Centers, Priority, Due Date, and Service Department are required, but it is advised to utilize as many fields as possible for quality reporting.

a. **Cost Center -** Drop-down that refers to the Account/Department that owns the Equipment.
b. **Responsible Center –** Drop-down that refers to the Account/Department where the Equipment is used and/or resides.

Note: Cost Centers and Responsible Centers can be identical or different depending on the piece of medical Equipment.

c. **Priority –** Denotes the importance of the Work Order. If setup in Data Managers, changing the Priority can change the Due Date (PMs excluded).
d. **Due Date** – When the Work Order will become overdue.
e. **Compliance Dates –** Optional date fields added by the Administrator to show when the Work Order can be started and must be completed.
f. **Estimated Hours –** The amount of time expected to complete the Work Order.
g. **Job Type –** Informs the User of an additional classification for the Work Order. This will limit the Procedures in the Procedure field to the Procedures limited to the Job Type.
h. **Procedure –** Lists the name of the Procedure on the Work Order.

CLASSIFICATION: FOR PUBLIC USE

i. **Vendor Assigned –** Drop-down that allows for the assignment of a specific vendor. A vendor can be forced by a warranty or contract. Setting the Vendor in this field will default it as the supplier of Labor and/or Materials.
j. **FSR Number –** This field contains the number of the Field Service Report, if needed.
k. **Service Department -** Drop-down that refers to one or multiple departments charged with maintaining and repairing the Equipment.
l. **Assigned To** – Allows specific employees/teams to be assigned to the Work Order.
m. **Trade –** Described the Trade needed to complete the requested work.


Documentation Center – The Documentation Center contains all files and photos pertaining to this Work Order. Click the New button to add a new file. Under File Details, click the Browse button and locate the file to be added. Administrators can add an optional description. If it is an image file, it can be selected as the default image under the list of files.




Save - Saves the attachment.



New – Adds a new attachment. When the plus is clicked the window will include a section on the right side to "Browse" for the file or Users can drag and drop the file in the "File Details" section.



Note: On mobile devices, browsing files will present the user with three options: taking a photo, selecting a photo from the Photo Library, or accessing the devices files application.




CLASSIFICATION: FOR PUBLIC USE

Update – The Update tab allows Users to record all work and costs related to the completed work order. The Work Order may need multiple times to update the Work Order to complete it. If the Work Order is in New mode, clicking the Update tab will automatically save the Work Order.

a) **Equipment Down –** Indicates if the Equipment is declared down during the work.
b) **Equipment Back Online –** Indicates if the Equipment is declared up during the work.
c) **PM Preventable -** Indicates if the work could have been prevented with Preventative Maintenance.
d) **Incident Report –** Denotes if an Incident Report was created due to the work.

Labor – The Labor portion of the Update tab allows Users to enter all time dedicated to the Work Order. User can enter time for themselves or for other workers who assisted on the Work Order. The Labor popup window includes common elements from the toolbar.




a) **Labor Source** – Denotes if the Labor came from In-House, Contract, or from a Vendor.
b) **Start/End Date** – The Date and Time when the Labor started and ended. If the Start Date is hidden, the start time will be calculated according to the amount of time entered.
c) **Employee/Vendor/Contract** – The Employee or Vendor conducting the Labor. If the Contract radio button is selected, this will present the User with a list of Contracts the Labor can be applied to.
d) **Response** – How the Employee responded to the work needed. If setup in Data Managers, the response can control the PM Result field.
e) **Action** – What action the Employee took during the Labor period.
f) **Cost Information**
    a. **Billable** – Denotes if the Labor will be billed.
    b. **Rate Source** – Shows where the Rate is pulled from. This could be from the Employee, Cost Center, Equipment Type, or Building.
    c. **Rate** – Denotes the Labor Rate. Different rates will affect the cost of the Work Order.
    d. **Labor/Travel** – Denotes if the time was for Labor or Travel.
    e. **Hours** – The amount of time for the Labor line.
    f. **Charge** – The Rate monetized.
    g. **Total** - The Charge times Hours
    h. **Test Equipment** – Allows the User to enter all test Equipment used during the Labor Line. After clicking the toggle switch the User can either enter the test Equipment's tag number or search for it using the same Find functionality found throughout the software. Test Equipment can be assigned to Users to make the process easier to

CLASSIFICATION: FOR PUBLIC USE

find the Equipment. Clicking the plus sign next to the Equipment will add it to the Work Order.

Apply Material – This allows Users to apply a Part to the Work Order.



a) **Part Source** – Denotes if the Part came from In-House, Contract, or from a Vendor.
b) **Date/Time** – The Date and Time when the Part was applied.
c) **Part and Description** – To apply a Part, either Part or Description is required to save.
    a. **Part –** This is the Part number as it appears in AIMS3.
    b. **Description –** This is used when a Part record in AIMS3 WILL NOT be used. Using this feature will not affect the inventory of any part record.
d) **Warehouse** – This includes a dropdown of all Warehouses listed in the system.
e) **Quantity** – The number of Parts used.
f) **Price/Item** – The price of EACH item.
g) **Extended** – Quantity time Price/Item.
h) **Billable** – Denotes if the Labor will be billed.
i) **Part Serial Number** – The serial number of the part (if applicable).
j) **Batch Number** – This indicates from which batch the Part was produced.
k) **Linked Parts** – Displays Parts previously used on the Equipment.


Apply Part Kit – Part Kits work similarly to Parts with one important distinction. When Part Kits are applied to a Work Order, all individual Parts are listed on the Work Order. In the event the User does not use all Parts in the Part Kit, the individual Parts can be removed, and they will be added back to the inventory.



a) **Part Source** – Denotes if the Parts came from In-House or from a Vendor.
b) **Date/Time** – The Date and Time when the Part Kit was applied.
    a. **Part Kit Number –** This is the Part number as it appears in AIMS3.
    b. **Description –** This is the description of the Part Kit record in AIMS3.


CLASSIFICATION: FOR PUBLIC USE

c) **Warehouse** – This includes a dropdown of all Warehouses listed in the system.
d) **Quantity** – The amount of Part Kits used.
e) **Billable** – Denotes if the Labor will be billed.
f) **Linked Parts** – Displays Part Kits previously used on the Equipment.




Closing Information – This area allows Users to include a final disposition of the Work Order, whether it is a PM or non-PM Work Order.

a) **Failure Type** – This field is used to describe why the Equipment Failed.
b) **PM Result** – This field is used to denote if the PM was Passed, Failed, or was unable to complete.



Totals – Totals include all costs for the Work Order and cannot be adjusted.

The Close Button – This button 

begins the closing process of the Work Order. The User will be presented with a confirmation dialogue. If they select yes, they will be presented with the option to change the Date and Status of the Closed Work Order. When the Work Order is closed, this button will display "Re-Open."

Note: Work Orders can only be re-opened by Users with the appropriate permissions!




Expansion – No CMMS comes with the precise fields to meet every organization's needs. Therefore, the Expansion tab allows for the addition of custom field sets and fields. However, these fields do not have to live in the Expansion tab. Fields can be moved to the Work Order Header as needed.

a. **Create a Field set** - Right-Click within blue screen below the Tab Bar. You will see the +Add Fieldset icon. Click on +Add Fieldset icon and populate the Field name you want to create and click OK.
b. **Customize Fieldset** – Once the Field has been created, Right Clicking on the Field displays Fieldset or +Add Field icons. Clicking Fieldset allows users to either Rename or Delete the custom field. Clicking on +Add Field allows users to choose the format of the customize field. Right Clicking inside the custom field displays either the Edit or Delete icons.

CLASSIFICATION: FOR PUBLIC USE

Required/Add Field to Nameplate – By editing the field, Administrators can delare the field required and/or Add to Header. Once in the header, fields can be rearranged to suit the need of the organization.



History Log – This area allows users to review the Work Order history of the Equipment. By clicking the Go To icon (right), users can open Work Orders from the Equipment according to the business rules assigned.


a. A Model History button is included in the upper left corner to show Work Orders from all Equipment records of the same Model.
b. A column selector is included in the upper right corner to allow users to add or remove displayed columns. Next to the column selector is an export button, so the user can export the list to an Excel file. To the right of the Export button is a Pop Out View button.
c. **Open PM –** Indicates whether there currently is an Open Preventative Maintenance Work Order on this Equipment.
d. **Next PM –** Indicated when the next Preventative Maintenance Work Order is scheduled to be generated.
e. **Last Closed PM** – Indicates date of last closed Preventative Maintenance Work Order.

Note: If you click on the icon, it allows users to see more information regarding the open, upcoming, or last closed PM.



Other Open Work Orders – This tab contains all other open work orders for the Equipment assigned to the current Work Order. This helps Users determine which Work Order should be completed first.

CLASSIFICATION: FOR PUBLIC USE



Other Open Work Orders


Work Order #	Status	WO Type	Tag	Problem	Request Date	Due Date	Priority	Employee Assigned
4978491	Open	Preventative Maintenance	COMP.CNTRLAIR.FHC	AIR COMPRESSOR, BUILDING CONTROLS - DAILY Please conduct equipment maintenance as per operating equipment manual.	06/08/2025 8:00 am	06/10/2025 12:59 am	Urgent Priority	
4978490	Open	Preventative Maintenance	COMP.CNTRLAIR.FHC	AIR COMPRESSOR, BUILDING CONTROLS - DAILY Please conduct equipment maintenance as per operating equipment manual.	06/07/2025 8:00 am	06/09/2025 12:59 am	Urgent Priority	

Total Records : 2

An Export and Pop Out View button has been added and have the same functionality as found elsewhere in AIMS 3. Clicking on a Work Order number will navigate to that Work Order.


CLASSIFICATION: FOR PUBLIC USE

List View




The List View is a powerful way to view the Work Orders in the database and by default will only display Open Work Orders inside of the Database. The List View is located under the Work Order Control on the side menu. With the List View, Users can replace values of fields for multiple Work Orders, select various colums to view their data, filter their data, export to an Excel file, and pop out the view to use in a different window. Each line within the view has a Go To icon to jump to a record.

To see a list of all Work Orders, not just Closed, you can select the "Open Statuses On;y Check box



The refresh  button in the upper left-hand corner will refrsh the list as needed.




The Tool Bar – The tool bar contains buttons to affect the data in the list or how the list is viewed.

View All Macros – This is an Administrator function to show all Macros in the system regardless of who created them.

Macro – Allows the User to select the desired Macro to run.


Update – Allows the User to update the values of certain fields. Fields to be adjusted must be selected by the Column Selector before "Update" is clicked. Once the "Update" button is clicked, a pop-up window will appear and any fields which can be changed have a column header allowing the User to enter new information.

Note: All records selected will have the same information. Do not use this feature if all records must have different values.




Closing Information – Closing Information allows for Users to include Labor, Parts, and additional information if they want the Work Orders closed. This follows the workflows for closing a Work Order individually.

CLASSIFICATION: FOR PUBLIC USE


Preview – Preview allows Users to review changes before the information is updated. This is important since it will be difficult to reverse the changes. If the information is correct, the User clicks the "Submit" button 

to finalize the process.

Select Columns – This option allows Users to select which columns they would like to view in the List View. This option is User-specific and will remain until the view is changed. Therefore, if a User selects specific columns for their list view, it will not affect the views of other Users. However, the columns they selected will remain as selected until changed. After the User selects the desired fields to be viewed, they should click the "Ok" button to apply the changes.



Filter – The Filter allows Users to refine which data they see in the list view. Clicking on the Filter button will bring up a pop-up window with a list of fields which can be filtered. In this window, Users can click the field they would like to filter and click the filter at the bottom of the window. This will display the field with its filter options. After the selections are made, clicking "OK" will accept the selections or "Clear" will cancel them. Once the User has filtered the needed fields, clicking "OK" returns the User to the List View with the revised data. Clicking the "Macro" button in the window will launch the Macro window. From here, the User can load a previously saved Macro, or they can choose to save their selected filter as a new Macro. The "Global" checkbox will make it available to all Users. Deselecting the checkbox allows the creator to share the Macro with other specific Users.




Export – The Export button exports the current list to an Excel file.

Popout View – The Popout View button creates another window with the current view. If a User clicks on the Go To button of the new window, the original window will show the selected record. The new window retains the Refresh, Column Selector, Filter, and Export buttons. At the bottom of the new window is the last time the view was refreshed.


CLASSIFICATION: FOR PUBLIC USE

Scheduled Events

Scheduled Events are scheduled non-Equipment-based Work Orders. For example, Fire Drills are not aligned with a particular asset, but they must be done on a regular basis.



To create a new Scheduled Event, the User clicks on the New Event button which will bring up a Scheduled Event screen as seen elsewhere in the program.



Note: Red asterisks indicate a required field to Save.

CLASSIFICATION: FOR PUBLIC USE

Active – Indicates if the PM schedule is Active or Inactive.

Schedule Type – This field contains two options:

- Fixed – The Scheduled Event will occur on the same frequency and interval.
- Floating – The next Scheduled Event will occur depending on when the last Scheduled Event was closed.

General Details – Provides the default settings for Work Order creation.

WO Type – The specific type of Work Order that will created when it is generated.
Procedure – The pre-configured Procedure that will be associated with the Work Order.
Priority – Priority ranking associated with the Work Order.
Location Fields – The location of the work to be performed.
Cost Center – The Cost Center assigned to the Work Order.
Responsible Center – The Responsible Center assigned to the Work Order.
Service Department – The Service Department(s) assigned to the Work Order.
Employee Assigned – The Users/teams who will be assigned to the Work Order once it is generated.
Vendor Assigned – The vendor who will be assigned to the Work Order once it is generated.
Estimated Hours – Estimated Labor time it will take to complete the Work Order.
Problem – Allows Users to add specific notes that will be populated on the Work Order once it's generated.

Schedule **–** Provides the frequency and next date for the Schedule.

Frequency – Number associated with how often a Work Order will be generated for this specific Equipment. This field is directly tied to the Interval field.
Interval – Pre-configured intervals indicating how often the specific Equipment will generate a Work Order.
Next Event Date Time – The Date and Time the next Work Order will be generated.
Grace Period – Establishes the number of days the work order will be available for completion and be counted as On Time.


Frequency – The Date Part allowed before Work Order is considered Overdue.
Interval – Grace Period Interval**.**
Season – Allows the User to set a beginning and end date for seasonal activities.
Beginning – Date when Work Order will begin generating.
Ending – Date Work Order will stop generating.

Note: Seasonal Dates must be turned on in System Setup->Other Options.

CLASSIFICATION: FOR PUBLIC USE

Generate Events

Generate Events is the tool to manually create Scheduled Work Orders. Upon clicking General Events, the User will be presented with a popup. The popup includes two areas:




Generate Events – This area allows the User to determine if the schedules included should be up to a certain date and to adjust events on weekends.

The User can then preview the events to ensure the information is correct or simply generate the events.


Note: When generating events on a new instance of AIMS 3, it is strongly recommended to preview the events and make any necessary changes before generating!

Batch Open Work Orders



Batch Open Work Orders works similar to creating a new Work Order but is designed to create multiple Work Orders at a time. All required must be completed to generate the Work Orders.

The Request Information Section



The Request Information Section contains the basic information regarding the Work Order. This includes:

Type – (dropdown) This field is to classify the type of Work Order. This usually refers to the source of the Work Order. These can include:


- Preventative Maintenance
- Corrective Maintenance
- Initial Inspection
- Compliance Round

Request Date – (Date Format) This is the creation date of the Work Order for all non-PM Work Orders and the start date for PM Work Orders.
Requester – (free text) The name of the person requesting work.
Phone # – (free text) The phone number of the person requesting work.
Email – (free text) The email of the person requesting work.

CLASSIFICATION: FOR PUBLIC USE

Problem – (free text) The description of the work to be performed.

Dispatch



The Dispatch section contains fields regarding the Work Order ownership and status. By default, Cost and Responsible Centers, Priority, Due Date, and Service Department are required, but it is advised to utilize as many fields as possible for quality reporting.

a) **Priority –** Denotes the importance of the Work Order. If setup in Data Managers, changing the Priority can change the Due Date (PMs excluded).
b) **Due Date** – When the Work Order will become overdue.
c) **Estimated Hours –** The amount of time expected to complete the Work Order.
d) **Job Type –** Informs the User of an additional classification for the Work Order.
e) **Procedure –** Lists the name of the Procedure on the Work Order.
f) **Parent Work Order #** - Entering a Parent Work Order # will make all Work Orders created a child Work Order of the Work Order Number entered.
g) **AIMS Default/Override** – This choice will use either the AIMS defaults in System Setup or the User can override those settings.
h) **Vendor Assigned –** Drop-down that allows for the assignment of a specific vendor. A vendor can be assigned to any Equipment under warranty or contract.
i) **Service Department -** Drop-down that refers to one or multiple departments charged with maintaining and repairing the Equipment.
j) **Assigned To** – Allows specific employees/teams to be assigned to the Work Order.

Equipment



Tag Numbers can be entered individually or as a group.

Individually – The User enters the number and clicks the plus button.

Group – The User clicks the magnifying glass and finds the desired records using the Find feature. Each record will have its own checkbox, or the User can click the checkbox at the top of the screen to select them all.



CLASSIFICATION: FOR PUBLIC USE

Documentation Center




The Documentation Center contains all files and photos pertaining to this Work Order. Click the New button to add a new file. Under File Details, click the Browse button and locate the file to be added. Administrators can add an optional description. If it is an image file, it can be selected as the default image under the list of files.



Save - Saves the attachment.




New – Adds a new attachment. When the plus is clicked the window will include a section on the right side to "Browse" for the file or Users can drag and drop the file in the "File Details" section.



Note: On mobile devices, browsing files will present the user with three options: taking a photo, selecting a photo from the Photo Library, or accessing the devices files application.

CLASSIFICATION: FOR PUBLIC USE

Quick Apply Labor



Quick Apply Labor is a function added for Users who know the Work Order number they want to change, but do not want to go through all of the tabs of the Work Order component to add time or close a Work Order.

To use this function, the User enters the Work Order number and hits the TAB key or clicks on another field. Information will be shown for the Work Order, or the User will receive an error message if they are not able to change the Work Order. Moving in the direction of left to right and then top to bottom, the User completes all of the necessary information. Finally, if the User has met all of the criteria to close the Work Order and wishes to do so, they can click the “Close Work Order” checkbox.

When the save button is clicked, the information is saved to the Work Order, the screen resets, and the Work Order is list in the “Labor Entered In This Session” grid at the bottom of the page.


CLASSIFICATION: FOR PUBLIC USE

Generating Purchase Requests

Users can generate Purchase Requests Directly from the Work Order through the Purchase Request button  .

Note: If the User wants to add Parts to the Work Order and request them, Parts should be added through the Purchase Request tool and not directly on the Work Order!!!

After clicking the Purchase Request button, the User will be presented with a popup for the request. All required fields must be completed to save the request.




Request Information – This area contains the basic information of the request.

a) **Request #** - The request number will be set if defaults are set in System Setup. Otherwise, the User will be setup by the User. Letters, numbers, and special characters are allowed.
b) **Request Date** – When the request was submitted.
c) **Status** – Current status of the request.
d) **Requester** – The individual who is creating the Purchase Request.
e) **Ref. WO** – The Work Order related to the request.
f) **Facility** – The Facility associated with the Purchase Request.
g) **Request Dept**. – The requesting Service Department.
h) **Priority** – Determines the urgency of the Purchase Request.
i) **Date Needed** – The requested date needed by the User.
j) **Charge Facility** – The Facility responsible for the payment of the Purchase Request.
k) **Charge Cost Center** – The Cost Center responsible for the payment of the Purchase Request.
l) **Purchasing Account Number** – The unique identifier assigned to track the Purchase Request.
m) **PO#** - The Purchase Order related to the request.
n) **Purpose** – The reason for the Purchase Request.

CLASSIFICATION: FOR PUBLIC USE


Supplier Information – This area contains the basic information regarding the Vendor of the Purchase Request.



a) Supplier – The vendor associated with the Purchase Request.
b) The Suppliers accounting information.
c) Phone – The phone number associated with the vendor.
d) Fax – The Vendor's Fax number.

Note: These fields are not found within Data Managers or System Set Up and must be mapped during the conversion period.

Line Items – This area contains all the Parts requested. Clicking the New button brings up a popup to enter the Part. It can be an inventoried Part or a Part "On-the-Fly." Parts on-the-fly can be replaced later with an inventoried Part.




a) Part and Description – To apply a Part, either Part or Description is required to save.
   a. Part – This is the Part number as it appears in AIMS3.
   b. Description – This is used when a Part record in AIMS3 WILL NOT be used. Using this feature will not affect the inventory of any part record.
b) Warehouse – This includes a dropdown of all Warehouses listed in the system.
c) Supplier Part Number - The Part number as it spears to the vendor.
d) Supplier Part Description – The Part description as it appears to the vendor.
e) Price/Item – The price of EACH item.
f) Quantity – The amount of Parts used.
g) UoM – Unit of Measure used.
h) Date Needed – The requested date needed by the User.
i) Pricing Method – Priced Method used.
j) Ref. WO – The Work Order related to the request.
k) Notes – Notes for this specific Labor Line.

Note: To see the full workflow of the Purchasing Component, please refer to the Purchasing How-To Guide.

CLASSIFICATION: FOR PUBLIC USE

Custom Work Order Forms

Custom Work Order Forms can be created to meet an organization's, Facility's, or Service Department's needs. In System Setup->Customize Work Order Forms, Administrators can create Easynet pages with the fields they want, enter default values to fields, and hide fields from the end User. This function does not exclusively create EasyNet pages; it also creates Work Order forms to be used within the Work Order component. Once a Custom Form is created and activated within AIMS users will see a new dropdown icon next to the "New" button in the Work Order Toolbar. Clicking the dropdown will show any and all Custom Work Order forms that have been created.



Note: To see how these pages can be created and configured, please see our How-To Guide covering System Set Up.

CLASSIFICATION: FOR PUBLIC USE

Conclusion

The Work Orders component of AIMS3 enables Administrators to accurately record information regarding the work performed at their organization. This includes compliance information or basic costs to help with future budgeting. It is vital strong workflows are established to successfully record everything needed to maintain compliance and patient safety.

If Administrators require additional consulting or training, Phoenix Data Systems is available to assist at any level. Please contact our Sales Department or Project Managers for more information.

CLASSIFICATION: FOR PUBLIC USE

Appendix

To support your learning, we've created a How-To Guide in video format that walks you through each step visually. Simply click the link to be taken directly to our YouTube page, where you can watch the full set of tutorials at your own pace. This is a great way to follow along, revisit key actions, and get comfortable with the workflow.

Work Order Component

CLASSIFICATION: FOR PUBLIC USE