



## Station to Station Job Briefing Requirements

The acting Conductor will initiate the station to station job briefing at each station stop prior to departing. The engineer will acknowledge verbally what was said. Express and equipment trains must communicate the following passing each station

- What signal indication are you currently working on?
- Applicable speed changes between stations including: zone speed, PSOs; R43s, foreman's restrictions, crossing protect (103g)
- Upcoming 42/43 flags
- Next station stop
- Platform restrictions or moved markers
- Review arrival/departure time against 660 and note any delays
  - Report delays to NOC if total delay is 5 min or greater as soon as it is safe to do so
- Anything else that may pertain to your movement