PROGRAM CODE:

```
clc;
clear;
s=%s;
G1=syslin('c',1,s+2);//Get the numerator and denominator of the transfer function G1
G2=syslin('c',4,s);//Get the numerator and denominator of the transfer function G2
T1=G1*G2;//series or cascade system
disp (T1, "The series transfer function of T1 = ");
T2=G1+G2;//parallel system
disp (T2, "The parallel transfer function of T2 = ");
T3=G1/(1+G1*G2);//positive feedback system
disp (T3, "The positive feedback transfer function of T3 = ");
T4=G1/(1-G1*G2);//negative feedback system
disp (T4, "The negative feedback transfer function of T4 = ");
```

