

=====

=====

TECHNOVA ELECTRONICS - SMARTWATCH USER MANUAL

Complete Guide for TechNova Pro X1 Smartwatch

=====

=====

MODEL: TechNova Pro X1

FIRMWARE VERSION: 2.0.1

MANUAL VERSION: 1.0

DATE: January 2026

PART NUMBER: TN-SW-PROX1-UM-001

=====

=====

IMPORTANT SAFETY INFORMATION

=====

=====

READ BEFORE USING YOUR SMARTWATCH

- Read all instructions before use
- Keep this manual for future reference
- Follow all warnings and instructions
- This is NOT a medical device
- Do not use for medical diagnosis
- Consult doctor for health concerns
- Keep away from children under 3 years
- Contains small parts (choking hazard)

WARNINGS:

- Do not expose to fire or extreme heat
- Do not puncture or disassemble
- Do not expose to excessive moisture
- Do not wear during contact sports
- Remove if skin irritation occurs
- Do not charge when wet
- Use only provided charger
- Do not wear too tight

CAUTION:

- Water resistance may decrease over time
- Avoid extreme temperatures
- Avoid strong magnetic fields
- Clean regularly to prevent skin irritation
- Replace if damaged

=====

=====

TABLE OF CONTENTS

=====

=====

CHAPTER 1: GETTING STARTED 1

1.1 Package Contents

1.2 Product Overview

1.3 Specifications

1.4 Initial Setup

1.5 Charging

CHAPTER 2: BUTTONS AND NAVIGATION 8

2.1 Button Functions

2.2 Touch Gestures

2.3 Crown Controls

2.4 Navigation Basics

CHAPTER 3: PAIRING WITH PHONE 12

3.1 Downloading the App

3.2 Creating Account

3.3 Bluetooth Pairing

3.4 Permissions Setup

3.5 Troubleshooting

CHAPTER 4: DISPLAY AND WATCH FACES 18

4.1 Display Features

4.2 Changing Watch Faces

4.3 Always-On Display

4.4 Brightness Settings

CHAPTER 5: HEALTH MONITORING 22

5.1 Heart Rate Monitoring

5.2 SpO2 Measurement

5.3 Sleep Tracking

5.4 Stress Monitoring

5.5 Skin Temperature

CHAPTER 6: FITNESS TRACKING 27

6.1 Steps Counter

- 6.2 Workout Modes
- 6.3 GPS Tracking
- 6.4 Calories Burned
- 6.5 Fitness Goals

CHAPTER 7: NOTIFICATIONS AND CALLS 32

- 7.1 Notification Setup
- 7.2 Call Notifications
- 7.3 Message Notifications
- 7.4 App Notifications
- 7.5 Do Not Disturb

CHAPTER 8: BLUETOOTH CALLING 36

- 8.1 Making Calls
- 8.2 Receiving Calls
- 8.3 Call History
- 8.4 Contacts
- 8.5 Call Settings

CHAPTER 9: MUSIC CONTROL 39

- 9.1 Music Playback
- 9.2 Volume Control
- 9.3 Supported Apps

CHAPTER 10: SMART FEATURES 41

- 10.1 Voice Assistant
- 10.2 Find My Phone
- 10.3 Camera Control
- 10.4 Weather

10.5 Alarms and Timer

CHAPTER 11: SETTINGS AND CUSTOMIZATION 45

11.1 System Settings

11.2 Display Settings

11.3 Sound Settings

11.4 Connectivity Settings

CHAPTER 12: BATTERY MANAGEMENT 49

12.1 Battery Life

12.2 Power Saving Mode

12.3 Charging Best Practices

12.4 Battery Tips

CHAPTER 13: MAINTENANCE AND CARE 52

13.1 Cleaning Instructions

13.2 Water Resistance Care

13.3 Strap Maintenance

13.4 Storage Guidelines

CHAPTER 14: TROUBLESHOOTING 55

14.1 Common Issues

14.2 Error Messages

14.3 Reset Procedures

14.4 Contact Support

=====

=====

CHAPTER 1: GETTING STARTED

=====

=====

1.1 Package Contents

Congratulations on purchasing the TechNova Pro X1 Smartwatch!

Your package includes:

- TechNova Pro X1 Smartwatch (1 unit)
- Magnetic charging cable (1 unit)
- User manual (this document)
- Warranty card (1 unit)
- Quick start guide (1 unit)
- TechNova brand sticker (2 units)

IMPORTANT: Inspect all items immediately upon opening. If any item is missing or damaged, contact TechNova customer care within 7 days of purchase.

Contact: 1800-123-4567 or support@technovaelectronics.com

1.2 Product Overview

FRONT VIEW:

	1.43" AMOLED	
	Display	
	Touch Screen	

| Always-On Capable |

SIDE VIEW (Left):

| _____ |

| | ■ | Crown Button |

| _____ (Power/Function) |

| _____ |

| _____ |

| | □ | Side Button |

| _____ (Quick Access) |

| _____ |

| Speaker Grille |

| Microphone Hole |

BACK VIEW:

| Heart Rate Sensor |

| (Green LED) |

| _____ |

| SpO2 Sensor |

| (Red LED) |

| _____ |

| Skin Temperature |

| Sensor |

| _____ |

| ●●●● Charging Contacts |

Model Info Engraved	

STRAP:

- Width: 22mm (standard)
- Material: Premium silicone
- Length: Adjustable (140-220mm)
- Type: Quick-release pins
- Color: Multiple options available
- Interchangeable: Yes (22mm straps)

1.3 Specifications

DISPLAY:

- Type: AMOLED (Active Matrix Organic Light Emitting Diode)
- Size: 1.43 inches (diagonal)
- Resolution: 466 × 466 pixels
- Pixel Density: 326 PPI (Pixels Per Inch)
- Aspect Ratio: 1:1 (square)
- Brightness: Up to 1000 nits (peak)
- Contrast Ratio: 60,000:1
- Color Gamut: 100% DCI-P3
- Glass: 2.5D curved tempered glass
- Coating: Anti-fingerprint, scratch-resistant

SENSORS:

- Optical Heart Rate Sensor (PPG)
- SpO2 (Blood Oxygen) Sensor

- 3-Axis Accelerometer
- 3-Axis Gyroscope
- Ambient Light Sensor
- Skin Temperature Sensor
- Geomagnetic Sensor (compass)

PROCESSOR & MEMORY:

- Processor: Dual-core 1.3 GHz
- RAM: 512 MB
- Storage: 4 GB internal
- Operating System: TechNova OS 2.0 (based on RTOS)

CONNECTIVITY:

- Bluetooth: Version 5.2 BLE (Bluetooth Low Energy)
- Bluetooth Profiles: A2DP, AVRCP, HFP, HSP
- Bluetooth Range: Up to 10 meters (33 feet)
- GPS: Connected GPS (uses phone's GPS)
- WiFi: Not included
- NFC: Not included
- Cellular: Not included

BATTERY:

- Type: Lithium Polymer (Li-Po)
- Capacity: 380 mAh
- Voltage: 3.7V
- Charging Input: 5V DC, 500mA
- Charging Time: Approximately 2 hours (0-100%)
- Battery Life:
 - Typical Use: Up to 7 days

- Heavy Use: 3-4 days
- Power Saving Mode: Up to 14 days
- Standby: Up to 30 days
- Charge Cycles: 500+ cycles (80% capacity retention)

PHYSICAL SPECIFICATIONS:

- Case Material: Aluminum alloy (aviation grade)
- Case Finish: Anodized, matte and glossy options
- Case Size: 46mm × 46mm × 10.7mm
- Weight: 42 grams (with strap)
- Strap Width: 22mm (standard)
- Strap Length: 140-220mm (adjustable)
- Lug Width: 22mm
- Water Resistance: IP68 / 5ATM (50 meters)

DISPLAY FEATURES:

- Touch Type: Capacitive multi-touch
- Always-On Display: Supported
- Auto-Brightness: Yes (ambient light sensor)
- Manual Brightness: 5 levels
- Screen Timeout: 10s, 15s, 20s, 30s, 1min
- Raise to Wake: Supported
- Tap to Wake: Supported
- Gestures: Swipe, tap, pinch (in some apps)

AUDIO:

- Speaker: Built-in mono speaker (8Ω, 0.5W)
- Microphone: MEMS microphone (omnidirectional)
- Audio Codec: SBC, AAC

- Noise Cancellation: Basic ENC (Environmental Noise Cancellation)
- Call Quality: HD voice calling

COMPATIBILITY:

- Android: Version 6.0 (Marshmallow) and above
- iOS: Version 12.0 and above
- Required App: TechNova Fit (free download)
- Bluetooth: Version 4.0 or higher (phone)

ENVIRONMENTAL:

- Operating Temperature: 0°C to 45°C (32°F to 113°F)
- Storage Temperature: -20°C to 60°C (-4°F to 140°F)
- Humidity: 5% to 90% non-condensing
- Altitude: Up to 3000 meters (9842 feet)

CERTIFICATIONS:

- BIS (Bureau of Indian Standards)
- CE (European Conformity)
- FCC (Federal Communications Commission)
- RoHS (Restriction of Hazardous Substances)
- REACH (Registration, Evaluation, Authorization of Chemicals)
- IP68 (Ingress Protection)
- 5ATM (Water Resistance)

1.4 Initial Setup

BEFORE FIRST USE:

Step 1: Charge Your Watch

IMPORTANT: Charge your watch fully before first use.

1. Locate the magnetic charging cable in the box
2. Connect the USB end to a power source:
 - USB port on computer/laptop
 - USB wall adapter (5V/1A or 5V/2A recommended)
 - Power bank with USB port
 - Car USB charger
3. Align the magnetic connector with the charging contacts on the back of the watch
4. The magnets will automatically snap into place
5. Ensure all 4 pins are making good contact
6. Charging icon will appear on screen
7. Wait until battery is 100% charged (approximately 2 hours)

CHARGING INDICATORS:

- Red battery icon: 0-20% (charging)
- Yellow battery icon: 20-80% (charging)
- Green battery icon: 80-100% (charging)
- Full green battery: 100% (fully charged)
- Vibration: Confirms charging started
- Vibration: Confirms fully charged

TIP: For first charge, leave on charger for at least 2 hours even if it shows 100% earlier. This calibrates the battery.

Step 2: Power On

First Time Power On:

1. Press and hold the Crown Button (main button) for 3 seconds
2. TechNova logo will appear on screen
3. Wait for boot process to complete (10-20 seconds)
4. Home screen/watch face will appear
5. Watch is now ready for setup

Subsequent Power On:

- Press and hold Crown Button for 2 seconds
- Or raise your wrist (if Raise to Wake enabled)
- Or tap screen (if Tap to Wake enabled)

Step 3: Choose Language (if prompted)

On first boot, you may be prompted to select language:

1. Rotate crown to scroll through languages
2. Tap on your preferred language
3. Confirm selection
4. Interface will update to selected language

Available Languages:

- English (default)
- Hindi
- Spanish
- French
- German
- Italian
- Portuguese
- Russian
- Chinese (Simplified)

- Chinese (Traditional)
- Japanese
- Korean
- Arabic
- And 20+ more languages

Step 4: Select Wrist Preference

For accurate tracking, tell the watch which wrist you wear it on:

1. Watch will prompt: "Which wrist do you wear on?"
2. Options: Left Wrist / Right Wrist
3. Select your wrist
4. This affects:
 - Gesture controls (raise to wake)
 - Button operation (if configured)
 - Activity tracking accuracy
5. Can be changed later in Settings

Step 5: Adjust Strap

Proper fit is important for accurate tracking and comfort:

1. Remove watch from charging cable
2. Place on your wrist
3. Adjust strap to comfortable fit
4. Proper fit guidelines:
 - Snug but not tight
 - Should not slide around

- Should leave slight imprint when removed
- Should allow one finger to fit between strap and wrist
- Not too loose (affects sensor accuracy)
- Not too tight (causes discomfort)

POSITIONING FOR ACCURACY:

- Wear 1-2 cm above wrist bone
- Sensors should be in contact with skin
- Not too loose (sensors need contact)
- Clean skin contact area regularly
- Tighten during workouts for better accuracy

1.5 Charging

CHARGING YOUR WATCH:

Step-by-Step Charging:

1. Use ONLY the provided magnetic charging cable
2. Connect USB end to power source:
 - Computer/laptop USB port (5V/0.5A)
 - USB wall adapter (5V/1A or 5V/2A recommended)
 - Power bank (5V/1A or higher)
 - Car USB charger
 - Do NOT use fast chargers (9V, 12V, etc.)
3. Align magnetic connector with charging contacts on watch back
4. Magnets will automatically align and snap into place
5. Ensure all 4 pins are touching the contacts
6. Charging icon appears on screen
7. Wait for charging to complete

CHARGING TIME:

- 0% to 100%: Approximately 2 hours
- 0% to 50%: Approximately 45 minutes
- 0% to 80%: Approximately 1.5 hours
- Trickle charging: Additional 15-20 minutes after 100%

CHARGING TIPS:

- Charge on flat, stable surface
- Ensure good ventilation
- Don't cover while charging
- Remove watch from charger when fully charged
- Don't leave on charger for extended periods (days)
- Charge in room temperature (15-25°C ideal)
- Avoid charging in direct sunlight
- Avoid charging in very cold conditions

BATTERY INDICATORS:

While Charging:

- Battery icon: Shows charging animation
- Percentage: Increases every few minutes
- Color: Red (0-20%), Yellow (20-80%), Green (80-100%)
- Time remaining: Estimated time to full charge

When Fully Charged:

- Shows "100%"
- "Fully Charged" message
- Vibration confirmation (if enabled)
- Battery icon green and full

- Recommended to disconnect charger

LOW BATTERY:

At 20%:

- Low battery warning appears
- Battery icon turns red
- Suggestion to charge soon

At 10%:

- Critical battery warning
- "Please charge your watch" message
- Vibrates every 30 minutes
- Some features may be limited

At 5%:

- Urgent charging needed
- Very limited functionality
- May auto-shutdown soon
- Charge immediately

At 0%:

- Watch shuts down automatically
- All settings saved
- Charge as soon as possible
- May take 5-10 minutes to show charging icon

BATTERY SAFETY:

- Use only provided charger
- Don't charge when watch is wet

- Don't charge in extreme temperatures
- Don't puncture or damage battery
- If battery swells, stop using immediately
- Contact customer support if battery issues
- Recycle properly at end of life

=====

=====

CHAPTER 2: BUTTONS AND NAVIGATION


=====

=====

2.1 Button Functions

Your TechNova Pro X1 has two physical buttons:

CROWN BUTTON (Main Button - Top):



Functions:

Press Once (Short Press):

- Wake up display (when sleep)
- Go to home screen (from any app)
- View notifications (when on home screen)
- Confirm selection (in some menus)
- Open app drawer (from home screen)

Press and Hold (3 seconds):

- Power on (when watch is off)
- Power off menu (when watch is on)
- Force restart (when frozen, 10 seconds)

Press and Hold (5-10 seconds):

- Force restart (if watch is frozen)
- Use only when watch is unresponsive

Rotate (Scroll):

- Scroll through menus (up/down)
- Adjust values (brightness, volume, etc.)
- Zoom in/out (in some apps)
- Navigate lists
- Change watch faces (when on home)

Double Press:

- Quick access to workout modes (default)
- Customizable in Settings
- Opens last used app (if configured)

Press Three Times:

- Customizable shortcut
- Default: None
- Can set to: Flashlight, Camera, Music, etc.

SIDE BUTTON (Function Button - Bottom):



| □ | ← Side Button (Quick Access)



Functions:

Press Once (Short Press):

- Quick access to workout modes (default)
- Customizable in Settings
- Opens selected app or feature

Press and Hold (2 seconds):

- Quick launch camera control (default)
- Customizable in Settings
- Opens selected app or feature

Double Press:

- Quick access to voice assistant (default)
- Customizable in Settings
- Opens selected app or feature

BUTTON CUSTOMIZATION:

You can customize button functions:

1. Go to Settings
2. Buttons & Gestures
3. Select Crown or Side button
4. Choose from available actions:
 - Workout modes
 - Heart rate
 - SpO2
 - Music

- Camera
- Flashlight
- Voice assistant
- Find my phone
- Specific app
- None (disable)

BUTTON TIPS:

- Don't press too hard (gentle pressure sufficient)
- Keep buttons clean and free from debris
- If buttons feel sticky, clean with dry cloth
- Don't use sharp objects to press buttons
- Buttons are rated for 100,000+ presses

2.2 Touch Gestures

The touchscreen supports various gestures:

TAP (Single Tap):

- Tap once with finger
- Used for:
 - Selecting items
 - Opening apps
 - Confirming actions
 - Viewing notifications
 - Interacting with buttons on screen

TIP: Use the tip of your finger, not fingernail

DOUBLE TAP:

- Tap twice quickly
- Used for:
 - Wake display (if enabled)
 - Snooze alarm
 - Start/stop workout
 - Answer/end call (if enabled)
 - Play/pause music (if enabled)

TIP: Second tap must be within 300ms of first tap

LONG PRESS (Press and Hold):

- Press and hold for 1-2 seconds
- Used for:
 - Change watch face (long press on home)
 - App options menu
 - Rearrange app icons
 - Delete widgets
 - Access additional options

TIP: You'll feel vibration or see visual feedback

SWIPE:

Swipe DOWN (from top edge):

- Quick settings panel
- Access:
 - Brightness slider
 - Flashlight toggle

- Do Not Disturb
- Airplane mode
- Settings shortcut

Swipe UP (from bottom edge):

- Notifications panel
- View:
 - Current notifications
 - Clear all button
 - Quick replies
 - Notification history (if enabled)

Swipe LEFT:

- Previous screen
- Previous widget
- Go back in some apps
- Previous watch face (on home)

Swipe RIGHT:

- Next screen
- Next widget
- Go forward in some apps
- Next watch face (on home)

PINCH:

Pinch IN (Zoom Out):

- Not commonly used
- Some apps support zoom out

- Maps or photos (if applicable)

Pinch OUT (Zoom In):

- Not commonly used
- Some apps support zoom in
- Maps or photos (if applicable)

GESTURE SETTINGS:

Customize gestures in Settings:

- Settings → Buttons & Gestures
- Enable/disable gestures
- Adjust sensitivity
- Configure tap to wake
- Configure raise to wake

GESTURE TIPS:

- Use clean, dry fingers
- Don't use excessive force
- Keep screen clean for best response
- Remove screen protector if interfering
- Restart watch if gestures not responding

2.3 Crown Controls

The crown button is your primary navigation tool:

ROTATING THE CROWN:

Rotate Clockwise (Up):

- Scroll up through lists
- Increase values (brightness, volume, etc.)
- Zoom in (in some apps)
- Move to next item
- Fast forward (in music)

Rotate Counter-Clockwise (Down):

- Scroll down through lists
- Decrease values
- Zoom out (in some apps)
- Move to previous item
- Rewind (in music)

CROWN SCROLLING:

- Smooth, precise scrolling
- One notch = one item (in lists)
- Fast scroll = continuous scrolling
- Haptic feedback on each notch
- Responsive and accurate

CROWN PRESSING:

As described in Section 2.1

CROWN TIPS:

- Rotate gently (don't force)
- Clean around crown regularly
- Don't pull crown out (not water-resistant when pulled)
- If crown feels loose, contact support
- Crown is water-resistant when flush with case


CROWN SHORTCUTS:

- Double press: Quick access (customizable)
- Triple press: Disabled (can enable)
- Hold + rotate: Skip (in music player)
- Rotate while in app: Scroll (if supported)

2.4 Navigation Basics

Understanding the watch interface:


HOME SCREEN:



Default home screen shows:

- Current time
- Date
- Watch face design
- Swipe to access other features

APP DRAWER:




Access: Press crown from home screen

Shows: All installed apps in grid

Navigate: Rotate crown or swipe

Open: Tap on app icon

WIDGETS:




Access: Swipe left/right from home

Shows: Quick access to data

Customize: Add/remove widgets

Navigate: Swipe or rotate crown

QUICK SETTINGS:




Access: Swipe down from top

Shows: Quick toggles and settings

Toggle: Tap on icons

Adjust: Use crown for sliders

NOTIFICATIONS:



Access: Swipe up from bottom

Shows: Recent notifications

Interact: Tap to open, swipe to dismiss

Manage: Clear individual or all

BACK NAVIGATION:

- Swipe from left edge: Go back
- Or press back button (if shown in app)
- Or press crown: Go to home
- Or gesture: Swipe right (in some apps)

MULTITASKING:

- Swipe up and hold: Recent apps
- Shows last 3-5 apps used
- Tap to switch
- Swipe app away to close
- Or use app switcher (if available)

NAVIGATION TIPS:

- Practice basic gestures
- Use crown for precise scrolling
- Don't rush gestures
- Learn app-specific navigation
- Explore all menus
- Customize to your preference

=====

=====

CHAPTER 3: PAIRING WITH PHONE

=====

=====

3.1 Downloading the App

IMPORTANT: You must install the TechNova Fit app on your phone to use the smartwatch with full functionality.

FOR ANDROID USERS:

Step 1: Open Google Play Store

- Tap Play Store icon on your phone
- Or visit: play.google.com

Step 2: Search for App

- Tap search bar
- Type: "TechNova Fit"
- Or scan QR code from quick start guide

Step 3: Find Official App

- Look for: "TechNova Fit" by TechNova Electronics Pvt. Ltd.
- Icon: Blue and white with heart rate symbol
- Rating: 4.0+ stars
- Downloads: 1M+
- Size: ~50 MB

Step 4: Install App

- Tap "Install" button
- Wait for download and installation
- App will appear on home screen
- Grant necessary permissions

FOR iOS (iPhone) USERS:

Step 1: Open App Store

- Tap App Store icon
- Or visit: apps.apple.com

Step 2: Search for App

- Tap search tab
- Type: "TechNova Fit"
- Or scan QR code

Step 3: Find Official App

- Look for: "TechNova Fit" by TechNova Electronics Pvt. Ltd.
- Icon: Blue and white with heart rate
- Rating: 4.0+ stars
- Size: ~60 MB

Step 4: Install App

- Tap "Get" or download icon
- Authenticate with Face ID/Touch ID/Apple ID
- Wait for download and installation
- App appears on home screen

APP REQUIREMENTS:

Android:

- Android 6.0 (Marshmallow) or higher
- Bluetooth 4.0 or higher

- 100 MB free storage
- Internet connection (for initial setup)
- RAM: 1 GB minimum (2 GB recommended)

iOS:

- iOS 12.0 or higher
- iPhone 5s or newer
- 100 MB free storage
- Internet connection (for initial setup)
- iPad: Not supported (iPhone only)

ALTERNATIVE DOWNLOAD:

If app not available in your region:

- Visit: www.technovaelectronics.com/app
- Download APK (Android only)
- Enable "Install from unknown sources"
- Install manually
- Scan QR code from manual

3.2 Creating Account

After installing the app:

Step 1: Open App

- Tap TechNova Fit icon
- App may request permissions
- Grant necessary permissions
- Welcome screen appears

Step 2: Create Account

Option A: Mobile Number (Recommended)

1. Tap "Sign Up with Mobile"
2. Enter your mobile number
3. Select country code
4. Tap "Send OTP"
5. Enter 6-digit OTP received via SMS
6. Account created automatically
7. Proceed to profile setup

Option B: Email Address

1. Tap "Sign Up with Email"
2. Enter email address
3. Create password (min 8 characters)
4. Confirm password
5. Tap "Create Account"
6. Verify email (check inbox)
7. Click verification link
8. Account activated

Option C: Social Login (Fastest)

1. Tap "Continue with Google" or "Continue with Apple"
2. Select your account
3. Grant permissions
4. Account created automatically
5. No additional verification needed

Step 3: Complete Profile

- Enter your name (first and last)
- Select gender (male/female/other)
- Enter date of birth
- Enter height (cm or ft/in)
- Enter weight (kg or lbs)
- Set fitness goals (optional)
- Tap "Continue" or "Save"

Step 4: Account Benefits

- Sync data across devices
- Backup health data
- Access from multiple devices
- Receive updates and tips
- Customer support
- Community features

3.3 Bluetooth Pairing

STEP-BY-STEP PAIRING:

On Your Phone:

1. Enable Bluetooth:
 - Go to Settings → Bluetooth
 - Or use quick settings
 - Turn Bluetooth ON
2. Open TechNova Fit app
3. Tap "Devices" tab (bottom)
4. Tap "Add Device" or "+" icon
5. Select "Smartwatch"

6. Choose "TechNova Pro X1" from list

On Your Watch:

7. Ensure watch is powered on
8. Watch should show pairing mode
9. If not, go to Settings → Bluetooth
10. Enable Bluetooth on watch
11. Make watch discoverable

Complete Pairing:

12. Watch appears in "Available Devices" in app
13. Tap on your watch (shows model number)
14. Pairing request appears on phone
15. Pairing request appears on watch
16. Confirm on BOTH devices:
 - Tap "✓" or "Pair" on phone
 - Tap "✓" on watch
17. Wait for "Connected" message
18. Watch face syncs to phone
19. Time and date set automatically
20. Pairing complete!

PAIRING TIME:

- Typically: 30-60 seconds
- First time: Up to 2 minutes
- Subsequent: Faster

PAIRING TIPS:

- Keep watch and phone within 1 meter (3 feet)

- Ensure watch has 20%+ battery
- Close and reopen app if issues
- Restart Bluetooth on phone
- Don't pair with multiple phones simultaneously

AFTER PAIRING:

- Watch shows connected status
- App shows device details
- Time syncs automatically
- Notifications start working
- Data syncs to app
- Firmware update check (if available)

3.4 Permissions Setup

IMPORTANT: Grant all necessary permissions for full functionality.

NECESSARY PERMISSIONS:

LOCATION (Important):

Why needed:

- GPS tracking for workouts
- Weather updates
- Distance calculation
- Map features

Permission type:

- Android: "Allow only while using app" or "Allow all the time"
- iOS: "While Using the App"

How to enable:

- Android: Settings → Apps → TechNova Fit → Permissions → Location → Allow
- iOS: Settings → TechNova Fit → Location → While Using the App

NOTIFICATIONS (Important):

Why needed:

- Call notifications
- Message notifications
- App notifications
- Alerts and reminders

Permission type:

- Android: Allow all notifications
- iOS: Allow notifications

How to enable:

- Android: Settings → Apps → TechNova Fit → Notifications → Allow all
- iOS: Settings → Notifications → TechNova Fit → Allow Notifications

BLUETOOTH (Essential):

Why needed:

- Connect to watch
- Sync data
- Firmware updates
- Call audio

Permission type:

- Android: Allow Bluetooth

- iOS: Automatically granted

How to enable:

- Android: Settings → Apps → TechNova Fit → Permissions → Bluetooth → Allow
- iOS: Automatically enabled when app installed

PHYSICAL ACTIVITY (Important):

Why needed:

- Step counting
- Workout tracking
- Health data sync
- Fitness metrics

Permission type:

- Android: Allow physical activity
- iOS: Automatically granted with Health app access

How to enable:

- Android: Settings → Apps → TechNova Fit → Permissions → Physical Activity → Allow
- iOS: Settings → Privacy → Motion & Fitness → TechNova Fit → Enable

HEALTH DATA (iOS Only):

Why needed:

- Apple Health integration
- Data export
- Health insights

Permission type:

- iOS: Allow read and write access to Health app

How to enable:

- iOS: Settings → Privacy → Health → TechNova Fit → Enable all categories

CONTACTS (For Calling):

Why needed:

- Sync contacts to watch
- Caller ID display
- Quick dial

Permission type:

- Android: Allow contacts
- iOS: Allow contacts

How to enable:

- Android: Settings → Apps → TechNova Fit → Permissions → Contacts → Allow
- iOS: Settings → Privacy → Contacts → TechNova Fit → Enable

MICROPHONE (For Calling):

Why needed:

- Bluetooth calling
- Voice assistant
- Audio during calls

Permission type:

- Android: Allow microphone
- iOS: Allow microphone

How to enable:

- Android: Settings → Apps → TechNova Fit → Permissions → Microphone → Allow
- iOS: Settings → Privacy → Microphone → TechNova Fit → Enable

CAMERA (Optional):

Why needed:

- QR code scanning (for pairing)
- Remote camera control

Permission type:

- Android: Allow camera
- iOS: Allow camera

How to enable:

- Android: Settings → Apps → TechNova Fit → Permissions → Camera → Allow
- iOS: Settings → Privacy → Camera → TechNova Fit → Enable

STORAGE (Android Only):

Why needed:

- Store watch faces
- Store firmware updates
- Cache data

Permission type:

- Android: Allow storage

How to enable:

- Android: Settings → Apps → TechNova Fit → Permissions → Storage → Allow

ALWAYS RUN IN BACKGROUND (Android Only):

Why needed:

- Continuous sync
- Background data
- Notifications
- Always-connected

How to enable:

- Android: Settings → Apps → TechNova Fit → Battery → Background restriction → Disable
- Or: Settings → Apps → TechNova Fit → Advanced → Battery optimization → Don't optimize

PERMISSION CHECKLIST:

- ✓ Location
- ✓ Notifications
- ✓ Bluetooth
- ✓ Physical Activity
- ✓ Health (iOS)
- ✓ Contacts (for calling)
- ✓ Microphone (for calling)
- ✓ Camera (optional)
- ✓ Storage (Android)
- ✓ Background running (Android)

3.5 Troubleshooting

COMMON PAIRING ISSUES:

ISSUE: Watch not found in app

Solutions:

1. Ensure Bluetooth is ON on phone
2. Bring watch closer to phone (within 1 meter)
3. Restart Bluetooth on phone (turn off, wait 5 seconds, turn on)
4. Restart watch (Settings → System → Restart)
5. Ensure watch is in pairing mode
6. Check watch battery (20%+ required)
7. Close and reopen app
8. Restart phone
9. Update app to latest version
10. Try with different phone

ISSUE: Pairing fails or disconnects

Solutions:

1. Cancel existing pairing in phone Bluetooth settings
2. "Forget" device in Bluetooth settings
3. Restart both phone and watch
4. Move away from other Bluetooth devices
5. Ensure no interference (WiFi routers, microwaves)
6. Update phone OS to latest version
7. Update app to latest version
8. Reset watch network settings
9. Try pairing again from scratch
10. Contact support if persists

ISSUE: Connection keeps dropping

Solutions:

1. Keep phone within 10 meters of watch
2. Remove obstacles between phone and watch
3. Check for Bluetooth interference
4. Update watch firmware
5. Re-pair devices
6. Check phone Bluetooth range
7. Disable battery optimization for app
8. Allow app to run in background
9. Restart both devices
10. Try different phone (to isolate issue)

ISSUE: App crashes during pairing

Solutions:

1. Clear app cache (Android: Settings → Apps → TechNova Fit → Storage → Clear Cache)
2. Update app to latest version
3. Reinstall app (delete and install again)
4. Restart phone
5. Check phone has enough storage (100+ MB free)
6. Try different network (WiFi/mobile data)
7. Contact support with error details

ISSUE: Notifications not working

Solutions:

1. Grant notification permission to app
2. Enable notifications in app settings

3. Select which apps to notify
4. Ensure watch is connected
5. Restart app
6. Re-pair watch
7. Check phone notification settings
8. Disable Do Not Disturb
9. Update app
10. Restart phone

ISSUE: Time not syncing

Solutions:

1. Ensure watch is connected to app
2. Open app and sync manually
3. Check phone time is correct
4. Restart watch
5. Re-pair devices
6. Update firmware
7. Check time zone settings
8. Contact support

ISSUE: Firmware update stuck

Solutions:

1. Ensure 50%+ battery on watch
2. Keep watch on charger during update
3. Keep phone near watch
4. Don't close app during update
5. Wait for 10-15 minutes

6. If stuck >30 minutes, restart watch
7. Try update again
8. Contact support if fails repeatedly

GETTING HELP:

- In-app support: Profile → Help & Support
- Website: support.technovaelectronics.com
- Email: support@technovaelectronics.com
- Phone: 1800-123-4567
- WhatsApp: +91-9876543210

=====

=====

CHAPTER 4: DISPLAY AND WATCH FACES

=====

=====

4.1 Display Features

Your TechNova Pro X1 features a premium AMOLED display:

DISPLAY CHARACTERISTICS:

AMOLED Technology:

- Active Matrix Organic Light Emitting Diode
- Each pixel emits its own light
- True blacks (pixels turn off completely)
- High contrast ratio (60,000:1)
- Vibrant, saturated colors
- Wide color gamut (100% DCI-P3)

- Fast response time
- Wide viewing angles
- Energy efficient (dark pixels use less power)

Resolution:

- 466 × 466 pixels
- 326 PPI (Pixels Per Inch)
- Sharp, crisp text and images
- No pixelation visible at normal viewing distance

Brightness:

- Maximum: 1000 nits (peak)
- Minimum: 5 nits
- Auto-brightness: 5-1000 nits (ambient sensor)
- Manual levels: 5 preset levels
- Excellent outdoor visibility
- Auto-adjusts to environment

4.2 Changing Watch Faces

CUSTOMIZING YOUR WATCH FACE:

METHOD 1: On Watch (Quickest)

Step 1: Access Watch Face

- From home screen, long press (2 seconds) on current watch face
- Or swipe left/right to browse installed faces
- Watch face selection screen appears

Step 2: Browse Watch Faces

- Rotate crown to scroll through available faces
- Or swipe left/right
- Preview shows on screen
- Tap to select

Step 3: Confirm Selection

- Selected face appears full screen
- Press crown to confirm
- Or tap "Apply" button
- New face applied immediately

METHOD 2: In App (More Options)

Step 1: Open TechNova Fit App

- Launch app on phone
- Go to "Devices" tab
- Select your watch
- Tap "Watch Faces" or "Watch Face Store"

Step 2: Browse Store

- Categories: Analog, Digital, Sport, Minimal, Animated, etc.
- Featured faces
- New releases
- Popular faces
- Search by name

Step 3: Preview and Download

- Tap on face to preview

- See how it looks on your watch
- Tap "Download" or "Apply"
- Face syncs to watch automatically
- Wait for sync to complete

Step 4: Set as Active

- Most faces apply automatically
- Or select from "My Faces"
- Tap "Apply" or "Set as Active"
- Face appears on watch

WATCH FACE CATEGORIES:

ANALOG FACES:

- Traditional clock design
- Hour, minute, second hands
- Elegant and classic
- Professional look
- Examples: Classic, Minimal, Elegant, Vintage

DIGITAL FACES:

- Large digital numbers
- Easy to read
- Modern design
- Often includes complications
- Examples: Digital, Bold, Modern, Tech

ANIMATED FACES:

- Moving elements

- Dynamic backgrounds
- Interactive features
- Eye-catching
- Higher battery usage
- Examples: Particles, Nature, Space, Abstract

MINIMAL FACES:

- Simple, clean design
- Less visual clutter
- Battery efficient
- Professional
- Examples: Minimalist, Clean, Simple, Basic

SPORT FACES:

- Fitness data display
- Step count, heart rate
- Activity rings
- Motivational
- Examples: Sport, Fitness, Active, Workout

INFORMATION FACES:

- Multiple complications
- Weather, calendar, battery
- Detailed data
- Functional
- Examples: Info, Data, Calendar, Weather

COMPLICATIONS:

Small widgets on watch face showing:

- Date
- Day
- Battery level
- Steps
- Heart rate
- Weather
- Calendar events
- Custom data

CUSTOMIZATION OPTIONS:

Some watch faces allow:

- Color changes (tap to cycle colors)
- Complication selection (choose what data to show)
- Layout options (arrange elements)
- Font styles
- Background images
- Personalization

TIPS:

- Try different faces for different occasions
- Use simple faces for battery saving
- Use animated faces for special occasions
- Match face to your outfit/style
- Explore watch face store regularly
- Download multiple faces for variety

4.3 Always-On Display

ALWAYS-ON DISPLAY (AOD) FEATURE:

WHAT IS ALWAYS-ON DISPLAY?

- Display stays on at all times
- Shows simplified watch face
- Dimmed brightness (to save battery)
- Shows time and essential info
- No need to raise wrist or tap
- Always visible at a glance

BENEFITS:

- Quick time check
- Professional appearance
- No wrist movement needed
- Always aware of time
- Convenient in meetings

BATTERY IMPACT:

- Normal mode: 7 days battery
- AOD enabled: 3-4 days battery
- AOD reduces battery by ~50%
- Depends on usage and settings

HOW TO ENABLE:

METHOD 1: On Watch

1. Swipe down for quick settings
2. Tap "Always-On" icon
3. Or: Settings → Display → Always-On Display
4. Toggle ON

5. Configure options (see below)

METHOD 2: In App

1. Open TechNova Fit app
2. Devices → Your Watch
3. Display Settings
4. Always-On Display
5. Toggle ON
6. Configure options

AOD SETTINGS:

Enable/Disable:

- Toggle AOD on or off
- Immediate effect

Schedule:

- Always: AOD on 24/7
- Scheduled: AOD on during specific hours
- Example: 8 AM - 10 PM
- Outside schedule: AOD off (saves battery)

Smart AOD:

- AOD on when watch detects you're awake
- AOD off during sleep hours
- Uses sleep tracking data
- Automatic scheduling

Display Mode:

- Dimmed: Reduced brightness (saves battery)
- Normal: Standard brightness
- Custom: Set custom brightness level

Watch Face:

- Choose AOD-specific face
- Simpler design (saves battery)
- Only essential info
- Or use same face as normal

Tap to Wake:

- Tap screen to wake from AOD
- Opens full watch face
- Configurable

RAISE TO WAKE:

Works with AOD:

- Raise wrist: AOD → Full face
- Lower wrist: Full face → AOD
- Seamless transition

WHEN AOD TURNS OFF AUTOMATICALLY:

- Battery below 10%
- Power saving mode enabled
- Theater mode enabled
- During sleep (if smart AOD)
- When not worn (proximity sensor)

TIPS:

- Use AOD for convenience
- Disable AOD for maximum battery
- Use scheduled AOD for balance
- Choose simple AOD face
- Smart AOD is best option

4.4 Brightness Settings

ADJUSTING DISPLAY BRIGHTNESS:

MANUAL BRIGHTNESS:

How to Adjust:

1. Swipe down from top (quick settings)
2. Brightness slider appears
3. Drag slider or rotate crown
4. 5 levels available:
 - Level 1: Very dim (5-20 nits)
 - Level 2: Dim (20-100 nits)
 - Level 3: Medium (100-300 nits)
 - Level 4: Bright (300-600 nits)
 - Level 5: Very bright (600-1000 nits)
5. Adjustment is immediate

AUTO BRIGHTNESS:

How to Enable:

1. Swipe down for quick settings
2. Tap "Auto" icon (A with arrows)

3. Or: Settings → Display → Auto-Brightness

4. Toggle ON

How it Works:

- Ambient light sensor detects environment
- Automatically adjusts brightness
- Bright outdoors (up to 1000 nits)
- Dim indoors (100-300 nits)
- Very dim at night (5-50 nits)
- Seamless transitions

Benefits:

- Optimal visibility always
- Battery saving (not max brightness always)
- Eye comfort
- No manual adjustment needed
- Adapts to changes

BRIGHTNESS TIPS:

For Battery Saving:

- Use auto-brightness
- Lower manual level indoors
- Avoid max brightness unless needed
- Combine with AOD off

For Outdoor Visibility:

- Use auto-brightness
- Or set to max (level 5)

- AMOLED performs well in sunlight
- 1000 nits peak is very bright

For Indoor Use:

- Level 2 or 3 sufficient
- Auto-brightness works well
- Reduce in evening/night
- Eye comfort priority

For Night Use:

- Lowest brightness (level 1)
- Auto-brightness handles this
- Or use theater mode
- Avoid bright screens before sleep

SCREEN TIMEOUT:

How to Set:

1. Settings → Display → Screen Timeout

2. Options:

- 10 seconds
- 15 seconds (default)
- 20 seconds
- 30 seconds
- 1 minute
- 2 minutes
- Always on (with AOD)

Recommendations:

- 15 seconds: Good balance
- 10 seconds: Maximum battery saving
- 30 seconds+: Better usability, less battery
- "Always on": Use with AOD

RAISE TO WAKE:

How to Enable:

1. Settings → Display → Raise to Wake
2. Toggle ON
3. Adjust sensitivity (low, medium, high)

How it Works:

- Accelerometer and gyroscope detect motion
- Screen turns on when you raise wrist
- Turns off when you lower wrist
- Configurable sensitivity
- Works with or without AOD

TIP:

Combine raise to wake with auto-brightness for optimal experience

=====

=====

CHAPTER 5: HEALTH MONITORING

=====

=====

5.1 Heart Rate Monitoring

CONTINUOUS HEART RATE TRACKING:

FEATURES:

- 24/7 automatic heart rate monitoring
- Real-time heart rate display
- Resting heart rate tracking
- Heart rate zones
- Abnormal heart rate alerts
- Historical data and trends
- Heart rate variability (HRV)

HOW IT WORKS:

- Optical sensor on back of watch
- Emits green LED light
- Measures blood volume changes
- Calculates heart rate (BPM - beats per minute)
- Updates every 1-10 minutes (auto)
- Manual measurement on demand
- Accuracy: $\pm 2-5$ BPM (compared to medical devices)

VIEWING HEART RATE:

On Watch:

1. Swipe to heart rate complication on watch face
2. Or open Heart Rate app
3. Current BPM displayed
4. Heart rate zone shown
5. Tap for detailed view
6. Shows: Current, Resting, Zone, 24h graph

In App:

1. Open TechNova Fit app
2. Health → Heart Rate
3. Current BPM shown
4. 24-hour graph
5. Daily trends
6. Weekly/monthly trends
7. Resting heart rate
8. Export data option

HEART RATE ZONES:

Zone 1 - Warm Up (50-60% max HR):

- Very light activity
- Warm-up exercises
- Recovery
- Example: Slow walking

Zone 2 - Fat Burn (60-70% max HR):

- Light activity
- Fat burning
- Endurance building
- Example: Brisk walking, light jogging

Zone 3 - Cardio (70-80% max HR):

- Moderate activity
- Cardiovascular training
- Calorie burning

- Example: Jogging, cycling

Zone 4 - Peak (80-90% max HR):

- Hard activity
- Performance training
- Anaerobic threshold
- Example: Fast running, HIIT

Zone 5 - Maximum (90-100% max HR):

- Maximum effort
- Sprint training
- Short duration only
- Example: Sprinting, intense intervals

Maximum Heart Rate Formula:

- Max HR = $220 - \text{your age}$
- Example: Age 30 → Max HR = 190 BPM

AUTO MONITORING SETTINGS:

Settings: Health → Heart Rate → Auto Monitor

Options:

- Off: Manual measurements only
- Smart: Automatic based on activity (recommended)
- Every 1 minute: Continuous monitoring
- Every 10 minutes: Frequent monitoring
- Every 30 minutes: Moderate monitoring
- Every 60 minutes: Battery saving

Recommendations:

- Smart mode: Best balance
- Every 10 min: Good for fitness tracking
- Every 30 min: Good for general health
- Every 60 min: Maximum battery saving

HIGH/LOW HEART RATE ALERTS:

Set Alerts:

1. Settings → Health → Heart Rate → Alerts
2. Enable "High Heart Rate Alert"
3. Set threshold (e.g., 180 BPM)
4. Enable "Low Heart Rate Alert"
5. Set threshold (e.g., 40 BPM)
6. Save settings

When Alert Triggers:

- Watch vibrates
- Alert appears on screen
- Notification in app
- Logged in history
- Can dismiss or view details

Important:

- Set during rest (not during workout)
- If persistent, consult doctor
- Can disable during workouts
- Different thresholds for different activities

RESTING HEART RATE:

What it is:

- Heart rate when completely at rest
- Best measured in morning after waking
- Indicator of cardiovascular fitness
- Lower RHR = better fitness (generally)

Normal Range:

- Adults: 60-100 BPM
- Athletes: 40-60 BPM
- Well-trained: 50-70 BPM
- Average: 70-80 BPM

Tracking:

- App automatically tracks resting HR
- Best value shown (usually morning)
- Trend over time
- Compare with peers

5.2 SpO2 Measurement

BLOOD OXYGEN SATURATION TRACKING:

WHAT IS SpO2?

- SpO2 = Peripheral Capillary Oxygen Saturation
- Percentage of oxygen-saturated hemoglobin
- Indicator of respiratory and circulatory health
- Normal range: 95-100%

- Below 90%: Low (hypoxemia)
- Below 85%: Very low (seek medical attention)
- Altitude affects SpO2 (lower at high altitude)

HOW TO MEASURE:

On Watch:

1. Open SpO2 app
2. Sit still and relax
3. Keep wrist flat and stable
4. Don't move or talk
5. Sensor takes reading (15-30 seconds)
6. Result displayed as percentage
7. Saved to history
8. Can repeat for accuracy

In App:

1. Open TechNova Fit app
2. Health → SpO2
3. View all measurements
4. See trends over time
5. Time-stamped readings
6. Export data option

BEST PRACTICES FOR ACCURACY:

Before Measurement:

- Rest for 5 minutes
- Sit comfortably

- Keep arm relaxed
- Wrist at heart level

During Measurement:

- Stay completely still
- Don't talk
- Don't move fingers
- Keep watch snug (not tight)
- Wait for full reading

Environment:

- Room temperature (not too cold/hot)
- Good lighting
- Avoid direct sunlight on sensor
- No strong vibrations

After Exercise:

- Wait at least 10 minutes
- Let heart rate return to normal
- Cool down first
- Then measure

AUTO MONITORING:

Settings: Health → SpO2 → Auto Monitor

Options:

- Off: Manual only (default)
- During sleep: Automatic nighttime measurements

- Scheduled: Set specific times (e.g., 9 AM, 3 PM, 9 PM)
- On demand: Manual only

During Sleep:

- Measures every 30 minutes while sleeping
- Tracks overnight oxygen levels
- Can detect sleep apnea patterns
- Uses minimal battery
- Recommended for health monitoring

SPO2 TRENDS:

In App:

- Historical graph
- Daily average
- Weekly trends
- Monthly patterns
- Time of day analysis
- Correlation with other metrics

When to be Concerned:

- Consistently below 92%
- Sudden drops
- Large variations
- Symptoms: Shortness of breath, dizziness, fatigue
- Consult doctor if concerned

ALTITUDE TRACKING:

- SpO2 decreases with altitude

- Normal at high altitude: 90-95%
- Very high altitude: 85-90%
- Watch can track altitude changes
- Useful for hiking, climbing

5.3 Sleep Tracking

AUTOMATIC SLEEP MONITORING:

FEATURES:

- Automatic sleep detection
- Sleep stages (light, deep, REM, awake)
- Sleep duration tracking
- Sleep quality score
- Sleep consistency
- Nap detection
- Smart alarm (wake in light sleep)
- Sleep insights and tips
- Bedtime reminders

HOW IT WORKS:

- Wear watch to bed
- Auto-detects when you fall asleep
- Monitors movement (accelerometer)
- Monitors heart rate (optical sensor)
- Analyzes sleep patterns
- Detects sleep stages
- Wakes up when you do
- Syncs data to app in morning

SLEEP STAGES:

AWAKE:

- Brief awakenings during night
- Normal and healthy
- 2-5% of total sleep time
- Too many = poor sleep quality
- Can be caused by: noise, light, discomfort, stress

LIGHT SLEEP:

- Transition between awake and deep sleep
- 50-60% of total sleep time
- Body relaxes, heart rate slows
- Easy to wake up
- Important for mental and physical recovery

DEEP SLEEP (Slow Wave Sleep):

- Most restorative stage
- 10-20% of total sleep time
- Body repairs itself
- Immune system strengthens
- Hardest to wake up
- Growth hormone released
- Essential for physical recovery

REM (Rapid Eye Movement):

- Dreaming stage
- 20-25% of total sleep time

- Brain activity increases
- Memory consolidation
- Emotional processing
- Important for learning
- Eyes move rapidly (detected by watch)

VIEWING SLEEP DATA:

On Watch:

1. Swipe to sleep widget
2. Last night's summary:
 - Total duration
 - Sleep score
 - Time in bed
 - Sleep/wake times
3. Tap for more details

In App:

1. Open TechNova Fit app
2. Health → Sleep
3. Detailed analysis:
 - Sleep duration
 - Sleep stages graph
 - Sleep score (0-100)
 - Sleep consistency
 - Heart rate during sleep
 - SpO2 during sleep
 - Sleep insights
 - Tips for improvement

4. Historical data:

- Last 7 days
- Last 30 days
- Trends
- Patterns

5. Export option

SLEEP SCORE:

Calculated from:

- Sleep duration (30%)
- Sleep quality (25%)
- Sleep stages (20%)
- Sleep consistency (15%)
- Restlessness (10%)

Score Interpretation:

- 80-100: Excellent sleep
- 60-79: Good sleep
- 40-59: Fair sleep
- 0-39: Poor sleep

SLEEP SETTINGS:

Enable Sleep Tracking:

- Settings → Health → Sleep Tracking
- Toggle ON (default)
- Wear watch to bed

Bedtime Reminder:

- Set target bedtime
- Set target wake time
- Reminder 30 minutes before bedtime
- Helps establish routine

Smart Alarm:

- Set alarm time window (e.g., 6:00-6:30 AM)
- Alarm triggers during light sleep
- Wakes you at optimal time
- Less groggy feeling
- Gentle vibration

Sleep Mode:

- Enable during sleep hours
- Disables raise-to-wake
- Dims display
- Blocks notifications (except alarms)
- Do Not Disturb
- Preserves battery

SLEEP TIPS:

For Better Sleep:

- Consistent sleep schedule (same time daily)
- 7-9 hours per night (adults)
- Dark, quiet, cool room
- Avoid screens 1 hour before bed
- Limit caffeine after 2 PM
- No heavy meals before bed

- Regular exercise (not right before bed)
- Relaxation routine before bed
- Comfortable mattress and pillow

Common Issues:

- Insomnia: Difficulty falling/staying asleep
- Sleep apnea: Breathing interruptions
- Restless leg syndrome: Urge to move legs
- Narcolepsy: Excessive daytime sleepiness
- Consult doctor if persistent

5.4 Stress Monitoring

STRESS LEVEL TRACKING:

WHAT IS STRESS MONITORING?

- Based on heart rate variability (HRV)
- Measures time between heartbeats
- Lower HRV = higher stress
- Higher HRV = lower stress (relaxed)
- Scale: 1-100 (low to high)
- Provides insights into stress levels
- Helps manage stress

HOW IT WORKS:

- Optical heart rate sensor
- Measures time between heartbeats
- Calculates HRV (Heart Rate Variability)
- Algorithm converts to stress score

- Takes 2 minutes for reading
- Can be done on demand

STRESS LEVELS:

RELAXED (1-30):

- Green color
- Low stress
- Good relaxation
- Healthy state
- Well-rested

NORMAL (31-60):

- Yellow color
- Moderate stress
- Everyday stress levels
- Manageable
- Common during day

MEDIUM (61-80):

- Orange color
- Elevated stress
- Work pressure
- Deadlines
- Needs attention

HIGH (81-100):

- Red color
- High stress

- Overwhelmed
- Health concern
- Take action

HOW TO MEASURE:

On Watch:

1. Open Stress app
2. Sit comfortably
3. Keep arm still
4. Measurement takes 2 minutes
5. Stress level displayed
6. Interpretation provided
7. Saved to history

In App:

1. Health → Stress
2. Current stress level
3. Historical graph
4. Daily patterns
5. Weekly trends
6. Correlation with other metrics
7. Insights and tips

STRESS MANAGEMENT:

Breathing Exercise:

1. Open Breathing app on watch
2. Follow guided breathing

3. Inhale (4 seconds) - watch expands
4. Hold (4 seconds) - watch holds
5. Exhale (4 seconds) - watch contracts
6. Repeat for 2-5 minutes
7. Stress reduces
8. Can do multiple times daily

Tips for Stress Reduction:

- Regular exercise
- Adequate sleep
- Healthy diet
- Meditation/mindfulness
- Deep breathing
- Time management
- Work-life balance
- Social connections
- Hobbies and relaxation
- Professional help if needed

STRESS INSIGHTS:

In App:

- Daily stress patterns
- Identify stress triggers
- Best times of day
- Correlation with:
 - Sleep quality
 - Activity level
 - Heart rate

- SpO2
- Weather
- Day of week
- Personalized recommendations
- Progress tracking

5.5 Skin Temperature

SKIN TEMPERATURE MONITORING:

FEATURES:

- Continuous temperature monitoring
- Baseline temperature tracking
- Temperature trends
- Alerts for abnormal readings
- Correlation with other health metrics
- Nighttime tracking (most accurate)

WHAT IT MEASURES:

- Skin temperature (not core body temperature)
- Wrist temperature
- Changes from baseline
- Trends over time
- Typical range: 32-34°C (89-93°F)
- Varies by individual
- Varies throughout day

NORMAL RANGE:

- Average: 32-34°C (skin)

- Varies by:
 - Individual (baseline)
 - Time of day
 - Environment
 - Activity level
 - Menstrual cycle (women)
 - Health status

NOT core body temperature:

- Core body temp: 36.5-37.5°C
- Skin temp is lower
- Don't use for fever detection
- Consult doctor for medical concerns

VIEWING TEMPERATURE:

On Watch:

1. Swipe to temperature widget (if added)
2. Or open Temperature app
3. Current skin temperature
4. Trend arrow (up/down/stable)
5. Tap for details

In App:

1. Health → Temperature
2. Current temperature
3. 24-hour graph
4. Nighttime temperature (most accurate)
5. Daily patterns

6. Historical data
7. Trends over weeks/months
8. Export option

TEMPERATURE TRENDS:

Factors Affecting Temperature:

- Circadian rhythm (body clock)
- Environment (room temperature)
- Activity level
- Stress
- Menstrual cycle
- Illness
- Alcohol consumption
- Sleep quality

Tracking Benefits:

- Identify patterns
- Detect changes
- Correlation with:
 - Sleep quality
 - Stress levels
 - Activity
 - Menstrual cycle
 - Health status

TEMPERATURE ALERTS:

- Set baseline temperature
- Alert if deviation $>1^{\circ}\text{C}$

- Notification in app
- Historical tracking
- Can identify trends

IMPORTANT:

- Not a medical device
- Don't use for fever detection
- Skin temp $\neq$ body temp
- Consult doctor for health concerns
- For wellness tracking only

=====

=====

CHAPTER 6: FITNESS TRACKING

=====

=====

6.1 Steps Counter

AUTOMATIC STEP COUNTING:

FEATURES:

- 24/7 automatic step counting
- Accurate step detection
- Daily step goal
- Progress visualization
- Historical data
- Step reminders
- Goal achievements

HOW IT WORKS:

- 3-axis accelerometer detects motion
- Algorithm identifies walking patterns
- Counts steps automatically
- Filters out non-walking movements
- Works without phone
- Syncs to app when connected

VIEWING STEPS:

On Watch:

- Steps widget on home screen
- Shows current count
- Shows goal progress (circular progress bar)
- Tap for details
- Shows: Today's steps, goal, percentage

In App:

1. Dashboard shows daily steps
2. Graph shows:
 - Hourly breakdown
 - Daily totals (7 days)
 - Weekly totals (4 weeks)
 - Monthly totals (12 months)
3. Achievements section
4. Step history
5. Export option

SETTING STEP GOAL:

Default Goal: 10,000 steps/day

To Change:

1. Open TechNova Fit app
2. Profile → Step Goal
3. Select or enter custom goal:
 - 3,000 steps (beginner)
 - 5,000 steps (light activity)
 - 7,500 steps (moderate)
 - 10,000 steps (recommended)
 - 12,500 steps (active)
 - 15,000 steps (very active)
 - 20,000+ steps (athlete)
4. Save

Goal Recommendations:

- Sedentary: Start with 3,000-5,000
- Light activity: 7,500-10,000
- Moderate: 10,000-12,500
- Active: 12,500-15,000
- Very active: 15,000-20,000
- Athlete: 20,000+

STEP REMINDERS:

Sedentary Reminder:

- Enable: Settings → Health → Sedentary Reminder
- Reminder after 1 hour of inactivity

- Vibrates and shows message
- Encourages movement
- Helps break long sitting periods

Hourly Goal:

- Set hourly step goal
- Track progress throughout day
- Stay active consistently

ACHIEVEMENTS:

Daily Goals:

- Complete daily step goal
- Badge/achievement unlocked
- Logged in app

Weekly Goals:

- Average daily steps for week
- Weekly target
- Consistency tracking

Monthly Goals:

- Total steps for month
- Long-term consistency
- Progress tracking

Personal Records:

- Best single day
- Best week

- Best month
- Longest streak

6.2 Workout Modes

100+ WORKOUT MODES SUPPORTED:

POPULAR WORKOUTS:

RUNNING:

- Outdoor Running (uses GPS via phone)
- Indoor Running (treadmill)
- Track running
- Trail running
- Metrics: Distance, pace, heart rate, calories, time

WALKING:

- Outdoor Walking
- Indoor Walking
- Power walking
- Hiking
- Metrics: Distance, steps, pace, calories, time

CYCLING:

- Outdoor Cycling (GPS)
- Indoor Cycling (stationary)
- Mountain biking
- Road cycling
- Metrics: Distance, speed, heart rate, calories, time

SWIMMING:

- Pool Swimming (5ATM water resistant)
- Open Water Swimming
- Laps tracking
- SWOLF score (Swimming Golf)
- Metrics: Laps, distance, pace, calories, SWOLF

GYM/FITNESS:

- Strength Training
- HIIT (High Intensity Interval Training)
- Circuit Training
- CrossFit
- Bodybuilding
- Metrics: Duration, heart rate, calories, reps (manual)

YOGA & PILATES:

- Yoga
- Pilates
- Meditation
- Stretching
- Metrics: Duration, heart rate, calories, stress level

CARDIO:

- Elliptical
- Rowing Machine
- Stair Climber
- Jump Rope
- Aerobics

- Dance
- Kickboxing
- Martial Arts

SPORTS:

- Cricket
- Football
- Basketball
- Badminton
- Tennis
- Table Tennis
- Volleyball
- Baseball
- Golf
- Rugby
- Hockey

OUTDOOR:

- Hiking
- Climbing
- Skiing
- Snowboarding
- Surfing
- Kayaking
- Rowing

STARTING A WORKOUT:

On Watch:

1. Press side button or open Workout app
2. Scroll through workout list
3. Tap desired workout
4. Set goals (optional):
 - Time goal: e.g., 30 minutes
 - Distance goal: e.g., 5 km
 - Calorie goal: e.g., 300 kcal
5. Tap "Start"
6. 3-second countdown
7. Workout begins
8. Display shows real-time metrics

DURING WORKOUT:

Display Shows:

- Duration (time elapsed)
- Heart rate (real-time)
- Calories burned
- Distance (if GPS)
- Pace/Speed
- Workout-specific metrics
- Current heart rate zone

Swipe to See More:

- Swipe left: Different data screen
- Swipe right: Previous screen
- Swipe up: More metrics
- Swipe down: Quick settings

Buttons:

- Pause: Tap pause button or press side button
- Lap: Tap lap button (for intervals)
- Lock screen: Prevent accidental touches
- Unlock: Swipe or tap

ENDING WORKOUT:

1. Press side button or tap end
2. Options: Pause or End
3. If Pause: Can resume later
4. If End: Workout summary displayed
5. Summary shows:
 - Total duration
 - Total calories
 - Average heart rate
 - Max heart rate
 - Distance (if GPS)
 - Average pace
 - Training effect
 - Recovery time (suggested)
6. Auto-saved to history
7. Syncs to app when connected

6.3 GPS Tracking

CONNECTED GPS:

WHAT IS CONNECTED GPS?

- Watch uses phone's GPS

- More accurate than watch-only GPS
- Real-time tracking
- Route mapping
- Distance calculation
- Pace/speed tracking

SETUP:

1. Keep phone with you during workout
2. Ensure TechNova Fit app is open (or running in background)
3. GPS connects automatically
4. Wait for GPS lock (10-30 seconds)
5. GPS icon appears on watch
6. Start workout
7. GPS tracking begins

GPS ACCURACY:

Tips for Better GPS:

- Clear sky view
- Away from tall buildings
- Not indoors
- Phone in armband or pocket (not bag)
- Wait for GPS lock before starting
- Update maps regularly
- Keep phone charged
- Close other apps using GPS

GPS METRICS:

Outdoor Workouts:

- Distance (accurate to ~5 meters)
- Pace (time per km/mile)
- Speed (km/h or mph)
- Route map (in app)
- Elevation gain
- Splits (time per km/mile)
- Best pace
- Average pace

ROUTE TRACKING:

In App:

- Map view of route
- Distance markers
- Pace analysis
- Elevation profile
- Splits analysis
- Can share route
- Compare with previous runs

GPS BATTERY IMPACT:

- GPS increases battery usage
- Typical workout (1 hour): 10-15% battery
- Long workout (2+ hours): 20-30% battery
- Keep phone charged for long workouts
- Consider power bank for ultra-long workouts

GPS WORKOUTS:

- Outdoor Running
- Outdoor Cycling
- Outdoor Walking
- Hiking
- Trail Running
- Open Water Swimming
- Skiing
- And many more outdoor activities

6.4 Calories Burned

CALORIE TRACKING:

WHAT ARE CALORIES?

- Unit of energy
- Energy from food
- Energy burned through activity
- Balance determines weight change
- Important for fitness and health

CALCULATION:

Based on:

- BMR (Basal Metabolic Rate)
- Activity level
- Heart rate
- Workout intensity
- Personal data (age, weight, height, gender)
- Workout duration
- Workout type

BMR (Basal Metabolic Rate):

- Calories burned at complete rest
- Maintains body functions
- Breathing, circulation, cell production
- ~60-75% of total daily calories
- Calculated using Mifflin-St Jeor equation

BMR Formula (Mifflin-St Jeor):

Men: $BMR = (10 \times \text{weight in kg}) + (6.25 \times \text{height in cm}) - (5 \times \text{age in years}) + 5$

Women: $BMR = (10 \times \text{weight in kg}) + (6.25 \times \text{height in cm}) - (5 \times \text{age in years}) - 161$

Example: 30-year-old male, 70 kg, 175 cm

$BMR = (10 \times 70) + (6.25 \times 175) - (5 \times 30) + 5$

$BMR = 700 + 1093.75 - 150 + 5$

$BMR = 1,648.75 \text{ calories/day}$

TDEE (Total Daily Energy Expenditure):

- $BMR \times \text{Activity Factor}$
- Sedentary (little/no exercise): $BMR \times 1.2$
- Lightly active (1-3 days/week): $BMR \times 1.375$
- Moderately active (3-5 days/week): $BMR \times 1.55$
- Very active (6-7 days/week): $BMR \times 1.725$
- Extra active (very hard exercise): $BMR \times 1.9$

VIEWING CALORIES:

On Watch:

- Calories widget (if added)

- Shows calories burned today
- Shows calorie goal progress
- Tap for details

In App:

1. Dashboard shows:

- Active calories (from exercise)
- Total calories (including BMR)
- Calorie goal
- Progress

2. Graphs:

- Daily calories (7 days)
- Weekly average
- Monthly totals

3. Breakdown:

- By workout
- By activity
- By time of day

CALORIE GOALS:

Setting Goal:

1. App → Profile → Calorie Goal

2. Options:

- Maintain weight: TDEE calories
- Lose weight: TDEE - 500 calories/day
- Gain weight: TDEE + 500 calories/day

3. Or custom goal

4. Save

Recommendations:

- Lose 0.5 kg/week: -500 cal/day
- Lose 1 kg/week: -1000 cal/day
- Gain 0.5 kg/week: +500 cal/day
- Don't go below BMR (unsafe)
- Consult nutritionist for personalized plan

6.5 Fitness Goals

GOAL SETTING AND TRACKING:

TYPES OF GOALS:

Daily Goals:

- Steps: e.g., 10,000 steps
- Calories: e.g., 2,500 calories
- Active minutes: e.g., 60 minutes
- Stand hours: e.g., 12 hours
- Distance: e.g., 8 km
- Workouts: e.g., 1 workout

Weekly Goals:

- Workout days: e.g., 5 days/week
- Total distance: e.g., 40 km/week
- Total workout time: e.g., 300 minutes/week
- Average steps: e.g., 70,000 steps/week

Monthly Goals:

- Total workouts: e.g., 20 workouts/month
- Total distance: e.g., 160 km/month
- Weight goal: e.g., lose 2 kg/month
- Consistency: e.g., workout 4+ days/week

SETTING GOALS:

In App:

1. Profile → Goals
2. Select goal type
3. Set target value
4. Set deadline (if applicable)
5. Save

Goal Types Available:

- Weight goal
- Step goal
- Calorie goal
- Workout goal
- Distance goal
- Time goal
- Custom goal

TRACKING PROGRESS:

In App:

- Progress bar for each goal
- Percentage complete
- Time remaining

- On track / Behind schedule
- Historical comparison
- Achievement badges

On Watch:

- Goal complications on watch face
- Quick view of progress
- Motivational messages

ACHIEVEMENTS AND BADGES:

Achievements:

- First 5,000 steps
- First 10,000 steps
- First marathon (42 km)
- First 100 workouts
- 7-day streak
- 30-day streak
- Personal records
- And many more...

Badges:

- Visual representations of achievements
- Collect badges
- Share with friends
- Motivational

MOTIVATION:

Notifications:

- Goal completion celebration
- Behind schedule reminder
- Encouragement messages
- Streak tracking

Social Features:

- Compete with friends
- Join challenges
- Share achievements
- Leaderboards

Challenges:

- Daily step challenge
- Weekly distance challenge
- Monthly workout challenge
- Community challenges
- Corporate challenges

PERSONAL RECORDS:

Track Your Best:

- Best single day (steps)
- Best week (average)
- Best month (total)
- Longest workout
- Fastest pace
- Longest distance
- Most calories burned

- PR notifications

=====

=====

CHAPTER 7: NOTIFICATIONS AND CALLS

=====

=====

7.1 Notification Setup

CONFIGURING NOTIFICATIONS:

STEP 1: Grant Permission

On Android:

1. Settings → Apps → TechNova Fit
2. Notifications → Allow all notifications
3. Or: Settings → Notifications → TechNova Fit → Allow

On iOS:

1. Settings → Notifications → TechNova Fit
2. Allow Notifications → ON
3. Show in Notification Center → ON
4. Show on Lock Screen → ON
5. Show as Banners → ON

STEP 2: Select Apps to Notify

In TechNova Fit App:

1. Devices → Your Watch → Notifications

2. Toggle ON for apps you want:

- Phone calls
- Messages (SMS)
- WhatsApp
- Facebook
- Instagram
- Twitter
- Email (Gmail, Outlook, etc.)
- Telegram
- Snapchat
- And 50+ more apps

3. Toggle OFF for apps you don't want

4. Save settings

STEP 3: Customize per App

For each app, configure:

- Show notifications: ON/OFF
- Vibration: ON/OFF
- Sound: ON/OFF
- Show on lock screen: ON/OFF
- Show content: Show/hide message content
- Priority: High/Medium/Low

7.2 Call Notifications

INCOMING CALL ALERTS:

When Call Comes In:

- Watch vibrates
- Call notification appears
- Shows caller name/number
- Shows caller photo (if synced)
- Options: Answer or Decline

To Answer:

- Tap green phone icon
- Or swipe green icon
- Call audio routes to watch
- Speak and listen through watch
- Or use phone (your choice)

To Decline:

- Tap red phone icon
- Or swipe red icon
- Call goes to voicemail
- Or continues ringing on phone

To Silence:

- Press crown button
- Watch stops vibrating
- Notification still visible
- Can answer later

CALL SETTINGS:

In App:

1. Devices → Your Watch → Call Settings

2. Options:

- Show call notifications: ON/OFF
- Vibration: ON/OFF
- Sound: ON/OFF
- Caller photo: ON/OFF
- Auto-answer: ON/OFF (if supported)
- Route audio to watch: Always/Ask/Phone only

CONTACTS SYNC:

Sync Contacts to Watch:

1. App → Devices → Your Watch → Contacts
2. Enable "Sync Contacts"
3. Select contacts to sync:
 - All contacts
 - Favorites only
 - Specific contacts
4. Sync begins
5. Wait for completion
6. Contacts available on watch

On Watch:

- Open Phone app
- View synced contacts
- Search contacts
- Tap to call
- Quick dial

MULTIPLE CALL MANAGEMENT:

- Supports multiple Bluetooth devices
- Can switch audio between phone and watch
- Call audio on watch or phone (your choice)
- Can use either device during call

7.3 Message Notifications

SMS AND MESSENGER ALERTS:

When Message Arrives:

- Watch vibrates
- Message notification appears
- Shows sender name/number
- Shows message preview
- Can read full message
- Can reply (if supported)

VIEWING MESSAGES:

On Watch:

1. Notification appears
2. Tap to view full message
3. Scroll to read entire message
4. Can reply (if supported)
5. Can dismiss notification

QUICK REPLIES:

For supported apps (WhatsApp, SMS, etc.):

Pre-defined Replies:

- "OK"
- "Yes"
- "No"
- "Thanks"
- "Call me"
- "On my way"
- "In a meeting"
- "Can't talk now"
- Custom replies (up to 10)

To Reply:

1. Tap message notification
2. Scroll to bottom
3. Tap "Reply"
4. Select pre-defined reply
5. Or type (if supported)
6. Tap send
7. Message sent from phone

VOICE REPLIES:

- Tap microphone icon
- Speak your reply
- Speech-to-text conversion
- Review and send
- Supported languages

EMOJI REPLIES:

- Select emoji from list
- Send emoji reaction
- Quick and easy
- Fun and expressive

7.4 App Notifications

SOCIAL MEDIA AND APP ALERTS:

Supported Apps:

- WhatsApp
- Facebook
- Facebook Messenger
- Instagram
- Twitter
- LinkedIn
- Snapchat
- Telegram
- Signal
- Viber
- WeChat
- Line
- Email apps (Gmail, Outlook, Yahoo, etc.)
- News apps
- Shopping apps
- And 50+ more

CUSTOMIZATION:

Per-App Settings:

- Show notification: ON/OFF
- Show content: Show/hide
- Vibration: ON/OFF
- Sound: ON/OFF
- Priority: High/Medium/Low
- Show on lock screen: ON/OFF

NOTIFICATION GROUPING:

By App:

- All WhatsApp messages grouped
- All emails grouped
- Easier to manage
- Less clutter

By Time:

- Chronological order
- Newest first
- Easy to find recent

Notification History:

- Last 24 hours
- Scroll through history
- Can re-read
- Auto-cleared after 24 hours

7.5 Do Not Disturb

DND MODE:

WHAT IS DO NOT DISTURB?

- Blocks all notifications
- Except alarms and priority
- Useful for meetings, sleep, focus time
- Can be scheduled

ENABLING DND:

On Watch:

1. Swipe down for quick settings
2. Tap "Do Not Disturb" icon (moon)
3. DND enabled
4. Moon icon visible in status bar

In App:

1. Devices → Your Watch → Do Not Disturb
2. Toggle ON
3. Configure settings

SCHEDULED DND:

Set Schedule:

1. App → Devices → Your Watch → Do Not Disturb → Schedule
2. Enable "Scheduled DND"
3. Set start time (e.g., 10:00 PM)
4. Set end time (e.g., 7:00 AM)
5. Save

6. DND automatically enables/disables

Example Schedules:

- Sleep: 10 PM - 7 AM
- Work: 9 AM - 6 PM
- Meetings: Manual as needed
- Focus time: 2 PM - 4 PM

PRIORITY EXCEPTIONS:

Allow These Even in DND:

- Alarms: Always allowed
- Critical alerts: Enabled in settings
- Favorites: Calls from favorite contacts
- Repeated calls: Same person calls twice within 5 minutes
- Emergency: Emergency alerts

Settings:

1. App → Devices → Your Watch → Do Not Disturb → Exceptions
2. Configure priority contacts
3. Configure repeated calls
4. Configure critical alerts

DND INDICATORS:

On Watch:

- Moon icon in status bar
- Notifications silenced
- No vibration

- Notifications stored (not delivered)

In App:

- DND status shown
- Can disable remotely
- Schedule visible

DND TIPS:

- Use scheduled DND for sleep
- Use manual DND for meetings
- Allow priority contacts
- Don't miss important calls
- Combine with sleep mode

=====

=====

CHAPTER 8: BLUETOOTH CALLING

=====

=====

8.1 Making Calls

DIALING FROM WATCH:

METHOD 1: Keypad

1. Open Phone app on watch
2. Tap keypad icon
3. Enter number using on-screen keypad
4. Tap call button
5. Call initiated

6. Speaker and mic on watch activated
7. Call duration displayed
8. End call when done

METHOD 2: Contacts

1. Open Phone app
2. Tap contacts icon
3. Scroll or search for contact
4. Tap contact
5. Tap call button
6. Call initiated
7. Talk through watch

METHOD 3: Recents

1. Open Phone app
2. Tap recents icon
3. See call history
4. Tap number/name to call back
5. Call initiated

METHOD 4: Voice Dial

1. Activate voice assistant
2. Say "Call [contact name]"
3. Or "Dial [number]"
4. Call initiated
5. Hands-free calling

DURING CALL:

On Watch Display:

- Contact name/number
- Call duration (timer)
- Call status (connecting, talking, ended)
- Speaker icon
- Mute icon
- End call button
- Keypad (for DTMF tones)

Controls:

- Mute: Tap to mute/unmute yourself
- Speaker: Tap to switch audio (watch/phone)
- Keypad: Tap to enter numbers (for IVR)
- End: Tap to end call
- Volume: Rotate crown

AUDIO QUALITY:

Speaker:

- Built-in mono speaker
- Clear audio output
- 8Ω, 0.5W
- HD voice support
- Noise cancellation

Microphone:

- MEMS microphone
- Omnidirectional
- ENC (Environmental Noise Cancellation)

- Clear voice pickup
- Noise reduction

Quality:

- HD voice calls
- Clear audio in quiet environments
- Some noise reduction in noisy places
- Best for: Indoor, car, quiet places
- Not ideal for: Very noisy places, wind

8.2 Receiving Calls

INCOMING CALL ALERTS:

When Call Arrives:

- Watch vibrates (strong vibration)
- Call notification appears on screen
- Shows caller name (if in contacts)
- Shows caller number (if not in contacts)
- Shows caller photo (if synced)
- Ringtone plays (if enabled)
- Options: Answer or Decline

TO ANSWER CALL:

- Tap green phone icon
- Or swipe green icon to right
- Call audio routes to watch
- Speaker and mic activated
- Start talking

- Can use phone instead (audio on phone)

TO DECLINE CALL:

- Tap red phone icon
- Or swipe red icon to left
- Call goes to voicemail
- Or continues ringing on phone (if not answered on watch)

TO SILENCE:

- Press crown button
- Watch stops vibrating and ringing
- Notification still visible
- Can answer later
- Call continues on phone

TO IGNORE:

- Don't touch watch
- Call continues on phone
- Watch notification disappears after timeout
- Can check missed call later

CALL SETTINGS:

Ringtone:

- Choose ringtone for calls
- Multiple options
- Custom ringtones (if supported)
- Volume control

Vibration:

- Vibration pattern for calls
- Strong vibration
- Repeated until answered
- Can disable if needed

Volume:

- Call volume control
- Separate from notification volume
- Adjust during call
- Loud enough for most environments

8.3 Call History

VIEWING CALL LOG:

On Watch:

1. Open Phone app
2. Tap "Recents" or call history icon
3. See list of recent calls
4. Shows:
 - Contact name/number
 - Call type (incoming, outgoing, missed)
 - Date and time
 - Duration
 - Icons (missed, incoming, outgoing)
5. Scroll through list
6. Tap to call back
7. Tap for options (add to contacts, etc.)

In App:

1. TechNova Fit app
2. Devices → Your Watch → Call History
3. See complete call log
4. More details
5. Can export if needed

CALL LOG LIMITS:

- On watch: Last 10-20 calls
- In app: Last 100+ calls
- Synced from phone
- Can be cleared manually

CALL STATISTICS:

In App:

- Total calls made
- Total calls received
- Total missed calls
- Call duration (total, average)
- Most called contacts
- Call patterns (time of day, day of week)

8.4 Contacts

SYNCING CONTACTS:

How to Sync:

1. Open TechNova Fit app
2. Devices → Your Watch → Contacts
3. Enable "Sync Contacts"
4. Choose contacts to sync:
 - All contacts
 - Favorites only
 - Specific contacts/groups
5. Tap "Sync Now"
6. Wait for sync to complete
7. Contacts transferred to watch

CONTACTS ON WATCH:

Viewing Contacts:

1. Open Phone app
2. Tap contacts icon
3. Scroll through list
4. Alphabetical order
5. Search function (if supported)

Searching Contacts:

- Tap search icon
- Type name
- Results appear
- Tap to view
- Tap to call

Calling from Contacts:

1. Open Phone app

2. Tap contacts
3. Find contact
4. Tap contact
5. Tap call button
6. Call initiated

CONTACT LIMITS:

- Depends on watch storage
- Typically: 100-500 contacts
- Photos also synced (if available)
- Multiple numbers per contact supported

FAVORITE CONTACTS:

Mark as Favorite:

- In phone contacts app
- Or in watch contacts
- Quick access
- Separate list
- Up to 10-20 favorites

Quick Dial Favorites:

- Open Phone app
- Tap favorites
- Tap contact to call
- Fastest way to call

CONTACT PHOTOS:

- Synced from phone

- Shown on incoming calls
- Shown in contacts list
- Small thumbnails
- Adds visual context

8.5 Call Settings

CONFIGURING CALLS:

In App:

1. Devices → Your Watch → Call Settings

Available Settings:

Call Notifications:

- Show call notifications: ON/OFF
- Vibration: ON/OFF
- Sound: ON/OFF
- Caller photo: ON/OFF
- Show caller name: ON/OFF

Audio Routing:

- Default audio route: Watch/Phone/Ask
- Auto-answer: ON/OFF (if supported)
- Auto-answer delay: 3s, 5s, 10s
- Route audio to: Watch speaker, Bluetooth headset, Phone

Call Behavior:

- Raise to answer: ON/OFF

- Swipe to answer: ON/OFF
- Press crown to answer: ON/OFF
- Double-tap to answer: ON/OFF

Privacy:

- Hide caller name: ON/OFF
- Hide call content: ON/OFF
- Missed call notifications: ON/OFF

Advanced:

- Call duration reminder: ON/OFF
- Call end reminder: ON/OFF
- Call quality optimization: ON/OFF

TROUBLESHOOTING CALLS:

Issue: Can't hear caller

Solutions:

- Increase volume during call
- Check speaker not blocked
- Ensure watch connected to phone
- Restart watch
- Re-pair devices

Issue: Caller can't hear you

Solutions:

- Check microphone not blocked
- Speak clearly
- Reduce background noise

- Ensure watch connected to phone
- Restart watch

Issue: Calls not connecting

Solutions:

- Ensure Bluetooth connected
- Keep phone nearby
- Restart Bluetooth on phone
- Restart watch
- Re-pair devices
- Check phone has network

Issue: Poor call quality

Solutions:

- Move to quieter place
- Reduce background noise
- Keep phone close
- Update firmware
- Check for interference

=====

=====

CHAPTER 9: MUSIC CONTROL

=====

=====

9.1 Music Playback

CONTROLLING MUSIC FROM WATCH:

SUPPORTED MUSIC APPS:

- Spotify
- YouTube Music
- Apple Music
- Google Play Music
- Amazon Music
- Gaana
- JioSaavn
- Wynk Music
- And any app that supports media control

HOW IT WORKS:

- Watch acts as remote control
- Controls music playing on phone
- Bluetooth connection
- No music storage on watch (in this model)
- Can control any music app on phone

CONTROLS ON WATCH:

Music widget/app shows:

- Album art (if available)
- Song title
- Artist name
- Album name
- Progress bar
- Current time / Total duration

Playback Controls:

- Play: Tap play button ()
- Pause: Tap pause button ()
- Next: Tap next button ()
- Previous: Tap previous button ()
- Repeat: Tap repeat button ()
- Shuffle: Tap shuffle button ()

Navigation:

- Swipe up/down: Browse playlist/queue
- Swipe left/right: Previous/next screen
- Rotate crown: Adjust volume or scrub through song

9.2 Volume Control

ADJUSTING VOLUME:

From Watch:

- Rotate crown: Volume up/down
- Or: Tap volume buttons (if shown)
- Volume level displayed
- 15 volume levels
- Instant adjustment

From Phone:

- Can also adjust on phone
- Both sync
- Whichever you adjust last applies

Volume Levels:

- Level 1: Very quiet
- Level 5: Quiet
- Level 10: Medium
- Level 15: Maximum

MUTE:

- Tap mute button
- Or: Turn volume to 0
- Music paused
- Can unmute to resume

9.3 Supported Apps

MUSIC APPS:

Streaming Apps:

- Spotify (most popular)
- YouTube Music
- Apple Music (iOS)
- Amazon Music
- Gaana (India)
- JioSaavn (India)
- Wynk Music (India)
- Hungama Music (India)

Local Music Players:

- Google Play Music
- Poweramp
- VLC

- MX Player
- Any Android music player

PODCAST APPS:

- Spotify (podcasts)
- Google Podcasts
- Apple Podcasts (iOS)
- Pocket Casts
- And more

AUDIOBOOK APPS:

- Audible
- Google Play Books
- Kindle
- And more

COMPATIBILITY:

All major apps supported:

- Apps using standard media control API
- Any app that shows in phone's notification shade
- Most music apps work perfectly

TROUBLESHOOTING:

Issue: Music not controlling

Solutions:

- Ensure music playing on phone
- Keep phone connected to watch

- Grant notification permission to music app
- Check app supported
- Restart music app
- Restart watch

=====

=====

CHAPTER 10: SMART FEATURES

=====

=====

10.1 Voice Assistant

ACTIVATING VOICE ASSISTANT:

On Watch:

1. Press and hold side button (or configured button)
2. Or: Swipe to voice assistant widget
3. Or: Say wake word (if supported)
4. Microphone activates
5. Speak your command
6. Assistant processes
7. Response shown/heard

SUPPORTED ASSISTANTS:

- Google Assistant (Android)
- Siri (iOS)
- TechNova Voice Assistant (basic)

VOICE COMMANDS:

General:

- "What time is it?"
- "Set an alarm for 7 AM"
- "What's the weather?"
- "Set a timer for 10 minutes"
- "Start a workout"

Communication:

- "Call Mom"
- "Send message to John"
- "Read my messages"
- "What messages do I have?"

Music:

- "Play music"
- "Next song"
- "Pause music"
- "Volume up"

Health:

- "What's my heart rate?"
- "How many steps today?"
- "How did I sleep?"

Phone:

- "Find my phone"
- "Open camera"

10.2 Find My Phone

LOCATING YOUR PHONE:

On Watch:

1. Open Find My Phone app/feature
2. Tap "Find Phone"
3. Phone rings loudly
4. Even if on silent/vibrate
5. Keeps ringing until found/stopped
6. Can use to locate phone nearby

On Phone:

1. Open TechNova Fit app
2. Devices → Your Watch → Find My Watch
3. Tap "Find Watch"
4. Watch vibrates and beeps
5. Helps locate watch

FIND MY PHONE FEATURES:

- Phone rings at maximum volume
- Overrides silent/vibrate mode
- Continues until you find it
- Or stop from watch
- Or stop from phone
- Can also use Google Find My Device (Android)

10.3 Camera Control

REMOTE CAMERA SHUTTER:

On Watch:

1. Open Camera Control app
2. Phone camera opens automatically
3. See preview on phone
4. Tap button on watch to take photo
5. Or: Tap to start/stop video
6. Preview shows on watch (if supported)

Features:

- Remote shutter
- Switch front/rear camera
- Start/stop video
- Timer (3s, 5s, 10s)
- Burst mode (if supported)
- Flash control (if supported)

Uses:

- Group photos (you in the photo)
- Selfies (hold phone, use watch)
- Long exposure (no shake)
- Time-lapse (use watch to start/stop)
- Hands-free photography

10.4 Weather

WEATHER UPDATES:

On Watch:

- Weather widget on home screen
- Shows current temperature
- Shows weather icon (sunny, cloudy, rain, etc.)
- Shows location
- Tap for details

Details Show:

- Current temperature
- High/low for day
- Weather condition
- Humidity
- Wind speed and direction
- UV index
- Air quality (if available)
- Sunrise/sunset times
- 3-5 day forecast

In App:

- More detailed weather
- Hourly forecast
- 7-10 day forecast
- Weather maps
- Alerts and warnings
- Multiple locations

LOCATION:

- Uses phone's GPS
- Auto-updates with location

- Can add multiple cities
- Can set home/work locations

10.5 Alarms and Timer

ALARMS:

Setting Alarms on Watch:

1. Open Alarms app
2. Tap "+" to add new alarm
3. Set time (hour and minute)
4. Set repeat (days of week)
5. Set label (optional)
6. Set vibration pattern
7. Save

Alarm Features:

- Multiple alarms (up to 10)
- Repeat: Daily, weekdays, weekends, custom
- Label: Work, Gym, Medication, etc.
- Vibration: Different patterns
- Snooze: 5 min, 10 min, 15 min
- Delete: Can delete alarms

When Alarm Triggers:

- Watch vibrates (strong vibration)
- Alarm sound plays (if enabled)
- Alarm notification appears
- Shows alarm label

- Options:
 - Snooze: Sleep for configured time
 - Stop: Turn off alarm
 - Dismiss: Turn off for today only

TIMER:

Setting Timer:

1. Open Timer app
2. Set duration: Hours, minutes, seconds
3. Or use presets: 1 min, 5 min, 10 min, 15 min, 30 min, 1 hour
4. Tap "Start"
5. Timer counts down
6. When done: Vibrates and beeps
7. Can cancel or let finish

Timer Uses:

- Cooking
- Workouts
- Meetings
- Meditation
- Study sessions
- Any timed activity

STOPWATCH:

Using Stopwatch:

1. Open Stopwatch app
2. Tap "Start"

3. Stopwatch runs
4. Shows: Minutes:Seconds.Hundredths
5. Tap "Lap" for lap times
6. Lap times stored
7. Tap "Stop" to stop
8. Tap "Reset" to clear

Stopwatch Features:

- Lap timing
- Multiple laps stored
- Best lap time
- Average lap time
- Export lap times (if needed)

=====

=====

CHAPTER 11: SETTINGS AND CUSTOMIZATION

=====

=====

11.1 System Settings

ACCESSING SETTINGS:

On Watch:

- Swipe down → Settings icon
- Or: Settings app in app drawer

In App:

- Devices → Your Watch → Settings

AVAILABLE SETTINGS:

ABOUT:

- Model: TechNova Pro X1
- Firmware version
- Serial number
- MAC address
- Hardware version
- Software version

SOFTWARE UPDATE:

- Check for updates
- Auto-update: ON/OFF
- Update over WiFi only: ON/OFF
- Update history

FACTORY RESET:

- Reset watch to factory settings
- Erases all data
- Unpairs from phone
- Use only when needed
- Confirm before reset

REBOOT:

- Restart watch
- Soft reset
- Clears RAM
- Fixes minor issues

- Can do from settings

11.2 Display Settings

SETTINGS MENU:

BRIGHTNESS:

- Manual: 5 levels
- Auto: ON/OFF
- Adjust brightness

SCREEN TIMEOUT:

- 10 seconds
- 15 seconds (default)
- 20 seconds
- 30 seconds
- 1 minute
- 2 minutes

ALWAYS-ON DISPLAY:

- Enable: ON/OFF
- Schedule: Always / Scheduled / Smart
- AOD face: Choose watch face
- Dimmed: ON/OFF

RAISE TO WAKE:

- Enable: ON/OFF
- Sensitivity: Low/Medium/High
- Duration: How long screen stays on

TAP TO WAKE:

- Enable: ON/OFF
- Tap once to wake
- Convenient feature

WATCH FACE:

- Change watch face
- Browse installed faces
- Download new faces
- Customize complications

GESTURES:

- Configure gestures
- Enable/disable
- Adjust sensitivity

11.3 Sound Settings

SOUND MENU:

VOLUME:

- Media volume
- Call volume
- Notification volume
- Separate controls

VIBRATION:

- Vibration strength: Off/Weak/Medium/Strong

- Vibration for notifications: ON/OFF
- Vibration for calls: ON/OFF
- Vibration for alarms: ON/OFF
- Vibration patterns: Choose pattern

SOUND:

- Notification sounds: Choose sound
- Call ringtone: Choose ringtone
- System sounds: ON/OFF
- Touch sounds: ON/OFF
- Haptic feedback: ON/OFF

DO NOT DISTURB:

- Enable: ON/OFF
- Schedule: Set times
- Exceptions: Priority contacts, alarms, etc.

11.4 Connectivity Settings

CONNECTIVITY MENU:

BLUETOOTH:

- Status: Connected/Disconnected
- Paired devices: Show list
- Forget device: Unpair
- Pair new device

NOTIFICATIONS:

- App notifications: Configure per app

- Show on lock screen: ON/OFF
- Quick replies: Configure replies

WIFI:

- Not available (in this model)

GPS:

- Connected GPS (uses phone)
- GPS status: Active/Inactive
- GPS accuracy: Shown during workouts

=====

=====

CHAPTER 12: BATTERY MANAGEMENT

=====

=====

12.1 Battery Life

BATTERY SPECIFICATIONS:

Capacity: 380 mAh

Type: Lithium Polymer (Li-Po)

Charging Time: ~2 hours (0-100%)

Voltage: 3.7V

BATTERY LIFE:

Typical Use (Up to 7 days):

- Display on: 100 times/day

- Notifications: 50/day
- Heart rate: Automatic (every 10 min)
- Sleep tracking: Enabled
- Workout: 30 minutes/day
- Calls: 10 minutes/day
- Always-on display: OFF

Heavy Use (3-4 days):

- Display on: 300 times/day
- Many notifications
- Heart rate: Continuous
- GPS workouts: 1 hour/day
- Calls: 30 minutes/day
- Music control: Frequent
- Always-on display: ON

Power Saving Mode (Up to 14 days):

- Display always off
- Limited notifications
- Heart rate: Manual only
- No GPS workouts
- Basic time display only
- Minimal features

Standby (Up to 30 days):

- Watch not worn
- Minimal background activity
- Occasional sync
- No active use

BATTERY INDICATOR:

On Watch:

- Swipe down: Quick settings
- Battery icon shows percentage
- Or: Add battery widget to watch face
- Shows: Current percentage, time remaining (estimated)

In App:

- Devices → Your Watch → Battery
- Shows: Current percentage
- Battery health
- Usage statistics
- Tips for optimization

12.2 Power Saving Mode

ENABLING POWER SAVING:

On Watch:

1. Swipe down for quick settings
2. Tap "Power Saving" icon
3. Or: Settings → Battery → Power Saving Mode
4. Toggle ON
5. Features limited

In App:

1. Devices → Your Watch → Battery

2. Power Saving Mode
3. Toggle ON
4. Configure options

POWER SAVING FEATURES:

What Gets Disabled:

- Always-on display: OFF
- Raise to wake: OFF
- Continuous heart rate: OFF
- SpO2 monitoring: OFF
- Stress monitoring: OFF
- Sleep tracking: OFF (or limited)
- Notification vibration: Limited
- Background apps: Restricted
- GPS: OFF

What Stays Enabled:

- Time display
- Basic notifications (visual only)
- Alarms
- Manual heart rate
- Step counting
- Call notifications
- Essential functions

BATTERY SAVING TIPS:

Reduce Display Usage:

- Lower brightness
- Shorter screen timeout
- Disable always-on display
- Disable raise to wake
- Use simple watch face
- Dark watch faces (AMOLED advantage)

Limit Sensors:

- Heart rate: Every 10-30 minutes (not continuous)
- Disable SpO2 auto-monitoring
- Disable stress monitoring (manual only)
- Keep essential sensors only

Notifications:

- Reduce notification frequency
- Disable vibration for non-essential apps
- Use Do Not Disturb during idle times
- Limit app notifications

Connectivity:

- Keep phone nearby (reduces power)
- Don't use as remote frequently
- Disable unused features

General:

- Restart watch weekly
- Update firmware
- Close unused apps
- Use power saving mode when needed

12.3 Charging Best Practices

CHARGING TIPS:

Do's:

- Use only provided charger
- Charge on flat, stable surface
- Ensure good ventilation
- Charge at room temperature (15-25°C ideal)
- Charge when below 20%
- Disconnect when fully charged
- Regular charging (don't let drain completely)
- Charge overnight occasionally (for calibration)

Don'ts:

- Don't use fast chargers (9V, 12V, etc.)
- Don't charge when watch is wet
- Don't charge in extreme temperatures
- Don't leave on charger for days
- Don't use damaged charger
- Don't charge in direct sunlight
- Don't charge in very cold conditions
- Don't puncture or damage battery

CHARGING CYCLES:

Lithium Battery Facts:

- No "memory effect" (don't need to fully drain)

- Partial charges are better
- 20-80% is ideal range
- Full cycles (0-100%) stress battery
- Modern batteries are smart
- 500+ charge cycles (80% capacity retention)

Optimal Charging:

- Charge when 20-30%
- Disconnect at 80-90% (optional)
- Full charge (100%) occasionally for calibration
- Don't stress about exact percentages
- Regular charging is fine
- Battery management system handles optimization

12.4 Battery Tips

MAXIMIZING BATTERY LIFE:

Daily Tips:

- Charge nightly (like phone)
- Don't worry about overcharging (modern batteries)
- Use auto-brightness
- Enable power saving when needed
- Keep firmware updated
- Restart watch weekly

Weekly Tips:

- Do a full charge cycle (0-100%)
- Check battery health in app

- Review battery usage stats
- Adjust settings if needed

Monthly Tips:

- Calibrate battery (full drain, then full charge)
- Check for battery-draining apps
- Update firmware
- Review and optimize settings

BATTERY HEALTH:

In App:

- Battery health monitor
- Shows: Maximum capacity %
- Cycle count
- Estimated days remaining
- Health tips

Battery Degradation:

- Normal: 5-10% capacity loss per year
- Affected by: Heat, overcharging, deep discharges
- Can slow degradation with good practices
- Replace battery after 2-3 years (if needed)

WHEN TO REPLACE BATTERY:

- Battery life significantly reduced (<50% of original)
- Watch won't hold charge
- Battery swelling (stop using immediately)
- Random shutdowns

- Contact service center for battery replacement

=====

=====

CHAPTER 13: MAINTENANCE AND CARE

=====

=====

13.1 Cleaning Instructions

REGULAR CLEANING:

Daily:

- Wipe with soft, dry, lint-free cloth
- Remove sweat, dust, dirt
- Clean sensors (back of watch)
- Clean charging contacts
- Wipe display

Weekly:

- Clean with slightly damp cloth
- Use water only (no chemicals)
- Clean strap thoroughly
- Remove strap from watch for cleaning
- Clean all nooks and crevices
- Dry completely before reassembly

Monthly:

- Deep clean
- Use mild soap if needed

- Clean all surfaces
- Inspect for damage
- Check water resistance
- Check strap condition

CLEANING PRODUCTS:

Safe to Use:

- Soft, lint-free cloth (microfiber)
- Water (slightly damp cloth)
- Mild soap (for deep cleaning)
- Isopropyl alcohol (70%, for disinfection, occasional use)

Do NOT Use:

- Harsh chemicals
- Solvents
- Abrasives
- Compressed air
- Ultrasonic cleaners
- Household cleaners
- Window cleaners
- Bleach
- Hydrogen peroxide
- Acetone
- Ammonia

CLEANING PROCESS:

Step 1: Remove from wrist

- Step 2: Remove strap (quick-release pins)
- Step 3: Wipe watch body with dry cloth
- Step 4: For deeper clean, use slightly damp cloth
- Step 5: Clean sensors on back
- Step 6: Clean charging contacts (important!)
- Step 7: Clean strap separately
- Step 8: Dry completely
- Step 9: Reassemble
- Step 10: Put back on wrist

13.2 Water Resistance Care

IP68 / 5ATM RATING:

What it Means:

- IP68: Dust-tight, can be immersed in 1.5m water for 30 minutes
- 5ATM: Water resistant up to 50 meters (static pressure)
- Suitable for: Swimming, showering, rain, handwashing
- NOT suitable for: Diving, snorkeling, high-velocity water, hot water

WATER RESISTANCE TIPS:

Do:

- Wear while swimming (pool)
- Wear in shower
- Wear in rain
- Wear while washing hands
- Wear during water sports (surface level)

Don't:

- Don't dive or snorkel
- Don't use in hot water (hot tubs, saunas)
- Don't use in salt water without rinsing
- Don't press buttons underwater
- Don't expose to high-velocity water (water skiing, jet skiing)
- Don't wear in steam rooms or saunas

AFTER WATER EXPOSURE:

Rinse with Fresh Water:

- Especially after salt water or chlorinated water
- Removes salt, chlorine, chemicals
- Prevents corrosion
- Gently rinse
- Dry with soft cloth

Dry Thoroughly:

- Use soft, dry cloth
- Dry all surfaces
- Dry charging contacts
- Dry strap
- Air dry for few minutes
- Ensure completely dry before charging

Water Resistance Decreases Over Time:

- Normal wear and tear
- Gaskets degrade
- Impacts can affect seal

- Get checked annually if used in water
- Service center can test water resistance

13.3 Strap Maintenance

STRAP CARE:

Daily:

- Wipe with dry cloth
- Remove sweat and dirt
- Check for signs of wear
- Ensure pins are secure

Weekly:

- Remove strap from watch
- Wash with mild soap and water
- Scrub gently (soft brush if needed)
- Rinse thoroughly
- Dry completely
- Reattach to watch

Monthly:

- Inspect for cracks, tears, damage
- Check pin holes for wear
- Check quick-release pins
- Deep clean if needed
- Condition if leather (not applicable for silicone)

STRAP REPLACEMENT:

When to Replace:

- Visible cracks or tears
- Pin holes elongated
- Strap feels weak or brittle
- Discoloration or staining (cosmetic)
- After 1-2 years of regular use (preventive)

Replacement:

- Standard 22mm straps
- Quick-release pins
- Easy to swap
- Multiple colors/styles available
- Purchase from TechNova or third-party

INSTALLING STRAP:

1. Align quick-release pin with hole
2. Push pin into hole
3. Ensure clicks into place
4. Tug gently to test
5. Repeat for other side
6. Ensure secure

13.4 Storage Guidelines

STORING YOUR WATCH:

Short-term (Daily):

- Wear on wrist or place on bedside table

- Or place on charging dock
- Avoid direct sunlight
- Avoid extreme temperatures
- Keep away from liquids

Long-term (When Not Using):

- Charge to 50-60%
- Power off completely
- Store in cool, dry place
- Avoid direct sunlight
- Avoid extreme temperatures (0-30°C ideal)
- Store in original box or protective case
- Keep away from magnetic fields
- Check every 3 months, recharge if needed

STORAGE CONDITIONS:

Temperature:

- Ideal: 15-25°C (59-77°F)
- Acceptable: 0-30°C (32-86°F)
- Avoid: Below 0°C or above 45°C

Humidity:

- Ideal: 40-60%
- Avoid: Very humid or very dry

Environment:

- Clean, dust-free
- Away from direct sunlight

- Away from heat sources
- Away from strong magnetic fields
- Away from chemicals

PROTECTIVE CASE:

- Recommended for storage
- Original box is ideal
- Or: Soft pouch
- Protects from scratches
- Protects from dust
- Keeps organized

BEFORE RETURNING TO USE:

- Charge fully
- Power on
- Check for any issues
- Pair with phone again
- Update firmware if needed

=====

=====

CHAPTER 14: TROUBLESHOOTING

=====

=====

14.1 Common Issues

ISSUE: Watch won't turn on

Possible Causes:

- Battery completely drained
- Charging issue
- Software crash
- Hardware issue

Solutions:

1. Charge for at least 30 minutes
2. Use different charger/cable
3. Try different power source (computer, adapter, power bank)
4. Clean charging contacts
5. Ensure good contact
6. After charging, press and hold crown for 10 seconds
7. Force restart
8. If still won't turn on, contact support

ISSUE: Watch not charging

Possible Causes:

- Poor contact
- Dirty contacts
- Faulty charger
- Cable issue
- Power source issue

Solutions:

1. Clean charging contacts (on watch and cable)
2. Ensure good contact (magnets should snap)
3. Try different power source
4. Try different USB cable/adapter

5. Check for debris in charging port
6. Restart watch
7. If still not charging, contact support

ISSUE: Not connecting to phone

Possible Causes:

- Bluetooth issue
- Distance too far
- Interference
- Software issue

Solutions:

1. Ensure Bluetooth is ON on phone
2. Bring phone close to watch (within 1 meter)
3. Restart Bluetooth on phone
4. Restart watch
5. "Forget" device in Bluetooth settings, re-pair
6. Restart phone
7. Update app to latest version
8. Update watch firmware
9. If still not connecting, contact support

ISSUE: Inaccurate step count

Possible Causes:

- Loose fit
- Wrong wrist setting
- Arm movement not detected

- Software issue

Solutions:

1. Wear watch snugly (not too loose)
2. Check wrist setting (left/right)
3. Calibrate: Walk 100 steps, compare
4. Update firmware
5. Restart watch
6. If still inaccurate, contact support

ISSUE: Inaccurate heart rate

Possible Causes:

- Loose fit
- Dirty sensors
- Movement during measurement
- Cold skin
- Skin tone/tattoo interference

Solutions:

1. Wear watch snugly (1-2 cm above wrist bone)
2. Clean sensors on back
3. Keep still during measurement
4. Warm up skin (rub wrist)
5. Move watch slightly up/down
6. Tighten during workouts
7. Update firmware
8. If still inaccurate, contact support

ISSUE: Battery draining fast

Possible Causes:

- Always-on display enabled
- Continuous heart rate monitoring
- Many notifications
- Background apps
- Old battery
- Software issue

Solutions:

1. Disable always-on display
2. Reduce heart rate monitoring frequency
3. Reduce notifications
4. Enable power saving mode
5. Check battery health in app
6. Update firmware
7. Restart watch
8. If still draining fast, contact support

ISSUE: Notifications not showing

Possible Causes:

- App permissions not granted
- Notifications disabled in app
- Do Not Disturb enabled
- Watch not connected
- Phone issue

Solutions:

1. Grant notification permission to app
2. Enable notifications for desired apps
3. Check Do Not Disturb settings
4. Ensure watch connected to phone
5. Restart app
6. Restart watch
7. Restart phone
8. Re-pair devices
9. If still not working, contact support

ISSUE: Touch screen not responding

Possible Causes:

- Screen protector issue
- Wet screen
- Software freeze
- Hardware issue

Solutions:

1. Remove screen protector (if any)
2. Dry screen thoroughly
3. Clean screen
4. Restart watch
5. Force restart (hold crown 10 seconds)
6. If still not responding, contact support

14.2 Error Messages

ERROR: "Battery Low"

Meaning: Battery below 10%

Action: Charge immediately

ERROR: "Charging Error"

Meaning: Charging issue detected

Action:

1. Check charger connection
2. Clean contacts
3. Try different charger
4. If persists, contact support

ERROR: "Bluetooth Disconnected"

Meaning: Lost connection to phone

Action:

1. Bring phone closer
2. Check phone Bluetooth
3. Reconnect in app
4. Restart if needed

ERROR: "Storage Full"

Meaning: Watch storage full

Action:

1. Delete unused apps/data
2. Clear cache

3. Remove old workouts
4. Factory reset if needed

ERROR: "Update Failed"

Meaning: Firmware update failed

Action:

1. Ensure 50%+ battery
2. Keep on charger
3. Keep phone nearby
4. Try again
5. If persists, contact support

ERROR: "Sensor Error"

Meaning: Sensor malfunction

Action:

1. Clean sensors
2. Restart watch
3. If persists, contact support

14.3 Reset Procedures

SOFT RESET (RESTART):

When to Use:

- Minor issues
- Slow performance
- App crashes

- Occasional glitches

How to Do:

1. Settings → System → Restart
2. Or: Hold crown button → Power off menu → Restart
3. Or: Hold crown 10 seconds (force restart)
4. Watch restarts automatically
5. Takes 30-60 seconds

HARD RESET (FACTORY RESET):

When to Use:

- Major issues
- Software problems
- Before selling/giving away
- Last resort

WARNING:

- Erases ALL data
- Unpairs from phone
- Returns to factory settings
- Can't be undone
- Backup important data first

How to Do:

Method 1: On Watch

1. Settings → System → Factory Reset
2. Confirm reset
3. Enter PIN (if set)

4. Confirm again
5. Watch resets
6. Takes 2-3 minutes

Method 2: In App

1. Devices → Your Watch → Factory Reset
2. Confirm reset
3. Watch resets
4. Takes 2-3 minutes

After Factory Reset:

- Watch like new
- Need to set up again
- Re-pair with phone
- Reconfigure settings
- Restore data from backup (if any)

14.4 Contact Support

WHEN TO CONTACT SUPPORT:

Contact if:

- Issues persist after troubleshooting
- Hardware damage
- Water damage
- Battery issues
- Charging issues
- Display issues
- Button issues

- Any other problems

HOW TO CONTACT:

Phone:

- 1800-123-4567 (Toll-free)
- Mon-Sat: 9 AM - 9 PM
- Sun: 10 AM - 6 PM

Email:

- support@technovaelectronics.com
- Include: Model, issue description, steps tried, purchase date, invoice

Website:

- www.technovaelectronics.com/support
- Live chat
- Support ticket
- FAQs
- Troubleshooting guides

In-App:

- TechNova Fit app → Profile → Help & Support
- Chat with support
- Create ticket
- FAQs

Service Centers:

- Find nearest: Website → Service Centers
- Walk-in or appointment

- Carry watch and invoice
- Diagnosis and repair

Social Media:

- Facebook: @TechNovaElectronics
- Twitter: @TechNovaIndia
- Instagram: @technovaindia
- Quick response

WHAT TO PROVIDE:

When contacting support:

- Product model
- Serial number
- Purchase date
- Invoice number
- Issue description
- When it started
- Steps already tried
- Photos/videos (if applicable)
- Your contact details

SUPPORT HOURS:

- Phone: Mon-Sat 9 AM - 9 PM, Sun 10 AM - 6 PM
- Email: 24/7 (response within 24-48 hours)
- Chat: Mon-Sat 9 AM - 9 PM
- Service Centers: Mon-Sat 10 AM - 7 PM

=====

=====

WARRANTY INFORMATION

=====

=====

Your TechNova Pro X1 comes with:

- 12 months manufacturer warranty
- Covers manufacturing defects
- Does not cover physical damage or water damage
- Warranty card included in box
- Register warranty online for faster claims

See Warranty Policy for complete details.

=====

=====

REGULATORY INFORMATION

=====

=====

Compliance:

- BIS certified
- CE certified
- RoHS compliant
- WEEE compliant
- REACH compliant

FCC Statement:

This device complies with Part 15 of FCC Rules.

Disposal:

Do not dispose with household waste.

Recycle at e-waste collection center.

=====

TECHNOVA ELECTRONICS PVT. LTD.

=====

Registered Office:

Plot No. 123, HITEC City

Hyderabad - 500081

Telangana, India

Customer Support:

Phone: 1800-123-4567 (Toll-free)

Email: support@technovaelectronics.com

Website: www.technovaelectronics.com

WhatsApp: +91-9876543210

Support Hours:

Monday-Saturday: 9:00 AM - 9:00 PM

Sunday: 10:00 AM - 6:00 PM

=====

Thank you for choosing TechNova!

=====

=====

=====

=====

END OF SMARTWATCH USER MANUAL

=====

=====