

SwarmOS — Complete Replication, Setup, & Deployment Manual

1. PROJECT INFORMATION

Project Name: SwarmOS


Project Location: `~/Projects/SwarmOS`


Current Project Structure:

```
SwarmOS/
├── docs/                # Documentation directory
├── environment.yml      # Conda environment definition
├── LICENSE              # Project License
├── test_mavlink_direct.py # Direct MAVSDK API verification script
├── test_set_mode.py     # Flight mode emulation test script
├── venv/               # Python virtual environment (if used instead
of conda)
├── DroneOS/            # The onboard drone computer application
├── GroundStation/      # The laptop command and control UI
└── README.md           # Project root README
```

Purpose of Components: - **GroundStation:** PySide6 UI application running on the operator's laptop. It dispatches targeted UDP commands and displays live telemetry. - **DroneOS:** The onboard application running on a companion computer (e.g., Raspberry Pi). It interprets GroundStation commands and translates them into native PX4/MAVSDK instructions. - **test_*.py:** Standalone scripts used to independently verify MAVSDK connection, mode-switching logic, and telemetry emulation before integrating them into the main applications.

2. COMPLETE SYSTEM ARCHITECTURE





Architecture Layers:

- **GroundStation:** Issues commands (`ARM` , `SET_MODE` , etc.) and monitors health.
- **Network:** Operates over UDP (default port 14550) using Pydantic models serialized via `msgpack-rpc-python` .
- **Drone Computer:** Runs `DroneOS/main.py` . Responsible for safely accepting commands, verifying them against telemetry/health limits, and forwarding them.
- **Flight Controller:** Pixhawk running PX4, receiving MAVLink commands via the MAVSDK library.
- **Swarm Logic:** Operates in a decentralized manner. Telemetry is broadcast across drones, allowing DroneOS to calculate collision avoidance and peer-status internally.

3. IMPORTANT ARCHITECTURAL PRINCIPLE

Command Path:

```

Laptop GroundStation (UI) -> NetworkManager.send_command() -> NetworkNode
(UDP sendto) -> Target DroneOS (NetworkNode) ->
CommandHandler.handle_command() -> FlightManager -> PX4Adapter -> MAVSDK ->
Pixhawk -> Drone (UAV)
  
```

Telemetry Path:

```

Pixhawk -> MAVSDK -> DroneOS PX4Adapter -> DroneOS TelemetryPublisher ->
UDP Network -> GroundStation NetworkNode -> GroundStation UI
  
```

Drone Identification: Drones are identified natively by a string `drone_id` (e.g., `"drone1"` , `"drone2"`). This string originates from `DroneOS/configs/drone.yaml` (`drone_id:` `"drone1"`), is attached as `sender_id` in telemetry/heartbeat packets, and is utilized by the GroundStation to target specific IP endpoints.

4. PROJECT DIRECTORY — COMPLETE EXPLANATION

SwarmOS/ Root

- `docs/` : Storage for architecture reports and manuals.
- `environment.yml` : Specifies the Conda environment (Python >= 3.10, PySide6, pydantic, mavsdk).
- `test_mavlink_direct.py` : Validates MAVSDK `mavlink_direct` API capabilities.
- `test_set_mode.py` : Emulates FlightManager mode switching behavior.

DroneOS/

- **adapters/**: Interfaces with hardware (e.g., `px4_adapter.py` for MAVSDK).
- **core/**: Core business logic (`command_handler.py` , `flight_manager.py` , `swarm_manager.py` , `decision_engine.py` , `collision_avoidance.py`).
- **configs/**: YAML files defining the drone's identity and network (`drone.yaml` , `flight.yaml` , `network.yaml`).
- **deploy/**: Deployment scripts and utilities.
- **sensors/**: Hardware and health monitoring (`health_monitor.py` , `battery_monitor.py`).
- **tests/**: Local unit tests for DroneOS components.
- **shared/**: Symlinked or duplicated folder containing `protocol/messages.py` , `utils` , and configuration models.
- **main.py**: The Asyncio entry point initializing the event loop, network, sensors, and adapters.

5. DRONEOS ARCHITECTURE

`DroneOS/main.py` binds everything. 1. **Network**: Receives a `ControlMessage` from GroundStation. 2. **CommandHandler**: `handle_command()` parses the payload. Evaluates `_validate_safety_gate()` (checks heartbeat/telemetry staleness). 3. **FlightManager**: Executes standard flight operations. 4. **PX4Adapter**: Translates FlightManager intentions into MAVSDK functions (`action.arm()` , `action.land()` , `action.hold()`). 5. **Sensors**: `TelemetryPublisher` reads from PX4Adapter at 30Hz and broadcasts `TelemetryMessage` . `HealthMonitor` checks GroundStation connection staleness. 6. **Swarm/Decentralized**: `CollisionAvoidance` inside the core loops independently monitors peer telemetry and flags `future_intent` if a breach is imminent.

6. GROUNDSTATION ARCHITECTURE

- **main.py:** Initiates `qasync` (Asyncio over Qt event loop) and launches the PySide6 UI.
- **ui/:** Contains `FlightControlPanel`. Connects button clicks to Asyncio dispatchers (e.g. `_on_set_mode`).
- **core/:** `GSNetworkManager` keeps a registry of discovered drones.
- **Network:** `NetworkNode` listens to port 14550. When it receives telemetry, it dynamically maps the `sender_id` (e.g., `drone2`) to the incoming `(IP, port)`. Targeted commands then unicast directly to that learned IP.

7. GROUNDSTATION LAPTOP SETUP

OS Requirements: Linux/Ubuntu highly recommended (macOS/Windows supported via Conda). **Dependencies:** Git, Conda, Python 3.10+.

```
# Clone Project
git clone <repository_url> ~/Projects/SwarmOS
cd ~/Projects/SwarmOS

# Create Environment
conda env create -f environment.yml
conda activate base

# Verify Environment
python3 -c "import PySide6, pydantic, mavsdk; print('Ready')"
```

8. CONDA / ENVIRONMENT SETUP

The project explicitly provides `environment.yml` and `requirements.txt`. **Recommended:** Conda.

```
conda env create -f environment.yml
conda activate base
```

Alternatively, using the provided `venv/`:

```
python3 -m venv venv
source venv/bin/activate
pip install -r GroundStation/requirements.txt
```

9. GROUNDSTATION RUN PROCEDURE

MACHINE: Laptop DIRECTORY: `~/Projects/SwarmOS` COMMAND: `python3 -m GroundStation.main` PURPOSE: Starts the PySide6 UI and UDP command listener. EXPECTED OUTPUT: The UI window opens. Terminal logs `GroundStation UI running`.

10. DRONE RASPBERRY PI SETUP

For each Drone (Drone 1, Drone 2...): 1. Flash Raspberry Pi OS (64-bit recommended for MAVSDK). 2. Connect to the same Wi-Fi subnet as the GroundStation. 3. SSH into the Pi. 4. Clone the repository to `~/Projects/SwarmOS`. 5. Install Python dependencies: `pip install -r DroneOS/requirements.txt`. 6. Configure `DroneOS/configs/drone.yaml` to uniquely identify the drone (e.g., `drone_id: "drone2"`).

11. PIXHAWK / PX4 CONNECTION

Determined by `DroneOS/configs/flight.yaml`. **Standard Connection:** `px4_connection_string: "serial:///dev/ttyAMA0:115200"` - DroneOS uses `MAVSDK-Python` over this serial port. - Diagnostic check on Pi: `ls -l /dev/ttyAMA0`. Ensure the Pi user is in the `dialout` group.


12. MAVLINK ARCHITECTURE

SwarmOS natively utilizes `MAVSDK-Python` as a high-level wrapper over MAVLink. - `ARM` -> `client.action.arm()` - `TAKEOFF` -> `client.action.takeoff()` - `RTL` -> `client.action.return_to_launch()` - `TELEMETRY` -> `client.telemetry.position()`, `client.telemetry.flight_mode()`. `test_set_mode.py` and `test_mavlink_direct.py` verify that specific custom modes (like `STABILIZE`) may not be supported by standard MAVSDK actions and require fallback or explicit rejections.

13. MULTI-DRONE IDENTIFICATION

SwarmOS isolates drones via the `drone_id` defined in `DroneOS/configs/drone.yaml`. - The `sender_id` of UDP messages maps directly to `drone_id`. - Drones ignore commands where `target_id` does not match their own `drone_id` (or `"ALL"`). - Two drones sharing `"drone1"` will cause GroundStation network endpoint flapping, breaking targeted command routing.

14. NETWORK TOPOLOGY



- **Port:** UDP 14550.
- **Discovery:** GroundStation broadcasts heartbeat to `255.255.255.255`. Drones broadcast telemetry to `255.255.255.255`. Once IPs are learned, SwarmOS utilizes **Targeted Unicast** for execution commands to guarantee delivery over tricky subnet routing.

15. COMMAND ARCHITECTURE

Supported Actions (from `CommandAction Enum`): - `ARM`, `DISARM`, `TAKEOFF`, `LAND`, `RTL`, `HOVER`, `MOVE`, `FORMATION_UPDATE`, `SET_MODE`.

Path for ARM: 1. User clicks "ARM" in `FlightControlPanel`. 2. UI evaluates `target = "drone2"`. 3. Calls `GSNetworkManager.send_command("drone2", ARM)`. 4. `NetworkNode` looks up "drone2" in `known_endpoints`, serializes to UDP, and Unicasts to `10.168.175.176`. 5. DroneOS receives it, verifies GS heartbeat is fresh (`Command_RX`). 6. `FlightManager.arm()` invokes `PX4Adapter.arm()`.

16. SWARM COMMANDS

- **ALL DRONES / SWARM:** In the GroundStation UI, selecting "ALL" passes `target_id = None`. The `GSNetworkManager` automatically falls back to `broadcast_message()`, transmitting the command to `255.255.255.255:14550`. Every drone receives it and processes it because `target_id` matching permits `"ALL"`.

17. TELEMETRY

Published via `TelemetryMessage` -> `TelemetryData` object: - `gps_valid`, `battery_level`, `voltage`, `altitude`, `latitude`, `longitude` - `velocity_x/y/z`,

`flight_mode` , `armed_state` - `future_intent` (used by collision avoidance) Generated at 30Hz by DroneOS `TelemetryPublisher` , consumed by `FlightControlPanel` (UI updates) and peer DroneOS nodes (Collision Avoidance).

18. GROUNDSTATION UI

- **Framework:** PySide6 with `qasync` loop.
- **Main Window:** A modular interface displaying logs, connected drones drop-down, telemetry dials, a D-Pad for `MOVE` commands, and a Flight Mode selector.

19. MISSIONS

- `CommandAction.FORMATION_UPDATE` and Mission Message enums (`MISSION_UPLOAD` , `MISSION_START` , `MISSION_PROGRESS`) are fully defined in the Pydantic schemas.
- GroundStation `missions/` handles defining waypoints.
- DroneOS `mission_receiver.py` (VERIFY FROM PROJECT SOURCE) processes these arrays.

20. CONFIGURATION

- **GroundStation:** `GroundStation/configs/network.yaml` (Defines UDP port, broadcast address).
- **DroneOS:**
- `DroneOS/configs/drone.yaml` -> Sets the critical `drone_id` (e.g. `"drone1"`).
- `DroneOS/configs/flight.yaml` -> Sets MAVSDK connection (`serial:///dev/ttyAMA0:115200`).

21. TESTING

Static Tests: Execute `python3 -m compileall GroundStation/ DroneOS/` to verify Python syntax. **Hardware Test:** - `python3 test_set_mode.py` -> Mocks FlightManager and evaluates Python-level mode rejection logic without hardware. - `python3 test_mavlink_direct.py` -> Prints whether `sys.mavlink_direct` API is locally available in MAVSDK.

22. COMPLETE SINGLE-DRONE TEST

1. Start GroundStation: `python -m GroundStation.main`
2. Start DroneOS: `python -m DroneOS.main`
3. Pixhawk Connection: Observe DroneOS console `Connected to flight controller`.
4. Discovery: Observe GS console `Peer learned: drone1`.
5. Arm: Select `drone1`, click ARM. Observe `COMMAND_RX sender=gs1 target=drone1 action=arm` on drone.

23. COMPLETE MULTI-DRONE TEST

- Ensure Drone1 has `drone.yaml: drone_id: "drone1"`.
- Ensure Drone2 has `drone.yaml: drone_id: "drone2"`.
- Launch both drones.
- GroundStation will display both in the drop-down.
- Send a targeted command (e.g. `SET_MODE: RTL`) to `drone2`. Confirm `drone1` ignores it.

24. FRESH REPLICATION — FROM ZERO

1. Clone repo to laptop. `conda env create -f environment.yml`
2. Clone repo to Raspberry Pi 1. `pip install -r requirements.txt`. Edit `drone.yaml` -> `drone1`.
3. Connect Pi UART to Pixhawk `TELEM2` port.
4. Launch GS on laptop.
5. Launch DroneOS on Pi 1.
6. Verify Telemetry propagates to the UI.

25. ADDING DRONE 4

1. Copy Pi image from Drone 3 to Drone 4.
2. Edit `/home/pi/Projects/SwarmOS/DroneOS/configs/drone.yaml`.
3. Change `drone_id` to `"drone4"`.
4. Boot Drone 4. GroundStation will natively auto-discover it over UDP and add it to the UI drop-down. No GS restarts required.

26. DEVELOPMENT GUIDE

- **GroundStation UI:** Edit `GroundStation/ui/flight_control_panel.py`. Always use `asyncio.get_event_loop().create_task()` to hook into Qt callbacks without blocking.
- **DroneOS Logic:** Edit `DroneOS/core/flight_manager.py`. Run `python3 -m compileall DroneOS/` before flight to trap basic syntax faults.

27. GITHUB WORKFLOW

- Always branch before editing core logic: `git checkout -b feature/collision-avoidance`.
- Revert safely: `git checkout -- <file>`.

28. COMMON ERRORS

SYMPTOM	CAUSE	FIX
<code>Command rejected: Heartbeat stale</code>	GroundStation heartbeat broadcast routing failed.	Ensure GroundStation loop explicitly unicasts heartbeat to known endpoints.
GroundStation UI logs <code>COMMAND_DISPATCH_FAILED</code>	Asyncio loop detachment in Qt callback.	Use <code>get_event_loop()</code> instead of empty <code>asyncio.run()</code> .
DroneOS ignores command	Targeted command sent to wrong <code>drone_id</code> .	Select correct drone in GS dropdown.

29. LOG ANALYSIS

- `COMMAND_TX` : Logged by `GroundStation/shared/communication/network_node.py` right at `transport.sendto`.
- `COMMAND_RX` : Logged by `DroneOS/core/command_handler.py`. If RX appears but Pixhawk fails, the fault lies in MAVSDK/PX4 params.

30. SAFE PROCESS CLEANUP

- Terminate DroneOS with `Ctrl+C`. `main.py` explicitly catches `KeyboardInterrupt`, cleanly cancels asyncio tasks, stops `UdpNetworkAdapter`, and disconnects MAVSDK to prevent zombie serial locks.

31. SYSTEMD / SERVICES

“No systemd service is currently provided by the verified project.” (VERIFY FROM PROJECT SOURCE: Manually creating a systemd unit calling the virtualenv python is recommended for production).

32. PERFORMANCE AND SAFETY

- **Heartbeat Timeout:** If GS heartbeat stops, DroneOS triggers Connection Lost Failsafe (usually mapped to RTL/LAND).
- **Collision Avoidance:** DroneOS internally monitors `TelemetryMessage` from peers. If distances close, `future_intent` halts the drone locally without GroundStation intervention.

33. DEVELOPMENT VS PRODUCTION

- **Development:** Use software-in-the-loop (SITL) simulators connected to MAVSDK.
- **Production:** Real Pixhawk. Ensure all logging captures `Exceptions` fully (no `except RuntimeError: pass`) so mid-air logic aborts leave forensic traces.

34. FINAL VALIDATION CHECKLIST

- [] GroundStation Python environment loaded.
- [] Network Broadcast IPs matched.
- [] Drone `drone.yaml` IDs verified unique.
- [] GroundStation UDP UI Dropdown populated.
- [] "ARM" command targets exclusively the selected drone.

35. QUICK REFERENCE

MACHINE: Laptop DIRECTORY: `~/Projects/SwarmOS` COMMAND: `python3 -m GroundStation.main`

MACHINE: Drone Computer DIRECTORY: `~/Projects/SwarmOS` COMMAND: `python3 -m DroneOS.main`

36. FILE-BY-FILE REFERENCE

FILE: `GroundStation/core/network_manager.py` **PURPOSE:** Tracks drones via incoming UDP, routes commands via `NetworkNode`. **SAFE TO MODIFY?:** Yes, but ensure `send_message(target_id)` unicasting is preserved for reliability.

FILE: `DroneOS/core/command_handler.py` **PURPOSE:** Validates incoming UDP `ControlMessage`. Enforces `HealthMonitor` safety checks before passing to `FlightManager`.

37. ARCHITECTURE DIAGRAMS

Refer to Section 2 for the Unified Architecture Layout.

38. DOCUMENTATION STYLE

This document adheres strictly to verified source code mechanics, removing speculative hardware assumptions.

39. CRITICAL SOURCE-ACCURACY RULE

Verified Implementation: - Actual technology: UDP over Port 14550, `msgpack`, Pydantic models.
- Actual GroundStation: PySide6. - Actual MAV: MAVSDK Python wrapper.

40. FINAL PDF

This document will be saved and rendered to `~/Documents/SwarmOS_Complete_Replication_Setup_Deployment_Manual.pdf`.