


We can see firstly, we are trying to write the data 10 at the address 10 in the salve memory and we get response as 0 it means that data is successfully written in the slave memory without any error now when we try to write 10 on the memory location 18 we get the response from the slave as 3 because address is out of range .



Here salve memory is successfully updated with the data 10 at the memory location 10.