

SUBPRO


STARTUP PROCEDURE - EROSION RIG






Page 1/2

- 6. Turn on air valve from Step 2 (AIR)
- 7. Turn on pressure regulator **V108** (clockwise on | counter-clockwise off)
- 8. Turn on the cabinet using the **green button** (outside)
- 9. Start the LabVIEW program by pressing the white arrow
- 10. Turn on the pump
- 11. Open valves **V102, V103 & V104** (any order)
- 12. Open valve **V101**







END