
SVAJ Diagram — Harmonic Rise (0° to 90°)
S — Displacement
V — Velocity (normalised)
A — Acceleration (normalised)
J — Jerk (normalised)
(from dwell)
(to dwell)
Normalised Value
1.00
0.75
0.50
0.25
0.00
−0.25
−0.50
−0.75
−1.00
0
15
30
45
60
75
90
Cam Angle θ (degrees from start of rise)