

Regenerative Braking Duty Cycle: Continuous vs. Intermittent Loads

Continuous braking needs a continuous-duty (100% ED) resistor; brief pulses do not

