PNP (Sourcing)

Fault pulls signal LOW −> reads OFF (fails to a detectable, safe state)



NPN (Sinking)

Fault pulls signal LOW −> mimics sensor ACTIVE (can read ON unexpectedly)