# Interlocked Guard System

Opening the guard door breaks the safety circuit




Door Closed
= Machine Runs

Door Open
= Machine Stops