STEPS TO DOWNLOAD AND INSTALL FRACKTORY

- 1) Type Technoventor: TI on google 'or' Technoventor.com
- 2) Go to support -> Choose software
- 3) Download Fracktory -> Latest version
- 4) Extract all files to PC
- 5) Open extracted file -> search for Fracktory.exe by scrolling down.
- 6) Run the file. Allow permission.
- 7) Go in Julia Series -> Julia advanced -> add printer