STEPS TO DOWNLOAD AND INSTALL LASERCAD

- 1) Type Technoventor: TI on google 'or' Technoventor.com
- 2) Go to support -> Choose software
- 3) Download Lasercad -> Latest version (copy and paste the link address by right clicking on 'download latest version'
 - → paste in parallel tab, download will start → go to downloads and press keep).
- 4) Download is completed.
- 5) Do NOT extract the file. Open the LaserCAD zip file.
- 6) Click on setup -> Run.
- 7) Click on 'install' and you are done.