SAMPLE

Cosmic Explorers: Space Refueling

Gas Stations in Orbit

Aira Astralis

Free sample: Introduction & Chapter 1

putrabooks.github.io

Contents

Introduction

Chapter 01: The Equation That Rules Everything

Chapter 02: The First Transfers

Chapter 03: The Case for the Depot

Chapter 04: Cryogenics: The Hard Cold Problem

Chapter 05: Storable Fluids and the Proven Art

Chapter 06: The Robots That Do the Work

Chapter 07: The Servicers

Chapter 08: Making Fuel Where You Land

Chapter 09: The Economics of Fuel Above the Sky

Chapter 10: Tankers and the Big Transfers

Chapter 11: The Physics of Moving Fluids in Orbit

Chapter 12: Safety, Law, and the Neighborhood

Chapter 13: Failures, Leaks, and Lessons

Chapter 14: The Long Game

Conclusion

Glossary Note

This free sample contains the Introduction and Chapter 1. The complete book contains the full contents above.

Introduction

Spaceflight has a weight problem, and the weight is almost always fuel. A rocket rising from the ground is, at the moment of liftoff, mostly propellant: the great launch vehicles of history have typically been between eighty-five and ninety-five percent fuel and tanks by mass, with everything else, the engines, the structure, the guidance, and the actual cargo, squeezed into what remains. The arithmetic that produces this imbalance is not engineering taste but physics, and it has governed every mission flown since 1957. The consequence is strange and severe: a spacecraft that reaches orbit arrives nearly empty, having burned almost everything it carried just to get there.

Refueling is the idea that breaks this arithmetic. If a vehicle can refill its tanks after reaching orbit, the propellant spent on the climb stops being a sunk cost and becomes a manageable expense, paid in installments, from supplies already stationed above the atmosphere. A ship that tops off in orbit can carry more cargo, go farther, come back, and do it again, and the difference between an expedition and a transportation system begins to look like the difference between a wagon train and a railroad with water towers along the line.

This book is about that idea: where it came from, what has actually been flown, what remains hard, and what it would take to make propellant an ordinary commodity in space. The story runs from the dockings of the Gemini program, through the routine but little-known refueling of the International Space Station by Russian cargo ships, to the robotic refueling demonstrations of the 2000s and 2010s, the first commercial servicing spacecraft that docked with a satellite whose builders never expected a visitor, and the current generation of launch vehicles designed from the start to be refueled in flight.

Along the way we will look at the physics of liquids in free fall, which is stranger than it sounds; the engineering of couplers, caps, and cryogenic tanks; the economics of selling fuel a few hundred kilometers above the Earth; and the quiet revolution in how satellites are built, serviced, and kept alive. The subject touches nearly every part of the space industry, because nearly every part of the space industry eventually runs out of fuel.

A note on scope before the journey begins. This is a book about the engineering and economics of moving propellant in space, not a catalog of vehicles or companies; hardware appears when it taught the field something, and programs are named when their lessons are public. Where the record is incomplete, on the classified servicing work of several nations, the book says so and moves on, and where a capability has been demonstrated but not yet made routine, the text is careful to say which of the two it is. Whoever finishes

these chapters should be able to read any refueling proposal, from a corporate slide or an agency study, and know exactly which parts of it are proven, which are engineering, and which are hope.

The argument of the book is simple. Refueling in space has already been done, repeatedly, by machines built for that purpose. What is missing is not knowledge but scale and commitment: depots stocked regularly, servicers flying on schedule, propellant bought and sold like any other cargo. When that happens, the rocket equation, for the first time in the history of spaceflight, will stop being the master of every mission plan and become merely the first constraint of many. That change is what the rest of these chapters describe.

Chapter 01: The Equation That Rules Everything

Every difficulty in this book begins with one line of mathematics. The rocket equation, published by Konstantin Tsiolkovsky in 1903, relates a rocket's change in speed to the exhaust velocity of its propellant and the logarithm of its mass ratio, the ratio of the vehicle's mass at ignition to its mass at burnout. The equation is short enough to fit on a napkin, and its consequences fill the rest of the book.

The key term is the logarithm. Because the mass ratio enters only logarithmically, gaining speed by carrying more fuel runs into brutal diminishing returns. To go a little faster, a rocket must burn exponentially more propellant, and the propellant itself must be lifted along with everything else, which means burning more propellant to lift the propellant. This is why launch vehicles are stacking-crate structures: stages are thrown away as they empty, discarding dead tank mass so that the surviving stage starts fresh with a favorable ratio.

Run the numbers for a real mission and the imbalance becomes vivid. Reaching low Earth orbit requires about nine and a half kilometers per second of effective velocity change, allowing for gravity and drag losses. With the exhaust velocities of practical chemical propellants, four and a half kilometers per second or thereabouts, that demand translates into mass ratios that leave a rocket eighty-five to ninety percent propellant at liftoff. The final dry remainder must include the engines, the tanks, the avionics, and the payload. For a hydrogen-fueled upper stage,

the payload delivered to orbit can be little more than two or three percent of what stood on the pad.

The equation's tyranny compounds at every step of a deep-space voyage. A mission to the Moon or Mars must carry into orbit not just itself but all the propellant for the journey beyond, and every kilogram of that propellant

required ten or more kilograms of propellant to be launched from the ground. Mission designers respond by shaving mass everywhere: thinner structures, smaller margins, instruments designed to grams. The Apollo lunar module was built with walls so thin an engineer could dent them by pushing hard, because the alternative was less fuel, and less fuel meant no landing.

Staging is one way out; refueling is the other, and it is the only way out that keeps the vehicle. A stage that docks with a depot and refills its tanks resets its mass ratio in the middle of the mission, in effect gaining a new first stage without throwing anything away. The maneuver trades one exponential for two mild ones, and the trade is enormously favorable. Studies across five decades have returned the same conclusion: for missions beyond low Earth orbit,

refueling in orbit can multiply the deliverable payload severalfold, or cut the number of launches required for the same cargo by half or more.

The equation also explains why the fuel itself, not the hardware, is the expensive part of deep-space ambitions. If nearly ninety percent of a rocket's liftoff mass is propellant, then a program of lunar or planetary exploration is, in a real sense, a program of purchasing and lifting enormous quantities of chemicals. That is the economic insight behind the depot: propellant is the one cargo that every customer needs, in bulk, forever, and it does not have to ride on the same rocket as the people who will use it.

There is a final subtlety worth stating at the start, because it recurs in every later chapter. The rocket equation rewards exhaust velocity, and the propellants with the best exhaust velocities, liquid hydrogen above all, are also the hardest to store, since they are colder than any winter on Earth and evaporate steadily even in the best tanks. The physics of the mission pushes toward the fuels the storage engineering can least easily keep. Much of this book is about that tension: the equation demands light, cold, and volatile chemistry, and the tankfarm in orbit must somehow provide it. The chapters that follow walk the same tension down through the layers of the field: the proven storable transfers that keep stations alive today, the robots and servicers that have learned to feed spacecraft never built for visitors, the mines and tankers that would make propellant an industry, and the economics that decides which of the pieces fly next.

The arithmetic rewards a closer look, because the numbers are what convince skeptics. A two-stage vehicle using dense propellants, kerosene and liquid oxygen, reaches orbit with a mass ratio around fifteen to one between ignition and burnout when losses are included; a hydrogen-fueled upper stage can do the same work with a smaller ratio because hydrogen's exhaust velocity is nearly a third higher, but its tanks must be far larger for the mass carried,

since hydrogen is the least dense fuel in common use, and larger tanks weigh more and cost more to insulate. Mission designers therefore match propellant to job: dense fuels for the thick lower atmosphere, where a wide tank punches a smaller hole through the air, and light fuels for space, where a big tank costs drag but nothing else. The refueling proposal is, in one sentence, to let each stage buy its ideal fuel separately, at a station, after the hard part of the climb is over.

Exhaust velocity itself has boundaries worth knowing. Chemical bonds cap the energy a propellant can release, and no chemical combination much beats what has already flown, which is why sixty years of rocketry improved reliability and cost rather than speed. The escape from that ceiling, electric

propulsion, accelerates propellant to ten times chemical velocities but with thrust so feeble that months are needed to change a mission's orbit, and nuclear thermal concepts, studied since the 1960s, sit between the two, promising roughly double chemical performance with a reactor aboard. Every one of these alternatives still wants propellant, and every one of them gets more capable when its tanks can be refilled, so the depot idea survives whatever the propellant of the future turns out to be; it is propellant-agnostic by construction.

A final worked example makes the stakes plain. A lunar cargo mission launched fully fueled on a large expendable rocket might deliver a few tens of tonnes to the Moon's vicinity. The same spacecraft, launched nearly empty and filled at an orbital depot, can multiply that figure several times over, or fly on a launcher a fraction of the size, and the propellant consumed is the same either way; the difference is entirely in where it was loaded. That result, reproduced by every architecture study that has examined it since the 1960s, is the reason refueling refuses to die as an idea: it is the rare proposal that makes missions cheaper and more capable at once, and its obstacles, as the rest of the book shows, have been falling one by one.

End of free sample. The full book is available at putrabooks.github.io