



Date: 07 / 10 / 2021
L/No-Raj (01)

PART NO	DESCRIPTION	RATE	PART NO	DESCRIPTION	RATE
FEED PUMP ASSY.			BENJO BOLT		
RJ1001	1001 Feed Pump Assy. Perkins Roller Ty. L/L	1850	RJ1026G	Benjo Bolt 6Mm*1	14
RJ1002	1002 Fuel Pump Assy. Inter Roller Ty.	2050	RJ1027	1027 Banjo Bolt 8Mm*1	18
RJ1003	1003 Fuel Pump Assy. Massey Roller Ty.	1950	RJ1029G	1029G Banjo Bolt 12*1.5Mm	30
RJ1006	1006 Feed Pump Assy. Cav Ty.	2400	RJ1030G	1030G Banjo Bolt 14Mm	24
RJ1011	1011 Fuel Pump Assy. Ford Roller Ty.	2050	RJ1031G	Benjo Bolt 16*1.5Mm	62
RJ1028	1028/1002 Fuel Pump Assy. Pin Ty. Inter	2050	BANJO/COPPER WASHER		
RJ1029	1029/1001 Feed Pump Assy. Perkins L/L Pin Ty.	1880	RJ1	1 Leakage Washer (0X) 4*8*1 Copper	116
RJ1030	1030/1003 Fuel Pump Assy. Massey. Pin Ty.	1950	RJ11	Copper Washer (3X) 10*14*1Mm	168
RJ1031	1031/1011 Fuel Pump Assy. Ford Pin Ty	2050	RJ12	10*14*1.5Mm (3X) Copper Banjo Washer	168
RJ1200	1200 Feed Pump Cummins 6 Bt (P.No.14)	1590	RJ15	12*16*1.5Mm (4X) Copper Banjo Washer	278
RJ1210	1210 Feed Pump	1790	RJ16	14*18*1Mm (5X) Copper Washer	286
RJ1223	1223 Feed Pump T.C	2390	RJ17	14*18*1.5Mm (5X) Coper Benjo Was.	391
RJ1350	1350 Feed Pump Qualish	980	RJ18	18*22*1Mm (7X) Copper Banjo Washer	342
RJ1390	1390 Feed Pump M-Zen Diesel 9090	1630	RJ19	18*22*1.5Mm (7X) Copper Washer	507
RJP26A	F.P. Glassy Spring (Big)	0	RJ22	16*19.5*1 (6X) Hand Praimer Was Copper.	286
RJ4501AL	4501 Fuel Pump Assy. (Pre-Filter) Allu. Ty.	315	RJ23	16*19.5*1.5Mm (6X) H.P. Copper Washer	417
HAND PRIMER			RJ24	Z***26*30*1Mm Feed Pump Plug Copper Washer	485
RJ3001	3001 Hand Primer	246	RJ25	8*11.5*1Mm 8Mm U Ty. Copper Washer	482
RJ3018	3018 Hand Primer Sumo O/M Cav Ty.	268	RJ27	6*11*1 6Mm UCoper Was.	434
RJ3019	3019 Hand Primer Sumo N/M Cav Ty.	260	RJ28	22*26*1Mm (8X) Cap Washer P-3/Ford	443
RJ3025	3025 Hand Primer Tc	285	RJ4	4 Air Screw Washer (1X) 6*10*1 Copper	130
RJ3033	3033 Hand Primer (3033)	250	RJ40	9.5*19*1 Nozzle Was. T-Di Kirlosker Ford	443
RJ3099	Z***3099 Hand Primer (R) (P.No 31)	124	RJ41	Z***41 Nozzle Washer Interdi 9.5*19*1.5	638
OVER FLOVE VALVE			RJ47	9.5*20*5*1 Conic Noz. Washer Small Hino	931
RJ8001	8001 O/F Valve L/L & 1210 O/M	98	RJ5	Z***6*10*1.5Mm (1X) Airvent Screw Washer	130
RJ8002	8002 O/F Valve Zetor 2511	98	RJ64	7.4*15*1 Noc Copper Washer	310
RJ8003	8003 Over Flow Valve Se	98	RJ65	7.4*15*1.5 Nozzle Cop. Was T-Cummins Tc	428
RJ8008	8008 Over Flow Valve Tc	92	RJ66	66 Nozzle Washer T.C (7.4*1.5*2)	515
RJ8010	8010 O/F Valve Tc N/M Ball Ty.	105	RJ67	7.4*15*2.5 Noz Copper Washer	662
RJ8011	8011 Over Flow Valve Tc-2515	150	RJ67A	7.4*15*3 Noz Copper Washer	760
OIL SEAL			RJ7	Copper Washer (2X) 8*12*1	143
RJR27A	Oil Seal A Type (11 8 11) Spaco	19	RJ75	0Mm Cattori Washer (Copper)	154
SHIMS			RJ8	8*12*1 (2X) Banjo Coper Was.	143
RJP167	Chuha Shims	0	RJ9	8*12*1.5Mm (2X) Copper Washer	189
RJE6	Element Washer (Shims) 14*18*0.2 Copper	0	RUBBER COMPONENTS ITEM		
BOWL NUT/SCREW			RJP154	Rubber Segment Suja	0
RJ018001	01.8001 F.P. Glassi Nut Only	19	F.P. VALVE BAKELITE		
RJ019001	01.9001 F.P. Glassi Wire (Clamp)	19	RJ8111010	8111010 F/ Pump Valve Cut. Ty. (Pkt 100 Pcs)	330
RJ2101	2101 Fuel Pump Repair Kit Full	83	RJ8111110	8111110 F/ Pump Valve Plain Ty. (Pkt 100 Pcs)	410
RJ7001001	7001.001 Glassi Screw Only	6.5	RJ6310	6310 Feed Pump Valve Spring	1
AIR BREATHER			DSL FILTER PLATE/ASSY.		
RJ5201	5201 Pump Nut O/M Small	65	RJ9010	9010 Dsl Filter Plate (C.A.V. Ty.) Single	430
RJ5202	5202 Pump Nut N/M Big	69	RJ9115	9115 Dsl. Filter Assy. Big (Close Ty.)	2250
DIAPHRAGM/DIAPHRAM			RJ9208	9208 D/Filter Assy. (Single Ty.) Small 407	952
RJ5002	5002 Diaphragm (1/3)	198	RJ9544	9544 Dsl Filter Plate (Big) Single Ty.	430
PUMP PKG			FEED PUMP REPAIR KIT		
RJP155	Pump Pkg (3Hole) Pjo/Tata	2.5	RJ2110	2110 Fuel Pump Reap. Kit Half	22
RJP156	Pump Pkg (3Hole) Marshal (Cut Ty.)	9	OTHER		
			RJ4510ASSY	4510 (Assy.) W/Saprotor Assy. Tc	1650
			RJP136	Air Brother Adopter (Air Vent Assy. 14Mm)	44
			RJP92	Control Sleeve L/L 402	110
W/SAPTRA ,D/F COVER/BOWLS & ASSY W/O/FILTER INSERTS					
PART NO.	DESCRIPTION	NO.	APPLICATIONS		RATE
RJ1350	1350 Feed Pump Qualish	L15	Toyota Qualis		#N/A
RJ407	9207/9205 D/Filter Cover Small Single 407	L22	407		#N/A
RJ4505	4505 Water Separator Cav Ty.	L32	CAV type Vertical		#N/A
RJ4506	4506 Water Separator Mico Ty.	L31	Mico type Horizontal		#N/A

W/SAPTRA ,D/F COVER/BOWLS & ASSY W/O/FILTER INSERTS

PART NO.	DESCRIPTION	NO.	APPLICATIONS	RATE
RJ4510	4510 Water Separator Top Tc		TC	#N/A
RJ9029	9029 D/Filter Assy.Big Di	L17	_do_	#N/A
RJ9072	9072 D/F Plate Ford (9072(100)Small (L)	L1	Ford Tractor	#N/A
RJ9074	9074 D/F Plate Escort (9074-106)Small (R)	L5	Escort Tractor	#N/A
RJ9101	9101 D/Filter Bowl Small	L30	0.5 Litre	#N/A
RJ9106	9106 D/Filter Assy Escort Small (L)	L6	_do_	#N/A
RJ9111	9111 D/Filter Bowl Big	L29	1.1 Litre	#N/A
RJ9116	9116 D/Filter Assy.Peugeot	L12	_do_	#N/A
RJ9200	9200 D/Filter Assy.Big Single Ty.	L28	---	#N/A
RJ9282	9282 D/Filter Plate Big L/L Hino	L20	L/L Hino	#N/A
RJ9300BR	9300-Br Duel Filter Bracket Tc		TC	#N/A
RJ9300PL	9300-Pl Duel Filter Cover (Plate)Tc		TC	#N/A
RJ9524	9524 D/F Plate Massey (9524-012)Small (L)	L3	Massey Tractor	#N/A
RJ9532	9532(029)D/F Plate Big Di	L16	HMT Zetor Tractor	#N/A
RJ9554	9554 D/F Plate Peug.W/H.P (9554-116)	L11	Mahindra Peu Tract.	#N/A
RJ9556	9556 D/F Plate M&M Tractor (9556-117)Small (C)	L7	Mahindra Tractor	#N/A
RJ9558	9558 D/F Plate L/L Tractor (9558-028)	L18	L/L, Tractor	#N/A
RJINDICA	9315 D/F Plate W/Hand Indica	L14	Lucas Pump CAV Indica	#N/A
RJINDICAB	9010/4555 D/Filter Bowl Cav Ty.Indica/Ace		Indica/Ace	#N/A
RJSUMO	9310 D/F Plate W/Hand Pre.Sumo	L13	Lucas Pump Sumo	#N/A

