Useful Attributes:

To keep logic from being synthesized away

Example:

```
attribute syn_keep: boolean;
SIGNAL ClkAndUP :  STD_LOGIC;
attribute syn_keep of ClkAndUP: signal is true;

   ClkAndUP <= Clk AND UP;
```

To have a register power-up with a certain logic

Example:

```
signal my_reg : std_logic;
attribute power_up_option : string;
attribute power_up_option of my_reg: signal is "-name POWER_UP_LEVEL HIGH";
```