Camera Drones Handheld Specialized Explore Support



# DATALINK PRO Specs

Home / Products / Datalink Pro / Specs

#### Performance

Transmission Power

### DATALINK PRO 400:

- China: 10 dBm
- Taiwan China: 10 dBm
- South Korea: 10 dBm

#### DATALINK PRO 900:

CE: 13 dBmFCC: 27 dBm

Transmission Range

Power Consumption

# Power Supply

Voltage

Max. Current (Transmitting Signal)

Max. Current (Receiving Signal)

#### **Features**

Frequency Band (MHz)

Serial Data Rate

Antenna Options

Supported Interfaces

Supported Max. Mobile Station Number

Supported DJI Products

Operating Temperature

Storage Temperature

Humidity

Dimension (without Antenna)

Weight (without Antenna)

DATALINK PRO 400:

• Taiwan China: 1000 m

• Korea: 1000 m

• China: 600m

DATALINK PRO 900:

• Japan: 1200 m

• Australia: 2000 m

• FCC: 2000 m

• CE: 300 m

DATALINK PRO 400:

• Base Station: 2.1 W

• Mobile Station: 0.65 W

DATALINK PRO 900:

• Base Station: 1.2 W

• Mobile Station: 0.65 W

• Base Station: DC 9 V

• Mobile Station: DC 9 V

DATALINK PRO 400: 230 mA DATALINK PRO 900: 130 mA

70 mA

DATALINK PRO 400:

• China: 430-432

• Taiwan China: 429.175-429.2375

• South Korea: 447.8625-447.9875

DATALINK PRO 900:

• CE: 869.525

• FCC: 903-925.5

• Canada: 903-925.5

• Australia: 916.5-925.5

• Japan: 923.1-926.3

115200 bps

Vertically polarized

USB, UART, CAN

• Full Duplex Mode: 1

• Broadcast Mode: 32

D-RTK

32° to 113°F (0° to 45°C)

-40° to 185°F (-40° to 85°C)

5% to 95%, non-condensing

• Base Station: 82.9 mm x 51 mm x 14.35 mm

• Mobile Station: 57.8 mm x 42.3 mm x 9.35 mm

• Base Station: 53 g

• Mobile Station: 25.5 g

#### DATALINK PKU DOWINGAUS

Home / Products / Datalink Pro / Downloads

### Documents & Manuals

DJI Datalink Pro Quick Start Guide ZIP PDF 2017-08-23

#### SOFTWARE

**Product Categories** 

DJI Care Refresh

DJI Care Refresh +

DJI Care Pro

Osmo Shield

DJI Assistant 2 URL

## DATALINK PRO FAQ

Home / Products / Datalink Pro / FAQ

1. How do I link the Base Station with the Air System?

2. Can one Base Station used with multiple Mobile Stations?

3. What is the difference between Full Duplex Mode and Broadcast Mode?

4. What are the options for powering the DATALINK PRO?

5. What devices does the DATALINK PRO support other than the D-RTK?

6. What will happen if the DATALINK PRO loses signal during flight?

7. Will the DATALINK PRO transmission frequency interfere with the remote controller?

Where to Buy

Cooperation

Consumer DJI Online Store Fly Safe Newsroom Professional Flagship Stores DJI Flying Tips Events DJI-Operated Stores **Buying Guides** Enterprise Support Components Retail Stores STEAM Education **Product Support** Enterprise Retailers Mini Drones Service Plans Service Request and Inquiry DJI Camera Drones

Agricultural Drone Dealer Help Center

Fly Safe

Security and Privacy

Pro Retailers After-Sales Service Policies DJI Store App Download Center

Your email address

Explore

Community

SkyPixel

DJI Forum

Developer

Subscribe

Get the latest news from DJI

Who We Are Contact Us Careers Dealer Portal RoboMaster DJI Automotive







DJI Privacy Policy · Use of Cookies · Terms of Use · Business Information · Cookie Preferences

Copyright © 2022 DJI All Rights Reserved. Feedback on web experience

United States / Engl